

LEGACY SERIES OPERATIONS MANUAL

Models: L1250 L1350 L2550 L2650
L2700 L3100 L3105 L4145
L5175 L6205



OPERATIONS MANUAL - LEGACY SERIES



© 2015 Mathews Company
500 Industrial Avenue
Crystal Lake, IL 60012 USA
Toll Free: (800) 323-7045
www.mathewscompany.com

CSA 3.8 2014 Certified Dryers



The following instructions pertain to dryers built and certified to the CSA 3.8 2014 standard and is meant for qualified personnel only.

Gas Installation

The equipment shall be installed in accordance with the Natural Gas and Propane Installation Code, CSA B149.1 and the Propane Storage and Handling Code, CSA B149.2, or applicable provincial regulations, which should be carefully followed in all cases. Authorities having jurisdiction should be consulted before installations are made.

Installation of Fuel Piping

LP

LP installations shall conform to the following:

- The LP supplier must install the appropriate supply line in Type K copper underground from the supply tank to the edge of the concrete pad as per B149.1,2. This is solely the responsibility of the fuel supplier under the Z code.
- If an underground installation is not preferred, a continuous run of black iron and copper can be installed above the concrete.
- A continuous piece of type K copper can be used through or under the concrete provided that it is protected by sleeves or in a channel. A coil at the final connection can be used as an expansion provided it is not kinked.
- A typical installation on LPG starts with the Type K copper ending at the pad followed by a swing joint attached to lengths of SK80 piping fittings with resign coated hanger brackets attached to the concrete to avoid galvanic reaction. The final connection shall have a swing joint or category 1 expansion hose no longer than 3 feet in length followed by a SK 80 union to facilitate removal and final attachment to ball valve supplied by manufacturer.

Pertinent code clauses pertaining to basic installation:

- B149.1 6.16.3 piping and tubing shall be mounted and braced to provide for vibration, contraction or jarring.
- B149.1 6.14.1 a defective section of piping or tubing shall be replaced
- B149.1 6.14.5 piping shall not be field bent
- B149.1 6.9.6 joint sealant shall conform to Can/ulc 642 and shall be applied to male threads of the pipe
- B149.1 6.8.1 piping ends shall be free of cuttings and burs
- B149.1 6.8.2 piping shall be reamed
- B149.1 6.14.2 bushings shall not be nested
- B149.1 6.11.9 provide effective swing joints at manifolds to accommodate for expansion and contraction and ground level and at appliance level
- B149.1 6.20.5 metallic gas hose can be used in commercial or industrial environments where vibrations, expansions or contractions are present.
- B149.1 6.20.3 gas hose for a PERMANENT installation shall not exceed 10 feet in length a permanent installation consists of an appliance hard wired to the electrical source a generator or PTO is considered temporary and can be moved.
- B149.1 6.16.1 piping exposed to atmospheres shall be painted or coated
- B149.1 6.17.1 standard practice paint Liquid propane piping RED.
- B149.1 union should be installed to facilitate removal of piping if required.

- B149.1 6.2.2 a fitting used shall with steel shall be malleable iron or steel
- B149.1 hydrostatic relief devices shall be used where liquid propane can be trapped and vented to a safe location
- B149.1 6.4.3 schedule 80 piping and fittings shall be used on liquid phase systems or over 125 psi
- B149.1 6.16.6 when piping or tubing is run in a sleeve the sleeve shall be of a type of material that will avoid galvanic reaction and protect the tubing
- B149.1 6.15.10 when tubing is laid under pavement and re-enters above ground a sleeve shall be used to protect the tubing through the concrete.
- B149.1 6.2.15 plastic pipe shall not be used in a liquid piping system
- B149.1 6.4.17 close nipples, street elbow or street T shall not be used
- B149.1 6.2.5 flare nuts shall not be externally forged or machined and shall be of the forged type
- B149.1 6.2.4 copper shall be of the type K,G or L
- B149.1 6.9.9 a joint in seamless copper shall be of a flared type

NG

NG installations shall conform to the following:

- Typically a gas meter is installed 15 feet away from the grain dryer. A pipe can be extended with a union to the pavement level with a swing joint before attaching to the pavement as the meter can move independently from the concrete pad. This can then be followed by a length of pipe to an additional swing joint, or type 2 gas hose, acting as a swing joint attached to the final connection with a union. There shall be a shut off valve after the union.

Pertinent code clauses pertaining to basic installation:

- B149.1 6.4.17 close nipples, street elbow or street T shall not be used
- B149.1 union should be installed to facilitate removal of piping if required.
- B149.1 6.2.2 a fitting used shall with steel shall be malleable iron or steel
- B149.1 6.20.3 gas hose for a PERMANENT installation shall not exceed 10 feet in length a permanent installation consists of an appliance hard wired to the electrical source a generator or PTO is considered temporary and can be moved.
- B149.1 6.16.1 piping exposed to atmospheres shall be painted or coated yellow
- B149.1 6.16.3 piping and tubing shall be mounted and braced to provide for vibration, contraction or jarring.
- B149.1 6.14.1 a defective section of piping or tubing shall be replaced
- B149.1 6.14.5 piping shall not be field bent
- B149.1 6.9.6 joint sealant shall conform to Can/ulc 642 and shall be applied to male threads of the pipe
- B149.1 6.8.1 piping ends shall be free of cuttings and burs
- B149.1 6.8.2 piping shall be reamed
- B149.1 6.14.2 Bushings shall not be nested
- B149.1 6.11.9 provide effective swing joints at manifolds to accommodate for expansion and contraction and ground level and at appliance level
- B149.1 6.20.5 metallic gas hose can be used in commercial or industrial environments where vibrations, expansions or contractions are present.
- B149.1 6.20.3 gas hose for a PERMANENT installation shall not exceed 10 feet in length a permanent installation consists of an appliance hard wired to the electrical source a generator or PTO is considered temporary and can be moved.
- B149.1 6.4.3 schedule 40 piping and fittings shall be used on systems or under 125 psi

Field Installed Wiring

Dryer wiring from the branch circuit is included in the field installation wiring schematic. All wiring is to be in accordance with the Canadian Electrical Code, Part1, CSA C22.1

This dryer is not service rated, and will require an additional overload protection device in front of the dryer for adequate protection. All wiring is to be in accordance with the Canadian Electrical Code, Part1, CSA C22.1.

The electrical installation should follow domestic NEC standards.

Minimum wire size is 18awg unless specified.

All wire gauges shown on the drawing are recommended only! Electrical contractor should follow the local codes and authority having jurisdiction.

All wire sizing based on copper conductors, but aluminum may be used if sized correctly.

This dryer is not service rated. Proper service protection is recommended.

Pressure Testing

The dryer and its individual shutoff valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 psi (3.5 kPa). The dryer must be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psi (3.5 kPa)

Min/Max Gas Supply Pressures

Refer to the dryer rating plate for determining the minimum gas supply pressure for obtaining the maximum gas capacity for which this dryer is specified.

Leak Tests

Gas leak tests need to be performed during dryer start-up to verify the gas-tightness of the dryer's components and piping under normal operating conditions. During the tests, observations should be made at the gauges attached to the unit. If the gauges are reading 0, there could be a leak as the system is normally under pressure. A soapy water solution can be used to check fittings for leaks while the unit is in operation by a 60/40 mixture of soap and water with a brush. Gauges can be installed before and after the safety shutoff valves. The unit can be bumped and shut off. If the gauges return to 0, a leak could be present.

Gas Tightness Check

Safety shut off valves need to be tested for tightness annually. To test, inlet connections should be soap tested up to the safety shut-off valves or solenoid. From there, install gauges in between the safety shut-off valves or solenoids. Fire up the dryer with the firing valve closed. The firing valve is the valve located just before the burner. The safety shut-off valves will open, pressurizing the system and allowing the gauges to read pressure. The dryer will fail on ignition and the gauges should remain pressurized. If the gauges drop in pressure with the firing valve closed, that would indicate a potential leak. If the gauges return to 0 soap testing should commence on all fittings.

Venting

The following specifications need to be followed in regards to venting:

- B149.1 5.4.1 hydrostats must be vented to a “safe location”
- B149.1 5.4.2 hydrostats may be vented into a common header provided the cross sectional area is equal to the cross sectional area of the multiple vents IE: 2 /12 “ hydrostats must vent into a 1” line
- B149.1 5.5.6 vents must be designed not to allow water, insects or debris simply put use a drip and a 90 at the end of the pipe with a screen
- B149.1 5.5.9 vents shall terminate 10 feet from mechanical air intake
- B149.1 5.5.8 vents shall not be capped off or made in-operable
- B149.1 5.5.4 vents shall not be reduced in size as to impede on the performance.

Emergency Manual Shut-off Valve

The gas piping installer must install a manual emergency shutoff valve in an appropriate location that allows access to this valve to shut off the fuel to the dryer in case of a fire or explosion at the dryer. This installation must conform to the following:

- B149.1 6.18.2 a readily accessible manual shutoff valve must be installed as per below. Either one is acceptable.
- In the drop or rise, as close as possible to the valve train of a commercial or industrial valve train.
- In the horizontal piping of the drop or riser and the appliance valve train within 2 feet of the appliance.

Warning

If the information in the operations manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

What To Do If You Smell Gas

- Do not try to light any appliance
- Extinguish any open flames
- Do not touch any electrical switch
- Immediately call your gas supplier. Follow the gas supplier’s instructions
- If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency or the gas supplier
- Improper installations, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operating, and maintenance instructions thoroughly before installing or servicing this equipment.

For Your Safety

The use and storage of gasoline and other flammable vapors and liquids in open containers in the vicinity of this appliance is hazardous. Refer to codes and standards CSA 3.8, 4.29.7

Warranty Statement

MATHEWS COMPANY LIMITED WARRANTY FOR WHOLE GOODS





Except as otherwise set forth herein, Mathews Company (Seller) warrants that the equipment supplied by Seller to Buyer shall be free from defects in materials and workmanship when properly installed and operated under normal conditions and in accordance with all applicable instruction manuals. This limited warranty shall expire two (2) years from the date of shipment from Seller's Crystal Lake, Illinois, U.S.A. facility. In addition, for a period of five (5) years from the date of shipment from Seller's Crystal Lake, Illinois, U.S.A. facility, Seller will re-balance M-C Shredder rotors for Buyer at Seller's Crystal Lake, Illinois, U.S.A. facility, provided that the rotors did not become unbalanced through abnormal use by Buyer or were not damaged by Buyer in any way.

To obtain consideration under this limited warranty, Buyer must first notify Seller in Crystal Lake, Illinois, U.S.A., stating in what respects the equipment is believed by Buyer to be defective and providing a list of the parts at issue. Additionally, Buyer must complete a warranty request form stating the machine serial number. Upon receipt by Seller of such notice from Buyer, Buyer may receive authorization from Seller to return the parts. If parts are to be scrapped locally, Buyer will be so advised. If Seller provides Buyer with authorization to return the parts, Buyer shall return such parts to Seller's facility in Crystal Lake, Illinois, U.S.A., transportation prepaid, for examination by Seller. No parts shall be returned to Seller unless Buyer first obtains a return authorization number from Seller. If, in Seller's sole judgment, the parts returned by Buyer are defective and covered under this limited warranty, Seller shall have the option of repairing, rebuilding or replacing such parts. This limited warranty shall not apply to parts which, in Seller's sole judgment, have been the subject of negligence, abuse, accident, misapplication, tampering, alteration, improper adjustment, or electrical problems caused by low voltage conditions; nor shall it apply to consumables, such as belts; nor shall it apply to parts damaged by acts of God, war or civil insurrection, acts of terrorism, improper installation, operation, maintenance or storage, or other than normal application, use or service, including, without limitation, operational failures caused by corrosion, erosion, wear and tear, rust or other foreign materials in the system in which they are utilized.

Failure to give notice within the warranty period shall be a waiver of this limited warranty and no assistance or other action thereafter taken by Seller shall be deemed to extend or revive the warranty period. This limited warranty covers only whole goods and shall not apply to replacement parts or upgrade kits. A separate warranty statement published by Seller covers the warranty on parts and upgrade kits. This limited warranty shall not apply to any products, parts, accessories or other equipment not manufactured by Seller, provided that Seller, upon request by Buyer, shall advise Buyer of any warranties known to Seller that may be offered by the manufacturer of such equipment. This limited warranty shall not cover, and Seller shall not under any circumstances be liable for, damages for injuries to persons or property; loss of crops or other products; losses caused by harvest delays; loss of profits; loss of use; cost of rental equipment; expenses of labor, travel or other items relating to the removal or replacement of defective parts; damages resulting from the removal of defective parts or the installation of repaired, rebuilt or replaced parts; expenses relating to the transportation of parts to and from Seller's facility; any consequential, incidental, contingent or special damages, whether arising in contract, in tort or under statute; or any other damages or expenses not agreed upon in writing by Seller, even if Seller has been advised of the potential for any such damages or expenses.

THIS LIMITED WARRANTY IS IN LIEU OF ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ALL WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE OR USE. No person is authorized to give any other warranty or to assume any other liability on Seller's behalf.

Table of Contents

| | | |
|---|---|-------------|
|  | Introduction | 1.1 |
| | Overview | 1.1 |
| | Grain Drying Principles | 1.1 |
| | Air | 1.1 |
| | Heat | 1.1 |
| | Time..... | 1.1 |
| | Owner / Operator Notes | 1.2 |
| | Warranty Registration | 1.2 |
| | Model / Serial Number / Specifications | 1.2 |
| | Safety | 1.3 |
| | Lock-out / Tag-out Requirements | 1.4 |
| | Blocks..... | 1.5 |
|  | Specifications | 2.1 |
| | Standard Specs | 2.1 |
| | Metric Specs | 2.1 |
| | L1250 Dimensions | 2.2 |
| | L1350 Dimensions | 2.3 |
| | L2550 Dimensions | 2.4 |
| | L2650 Dimensions | 2.5 |
| | L2700 Dimensions | 2.6 |
| | L3100 Dimensions | 2.7 |
| | L3105 Dimensions | 2.8 |
| | L4145 Dimensions | 2.9 |
| | L5175 Dimensions | 2.10 |
| | L6205 Dimensions | 2.11 |
|  | Equipment Overview | 3.1 |
| | Main Dryer Components | 3.1 |
| | High Voltage Cabinet | 3.3 |
| | Auxiliary High Voltage Cabinet | 3.4 |
| | Pinnacle Lite Remote Cabinet | 3.5 |
| | Burner Control Cabinet | 3.6 |
| | Discharge Moisture Sampler | 3.8 |
| | Gas Train | 3.9 |
| | LPG Gas Train (with Optional CE Requirements) | 3.9 |
| | NG Gas Train (with Optional CE Requirements)..... | 3.9 |
| | LPG Gas Train (With Optional CGA Requirements)..... | 3.10 |
| | NG Gas Train (With Optional CGA Requirements) | 3.10 |
| | Fuel Oil Gas Train | 3.10 |
| | Burner | 3.12 |
| | Venturi Burner (LPG or Natural Gas) | 3.12 |
| | Riello Burner (Fuel Oil) | 3.13 |
| | Pump Overview | 3.14 |
| | Oil Stand Pipe Assembly & Fuel Pump Operation | 3.15 |
| | Internal Burner Parts | 3.16 |
| | Internal Burner Electrical Components | 3.17 |
| | Burner Nozzles & Electrode Adjustment | 3.18 |
| | Burner Air Adjustment..... | 3.24 |
| | Fuel Schematic..... | 3.26 |
|  | Operating Procedures | 4.1 |

| | |
|--|-------------|
| Overview | 4.1 |
| Component Adjustments | 4.1 |
| Air Pressure Switch | 4.1 |
| High Limit Switch | 4.2 |
| Grain Fill System | 4.4 |
| Temperature Controller | 4.6 |
| Variable Frequency Drive (VFD) | 4.10 |
| Changing Variable Frequency Drive Parameters | 4.11 |
| Venturi Burner (LPG & NG only) | 4.12 |
| Operational Procedures | 4.13 |
| First Time Start-Up | 4.13 |
| Daily Shut-Down | 4.14 |
| Daily Start-Up | 4.15 |
| End-of-Season Shut-Down | 4.15 |
| Suggested Plenum Temperatures | 4.17 |
| Suggested Discharge Rate | 4.18 |

 **Maintenance** **5.1**

| | |
|--------------------------------|------------|
| Overview | 5.1 |
| Pre-Season Checks | 5.1 |
| Grain Fill & Discharge System | 5.1 |
| Belt Adjustment | 5.1 |
| Fans & Burners | 5.2 |
| Lubrication | 5.3 |
| Outer Screens | 5.4 |
| Inner Screens | 5.4 |
| Post-Season Maintenance | 5.4 |

 **Troubleshooting** **6.1**

| | |
|---|-------------|
| Diagnosing a Dryer Shutdown | 6.1 |
| Safety Circuit Overview | 6.1 |
| Safety Circuit Schematic | 6.3 |
| Customer Interface | 6.4 |
| Customer Connections | 6.4 |
| Temperature Controller | 6.4 |
| Always Overshoots the Setpoint Temperature | 6.4 |
| Unable to Reach Setpoint Temperature | 6.4 |
| Plenum Temperature Will Not Hold Satisfactorily | 6.5 |
| Controller Fault Codes | 6.5 |
| Variable Frequency Drive (VFD) | 6.6 |
| Display Faults | 6.6 |
| Fault Code Description | 6.6 |
| Fuel Oil Burner Faults | 6.16 |
| Common Diagnostic Issues | 6.18 |

 **Appendix** **7.1**

| | |
|--|------------|
| Normal Start Up Procedure (Oil Fire Model Dryers) | 7.1 |
| General Safety Control Circuit Shutdown (Oil Fire Model Dryers) | 7.4 |
| Plenum Temperature High Limit Shutdown (Oil Fire Model Dryers) | 7.6 |
| Loss of Air Pressure Shutdown (Oil Fire Model Dryers) | 7.7 |
| Low Fuel Pressure Shutdown (Oil Fire Model Dryers) | 7.8 |

 **Notes** **8.1**

Introduction

This volume of the manual is intended to provide you with an overview of the construction, operation and maintenance of your Mathews Company Legacy Series Grain Dryer. The information contained herein is divided into 6 sections which are: Introduction, Specifications, Equipment Overview, Operating Procedures, Maintenance and Troubleshooting.

Overview

The majority of the information in this manual applies to all Legacy Series Grain Dryers, however it is important to understand that there are different configurations and options that may or may not be included on your particular machine. In most cases it is indicated where there is a feature that may not be configured on all machines with a note of "if equipped" or "optional".

Grain Drying Principles

Understanding fundamental grain drying principles is an important element of the operation of your grain dryer. As such, the following is a brief overview of the grain drying process.

Grain drying is a mass transfer process consisting of the removal of water by evaporation from the grain. In its most simplest concept, drying consists of three main components, Air, Heat and Time:

Air

Ambient air is supplied to a fan that is horizontally mounted on the exterior of the dryer which pushes it through a burner to raise its temperature, then forces it across the column of grain. The function of the heated air is to facilitate a heat and mass transfer process. As the heated air passes over the grain, the heat from the air is transferred to the grain thereby elevating the temperature of the grain (heat transfer). Similarly, as the grain is heated, the moisture of the grain will start to exit to its surroundings as the equilibrium moisture of the grain is reached. This leads to the transfer of moisture from the grain to the air (mass transfer).

Heat

The accurate control of this heating process is what makes the equipment energy efficient. As the ambient conditions (temperature and relative humidity) change, as well as the desired plenum setpoint, the gas control system will respond to opening or closing to allow more or less fuel to flow to the burner.

Time

The time element of grain drying refers to the time the grain is spent inside the dryer. The time that the grain is exposed to the heated air determines how much moisture is driven out of the grain. The longer the exposure, more moisture removal occurs. As such, the best method for controlling the amount of moisture removal in the grain is to increase or decrease the grain's retention time by increasing or decreasing the discharge metering speed. The slower the metering system operates, the longer the grain is exposed to the heated air and the moisture removal is increased. The faster the metering system operates, the shorter the grain is exposed to the heated air and the moisture removal is decreased. The easiest way to keep good



grain quality and accurate control is to keep heat and air consistent while varying only grain retention time, which has proven to be the most common and efficient way to dry grain.

Owner / Operator Notes

Before operating your grain dryer, it is strongly encouraged that you read the contents of this Operations Manual as well as Volume 2 - Pinnacle Lite Controls Manual. It will be important for you to become familiar with the controls, adjustments and settings required to obtain efficient operation.



To keep your dryer operating at its peak efficiency, it should be cleaned, lubricated, belts tensioned, ignition system checked, and the fill/takeaway in good operating condition. Refer to the Maintenance Section to understand the required maintenance and suggested intervals. The Pre-Season check can be made when the dryer is empty. Any necessary repairs or adjustments should be completed so that the dryer will be ready to operate before your drying season begins.

Warranty Registration


It is important to send in your warranty registration card as soon as your new grain dryer is delivered. Not only does the card validate your warranty, but it also assists Mathews Company in disseminating information particular to your dryer model.

Model / Serial Number / Specifications

The model and serial number of your Mathews Company continuous flow grain dryer are stamped on plates located on the base of the dryer as shown:



Specifications for the machine will be located on the nameplate which is located on the inside door of the High Voltage Cabinet as well as on the inside of the Remote Cabinet. A sample nameplate is shown below:



Safety

While operating or performing maintenance on your machine, it is important to make safety a top priority. Be sure to read and understand the operations manual before attempting to operate the dryer. The following list of best practices should be followed to help ensure safe operation:

1. Keep ALL guards, access doors, covers, safety decals, and safety devices in place and securely fastened. Never operate the dryer while guards are removed.
2. Keep all untrained personnel away from system components and control panels at all times.
3. Never attempt to operate the unit by jumping or otherwise bypassing any safety devices.
4. Always open the main power supply disconnect switch and lock it in the open position with an approved lockout device prior to performing any service or maintenance work on the fan or burner unit.
5. Lock out power before removing guards, access doors, and covers.
6. Keep hands, feet and clothing away from all rotating parts.
7. Electrical repairs should be performed by trained and qualified personnel only. Failure to follow safe electrical procedures can result in serious injury.
8. If it should become necessary to perform checks on system components or high voltage test with energized circuits, proceed with extreme caution and follow all established safety practices.
9. Routinely check for any gas leaks.
10. Do not allow children or bystanders to be near the grain dryer or grain handling machinery while it is operating.
11. Do not operate the grain dryer without all safety shields in place and secure.



Lock-out / Tag-out Requirements

The purpose of a lock-out / tag-out procedure is to prevent injury and/or death to personnel by requiring that certain precautions be taken before servicing or repairing equipment. This includes shutting off and locking-out the electrical power source of the equipment. A standard Lock-out / Tag-out program is explained as follows:

1. All maintenance personnel are issued a suitable lock (or locks) that is durable. The lock has the individual's name and other identification on it. Each worker must have his/her own lock and the only key to that lock. In addition, locks can be color coded to indicate different shifts or types of services.
2. Each person who will be working on the machinery should put a lock on the machine's lockout device(s). Each lock must remain on the machine until the work is completed. Only the individual who placed the lock should remove his/her lock.
3. Check to be sure that no one is operating the machinery before turning off the power. The machine operator must be informed before the power is turned off. Sudden loss of power could cause an accident.
4. Any mechanism under load or pressure, such as springs, should be released and blocked.
5. All energy sources that could activate the machine must be locked-out.
6. The main valve or main electrical disconnect must be tested to be sure that the power to the machine is off.
7. Electrical circuits must be checked by qualified persons with proper and calibrated electrical testing equipment. An electrical failure could energize the equipment, even if the switch is in the OFF position. Stored energy in electrical capacitors should be safely discharged.
8. Return disconnects and operating controls to the OFF position after each test.
9. Attach accident prevention tags. The tags will give the reason for placing the tag, the name of the person placing the tag, how he/she may be contacted, and the date and time the tag was placed.

The following are some images of lock out tag out material that can be used for locking out the work area:





Blocks

Suitable blocks are another important safety device for making a piece of equipment safe to be repaired or serviced. Blocks must be placed under raised dies, lifts, or any equipment that might inadvertently move by sliding, falling, or rolling.

Blocks, special brackets, or special stands, such as those commonly used under raised vehicles, must be available at all times. Another form of blocking is the placement of a blind. A blind is a disk of metal placed in a pipe to ensure that no air or other substance will pass through that point if the system is accidentally activated.

Before installing blinds or blocks, bleed down steam, air or hydraulic lines to get rid of any pressure. Coiled springs, spring loaded devices or suspended loads must also be released so that their stored energy will not result in inadvertent movement.



Specifications




Standard Specs

| Model | L1250 | L1350 | L2550 | L2650 | L2700 | L3100 | L3105 | L4145 | L5175 | L6205 |
|--------------------------------------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| Holding Capacity (bu) | 474 | 712 | 904 | 1,019 | 1,019 | 1,326 | 1,326 | 1,633 | 1,940 | 2,247 |
| Grain Column Thickness | 12" | 12" | 12" | 12" | 12" | 12" | 12" | 12" | 12" | 12" |
| Grain Column Length | 16'-0" | 24'-0" | 24'-0" | 24'-0" | 24'-0" | 24'-0" | 24'-0" | 24'-0" | 24'-0" | 24'-0" |
| Burner Capacity (heat+cool) MMBTU/hr | 3.29 | 3.97 | 7.46 | 10.33 | 10.33 | 16.45 | 16.91 | 14.32 | 19.09 | 23.86 |
| Burner Capacity (all heat) MMBTU/hr | 5.01 | 7.01 | 10.56 | 13.50 | 13.50 | 20.01 | 19.89 | 22.08 | 26.85 | 31.62 |
| Number of Fans | 2 | 2 | 3 | 3 | 4 | 4 | 6 | 6 | 7 | 8 |
| Total Fan Motor Size (HP) | 25 | 35 | 55 | 65 | 70 | 100 | 105 | 145 | 175 | 205 |
| Level Auger Motor Size (HP) | 3 | 5 | 5 | 5 | 5 | 5 | 5 | 10 | 10 | 10 |
| Unload Auger Motor Size (HP) | 1.5 | 1.5 | 1.5 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| Electrical Load (208V/3ph/60Hz) | 129 Amps | 164 Amps | 218 Amps | 367 Amps | 276 Amps | 367 Amps | 371 Amps | 481 Amps | 581 Amps | 681 Amps |
| Electrical Load (230V/3ph/60Hz) | 118 Amps | 151 Amps | 201 Amps | 232 Amps | 255 Amps | 334 Amps | 343 Amps | 437 Amps | 527 Amps | 617 Amps |
| Electrical Load (460V/3ph/60Hz) | 59 Amps | 75 Amps | 100 Amps | 116 Amps | 127 Amps | 167 Amps | 171 Amps | 219 Amps | 264 Amps | 309 Amps |


Metric Specs

| Model | L1250 | L1350 | L2550 | L2650 | L2700 | L3100 | L3105 | L4145 | L5175 | L6205 |
|--|---------|---------|----------|----------|----------|----------|----------|----------|----------|----------|
| Holding Capacity (m3) | 16.6 | 25.0 | 31.7 | 35.8 | 35.8 | 46.5 | 46.5 | 57.3 | 68.1 | 78.8 |
| Grain Column Thickness (cm) | 30.5 | 30.5 | 30.5 | 30.5 | 30.5 | 30.5 | 30.5 | 30.5 | 30.5 | 30.5 |
| Grain Column Length (m) | 4.9 | 7.3 | 7.3 | 7.3 | 7.3 | 7.3 | 7.3 | 7.3 | 7.3 | 7.3 |
| Burner Capacity (heat+cool) kW thermal | 962 | 1,160 | 2,180 | 3,019 | 3,019 | 4,808 | 4,942 | 4,185 | 5,579 | 6,973 |
| Burner Capacity (all heat) kW thermal | 1,464 | 2,049 | 3,086 | 3,946 | 3,946 | 5,848 | 5,813 | 6,453 | 7,847 | 9,241 |
| Number of Fans | 2 | 2 | 3 | 3 | 4 | 4 | 6 | 6 | 7 | 8 |
| Total Fan Motor Size (kW) | 18.8 | 26.3 | 41.3 | 48.8 | 52.5 | 75.0 | 78.8 | 108.8 | 131.3 | 153.8 |
| Level Auger Motor Size (kW) | 2.3 | 3.8 | 3.8 | 3.8 | 3.8 | 3.8 | 3.8 | 7.5 | 7.5 | 7.5 |
| Unload Auger Motor Size (kW) | 1.1 | 1.1 | 1.1 | 2.3 | 2.3 | 2.3 | 2.3 | 2.3 | 2.3 | 2.3 |
| Electrical Load (380V/3ph/50Hz) | 72 Amps | 93 Amps | 124 Amps | 143 Amps | 156 Amps | 207 Amps | 210 Amps | 271 Amps | 327 Amps | 383 Amps |


L1250 Dimensions




L1350 Dimensions









L2550 Dimensions




L2650 Dimensions









L2700 Dimensions




L3100 Dimensions




L3105 Dimensions




L4145 Dimensions



L5175 Dimensions



L6205 Dimensions




Equipment Overview

The Equipment Overview section will help identify parts of the dryer and briefly explain their function. The images will physically show you what the component(s) look like and the description following will state their purpose.

Main Dryer Components

The following rendered image shows an overall view of the dryer with some of the main components highlighted. The pages following will explain these components or assemblies more in depth as well as explain the function of any associated parts.





Rotary (Bin) Fill Switch

The Rotary Fill Switch is located in the wet hopper on the opposite end of the fill tube and is powered by 120V. The switch is motorized and will rotate a paddle until wet grain comes in contact with the paddle. Once this happens, grain stops the rotation and proves the level of grain in the hopper.



Plenum Thermocouple

The Plenum Thermocouple is a temperature sensing device located in the plenum used to send a signal to the temperature controller to establish and maintain plenum temperature.



Mid-Grain RTD Assembly

The four Mid-Grain RTD (Resistance Temperature Device) Assemblies are located around the perimeter of the dryer and are used to detect the temperature of the grain in the column. Each of these four RTD assemblies is equipped with a 4-20mA transmitter which provides an analog input signal sent to the PLC.



Linear Limit Circuit (LLC) Switch (if equipped)

The Linear Limit Circuit (LLC) Switch is wrapped around the screen section of the dryer and provides a safety shutdown when over-temperature is detected.



Proximity Switch

The Proximity Switch is used to detect the rotation of the discharge metering system by sensing the proximity of a detector on the discharge metering shaft. If the rotation of the shaft goes undetected for a set duration of time, the machine will be shutdown.



Control Power Transformer

The Control Power Transformer is used to transform a portion of the incoming electrical power to reliable 120V control power which is used to supply power to various electrical components including the PLC.





Infeed DM510 Moisture Sensor (Optional)

The infeed moisture sensor is mandatory for AccuDry grain dryers, and optional for TruDry grain dryers. This sensor monitors incoming grain in real-time so that the AccuDry prediction model can react to incoming grain moisture changes. On an optional TruDry grain dryer, this will only display on the main screen, and will not affect the operation of the grain dryer.



High Voltage Cabinet

The High Voltage Cabinet contains all of the motor starters and protectors, main power disconnect, programmable logic controller (PLC), variable frequency drive (VFD), breakers, relays, and other associated electrical hardware.




Auxiliary High Voltage Cabinet

The Auxiliary High Voltage Cabinet contains all of the motor starters and protectors, main power disconnect, and other associated electrical hardware for the top fans on L2700 and larger machines.



Pinnacle Lite Remote Cabinet

The Pinnacle Lite Remote Cabinet is where all of the dryer controls are located including the Pinnacle Lite HMI touch screen, power switches and indicator lights, as well as fan, burner, fill and discharge controls.



Illuminated Push Button



The amber colored Illuminated Push Buttons are a combination push button and indicator light device which individually indicate the status of the air pressure and high limit switches associated with its respective fan and burner. These push buttons also serve an additional purpose which is to reset the associated plenum's temperature controller mounted in the burner control box. Pressing both of the push buttons simultaneously will reset the temperature controller by cycling the power.

Illuminated Selector Switch



Illuminated Selector Switches are a combination selector switch and indicator light device which is used to start/stop devices and also indicate that the associated devices are in operation when looking at the remote cabinet from a distance.

Human Machine Interface (HMI) Touch Screen





The HMI Touch Screen is where all Pinnacle Lite controls and related information is displayed. See the Pinnacle Lite Controls Manual for more information.



Burner Control Cabinet

The Burner Control Cabinet houses all of the components to safely operate the fan and burner which includes air pressure switches, high limit switches, ignition boards, and temperature controllers. The cabinet is mounted near the fan and burner for ease of access and/or troubleshooting purposes. This cabinet has a see through door so that the components, including the plenum temperature controllers, can be monitored without opening the door. Additionally, the plenum temperature setpoint can be adjusted locally on the temperature controller or remotely on the Pinnacle Lite HMI touchscreen.





Ignition Board

The Ignition Board controls the overall operation of the burner by supplying high voltage from the coil to the spark plug to ignite the burner, sending signals to open/close the gas valves, and continuously monitoring the presence of a flame for safe and reliable operation.



High Limit Switch

The High Limit Switch utilizes a capillary bulb to sense an over-temperature condition in the plenum which will cause the dryer to shutdown. The high limit setpoint is adjustable on the switch and should be set approximately 40 deg F higher than the plenum temperature setpoint.



Air Pressure Switch

The purpose of the Air Pressure Switch is to prove airflow from the fan for safe operation of the burner. The air pressure switch is adjustable and should be set once the dryer is full of grain. Adjustment of the switch is done in the burner control cabinet and indication of reaching the air pressure switch's setpoint is indicated on the green light on the outside of the burner control cabinet as well as the amber light on the remote cabinet.




Temperature Controller

The Temperature Controller controls the plenum temperature by continuously adjusting the position of the gas control valve and in doing so displays both the setpoint and the actual temperature in the plenum which is measured by the plenum thermocouple. Additionally, the plenum temperature setpoint, actual plenum temperature, and the controller output % can be viewed on the Pinnacle Lite HMI touch screen.



Discharge Moisture Sampler

The discharge moisture sampler is used to continuously collect a sample of grain, move it past the discharge moisture sensor in a controlled and steady fashion, and return the sampled grain back to the discharge of the dryer.



Moisture Sensor



The Moisture Sensor is an electronic device that measures the grain moisture indirectly by measuring the capacitance of the field of grain and correlating it to a voltage. Additionally, there is a small thermistor, which also produces an analog output voltage, mounted on the face of the sensor to measure the grain's temperature to compensate the moisture reading and to provide a real-time indication of the grain's temperatures. These voltages are input to the PLC and when calibrated, will display the discharge grain moisture as well as the temperature on the HMI touchscreen.

Discharge Limit Switch



The Discharge Limit Switch is a spring loaded lever that maintains a normally open contact which is held closed. The purpose of this switch is to detect a discharge grain overload condition that may be a result of a failed discharge auger or takeaway equipment. Once an overload conditions exists, the top door on the discharge auger will lift up and the switch will return to its normally open position; in doing so, the safety circuit is opened and the dryer is shutdown.

Moisture Sampler Auger Motor




The Moisture Sampler Auger Motor is a small fractional HP motor that slowly augers a sample of grain past the moisture sensor and returns the sampled grain back to the primary discharge of the dryer.

Gas Train


The purpose of the gas train is to safely and efficiently supply fuel at the correct pressures and flow rates to the burners. There are several variations of the gas train depending on what model and options are equipped on the machine.

If the dryer is equipped for LPG fuel, there will be liquid lines sending LPG to the vaporizer and back to the manifold. CE equipped machines will have gas pressure switches to meet local codes. CGA equipped machines will have valve proving shut-off valves as well as liquid and vapor venting to meet local codes.


LPG Gas Train (Domestic)




NG Gas Train (Domestic)




LPG Gas Train (With Optional CE Requirements)



NG Gas Train (With Optional CE Requirements)



Fuel Oil Gas Train





Control Valve

The Control Valve is a throttling butterfly valve that controls the fuel flow rate to the burner which is precisely positioned by the control valve actuator. The control valve is connected to the control valve actuator through a mechanical linkage.



Control Valve Actuator

The Control Valve Actuator is an electrical actuator that is connected to the control valve through a mechanical linkage that precisely positions it based on the output of the digital temperature controller. As the plenum temperature drops below the setpoint, the temperature controller tells the control valve actuator to open more, whereas if the plenum temperature rises above the setpoint, the temperature controller tells the control valve actuator to close more.



Strainer

The purpose of the Strainer is to collect any foreign material with a wire mesh filter that may find its way into the fuel supply line.



Solenoid Valve

The Solenoid Valve is to start and stop the flow of fuel to the burner. The opening/closing actuation of the solenoid valve is monitored and performed by the ignition board.



Pressure Relief Valve

The purpose of the Pressure Relief Valve is to automatically open and relieve excess pressure when the line pressure becomes too high. Once the pressure drops, the valve will close and seal again for continued proper operation.



Low / High Gas Pressure Switches (CE equipped machines only)

The Low / High Gas Pressure Switches are adjustable switches used to detect either low gas or high gas pressure in the gas train and shutdown the dryer. These switches are used for CE equipped machines to meet local codes.



Pressure Regulator

The Primary purpose of a Pressure Regulator is to continuously control the supply pressure of the fuel to the gas train manifold. There are various sizes and configuration based on model and configured options, however the primary purpose is the same.



Manual Hand Valve

The purpose of a Manual Hand Valve is to manually open and close various portion of the gas train for maintenance purposes.





Burner

The purpose of the burner is to provide heat to the drying air. This heat comes from the combustion of the supplied fuel and takes place in either the Venturi Burner found on LPG or Natural Gas fired machines or the Riello Burner found on fuel-oil fired machines.

Venturi Burner (LPG or Natural Gas)

The Venturi Burner is a proprietary Mathews Company designed burner that utilizes primary process air and secondary combustion air to burn the fuel thereby producing the required process heat to the drying air.



Spark Igniter

The Spark Igniter receives high voltage current from the ignition board and sparks to provide direct spark ignition for the burner.



Flame Sense Probe

The Flame Sense Probe detects the presence of the flame and provides positive confirmation to the ignition board so that operation of the burner may continue.

Riello Burner (Fuel Oil)

The Riello Burner is used for fuel oil application and utilizes an internal high pressure pump and nozzle to atomize the fuel oil so that efficient combustion occurs thereby producing the required process heat to the drying air.



The Riello Burner is self contained and ready to bolt directly to the mounting panel on the front side of the fan housing.




The guard that protects the burner components from the elements is made from Lexan so that the burner is visible to the operator. This guard is open on the bottom which allows for normal operating adjustments to be made easily. This guard can be removed from the mounting brackets to perform any cleaning or changes to the burner. This open bottom guard design also provides a good steady flow of free air for the blower system. This is important for obtaining maximum capacity and proper cooling of the motor.

The pump and blower motor run on 380 volt, 3-phase 50 Hz power. The contactor coil uses 120 volt control power. The ignition module has an internal 22 second pre-purge and 7 second trial for ignition. The flame



sensing is done by an optic eye. As long as the optic eye senses the flame, the solenoids will remain open allowing for a continuous flame. When the optic eye fails to see the flame, the burner will shut down. The burner must then be cycled off via the ignition switch to restart the burner.

Pump Overview



The pump is located on the lower right side of the burner and the adjustment screw is used for changing the pressure. This adjustment screw is located on the front side of the pump.

The picture illustrates an operator changing the pressure on the burner pump. The adjustment range of the burner is 125 psig minimum and 275 psig maximum. The standard operating pressure for the burner is 250 psig.



The plenum temperature is controlled using the HMI Screen or the Temperature Controller. This unit will cycle a secondary solenoid on and off to obtain and stabilize the temperature. The primary nozzle and solenoid remain energized during the entire running cycle of the burner.

If the burner fails to drop the temperature low enough in primary mode, lower the pressure or change the primary nozzle.



The standard fuel used for these burners is #2 diesel. However, these units can be modified to use 100% bio-diesel made from rapeseed. If the unit uses this bio-diesel fuel, it must have a new burner head, pump and the seals must be changed to withstand corrosion and combustibility.



Oil Stand Pipe Assembly & Fuel Pump Operation

The burner works on a loop system. The oil is fed to the burner and excess oil feeds back through the loop and into the burner again. The feed pressure to the burner is normally 10-20 psig. The fuel tank is located at a maximum of 100 feet away from the dryer. The tank must have a pump and motor assembly to push the fuel to the burner. The burner pump is designed to only pull fuel a maximum of 13 feet. Thus the pump and motor at the tank must fill the stand pipe with fuel and feed the burner. The burner pump will convert 10 psig to 125-275 psig for the burner head.

The standpipe near the bottom of the dryer must contain an oil filter to filter out large debris or particles from the main supply line. The pressure gauges at the burner inlet, the fuel tank pump, and motor feed are to prevent large pressure drops from occurring. The pump and motor unit at the supply tank can be adjusted from 20 psig to 80 psig. It is recommended to always run the unit at the lowest possible pressure that will still produce the desired temperature rise. Either that lowest possible pressure should be run or 20 psig. This is our starting point and should not be changed unless absolutely necessary.



Internal Burner Parts



The internal burner has a stainless steel blast tube and stainless steel air deflector. The blast tube is mounted to the fan scroll and internal burner tube. It provides a venturi effect for flame.


The deflector is located directly after the blast tube weldment and its main purpose is to deflect air from the fan wheels upward to mix the air. This creates an air turbulence that gives an even heat distribution through the plenum chamber of the dryer. This is a mounted component that should never be adjusted.

The internal mixing chamber must have the burner target in place for proper combustion. This part is a stainless steel weldment that bolts in place and is aligned with the blast tube.



The mixing chamber and target make up the housing where the air is heated and passed into the plenum chamber. The air is diverted through this 6' chamber and passes around the target. The target will ensure the air is fully heated. This target must be directly in line with the blast tube weldment.


Internal Burner Electrical Components



The nozzle selection is dependent upon which Fuel Oil Burner is installed on the dryer as well as what degree temperature rise is desired. For RL070 burners, the 5.5 nozzles should be installed for temperature rises between 65oF and 120oF (36oC and 67oC). For temperature rises of 125oF and 180oF (69oC and 100oC), the 8.3 size nozzles need to be installed. For RL100 burners, the 9.0 nozzles should be installed for temperature rises between 100oF and 195oF (56oC and 108oC). For temperature rises of 200oF and 260oF (111oC and 144oC), the 12.0 size nozzles need to be installed.





Burner Nozzles & Electrode Adjustment



Start by removing the lexan burner cover. Then loosen the 4 screws and remove the red molded cover that is shown as item 1. Now remove the 1" bolt on each side of the burner mounting plate, depicted as item 2. Now slide the burner back from the mounting plate. The burner will be supported by the plated rods shown as item 3. These rods will support the weight of the burner while the burner is being worked on.

If additional length is needed on the rods, 2 extensions are mounted under the molded cover and attached to the burner frame. They can be screwed into place and added bolts at the end can work as end stops. The electrode and burner nozzles are all easily accessible in the area marked item 4. See detail for visual location.





The standard nozzle size depends on the burner being used. The larger the size of nozzle, the hotter the burner or plenum temperature. The method of changing nozzles is to unscrew the nozzle and thread the new nozzle directly in its place. The burner nozzle is item 5 in the picture.

The burner electrode is replaceable by unscrewing 2 small screws and removing the bracket. This is shown as item 6. The location of the electrode arc is very critical and should be marked before changing.

The combustion system should be checked at least once a year by a representative of the manufacturer or another specialized technician.

For more information and correct electrode placement, nozzle selection, and maintenance see pages 6-7 of the Riello burner lite manual.



RL 70/2 - L1250

Application(s): drying wheat/sunflowers at normal and low ambient temp / drying corn at normal ambient temp.

| Temperature Rise | | Burner Rate | Burner Rate | Fuel Flow Rate | Nozzle Set A | | | Nozzle Set B | | |
|---------------------|---------|-------------|-------------|----------------|--------------|---------------|-------------|--------------|---------------|-------------|
| (deg F) | (deg C) | (MMBTU/hr) | (kW) | (GPH) | Low Fire (%) | High Fire (%) | Nozzle Size | Low Fire (%) | High Fire (%) | Nozzle Size |
| Nozzle Set A | | | | | | | | | | |
| 65 | 36 | 1.12 | 329 | 8.0 | 92% | 8% | 5.5 | - | - | - |
| 70 | 39 | 1.21 | 355 | 8.6 | 84% | 16% | 5.5 | - | - | - |
| 75 | 42 | 1.30 | 380 | 9.3 | 76% | 24% | 5.5 | - | - | - |
| 80 | 44 | 1.38 | 405 | 9.9 | 68% | 32% | 5.5 | - | - | - |
| 85 | 47 | 1.47 | 431 | 10.5 | 59% | 41% | 5.5 | - | - | - |
| 90 | 50 | 1.56 | 456 | 11.1 | 51% | 49% | 5.5 | - | - | - |
| 95 | 53 | 1.64 | 481 | 11.7 | 43% | 57% | 5.5 | - | - | - |
| 100 | 56 | 1.73 | 506 | 12.3 | 35% | 65% | 5.5 | - | - | - |
| 105 | 58 | 1.81 | 532 | 13.0 | 26% | 74% | 5.5 | - | - | - |
| 110 | 61 | 1.90 | 557 | 13.6 | 18% | 82% | 5.5 | - | - | - |
| 115 | 64 | 1.99 | 582 | 14.2 | 10% | 90% | 5.5 | - | - | - |
| 120 | 67 | 2.07 | 608 | 14.8 | 1% | 99% | 5.5 | - | - | - |
| Nozzle Set B | | | | | | | | | | |
| 125 | 69 | 2.16 | 633 | 15.4 | - | - | - | 67% | 33% | 8.3 |
| 130 | 72 | 2.25 | 658 | 16.0 | - | - | - | 61% | 39% | 8.3 |
| 135 | 75 | 2.33 | 684 | 16.7 | - | - | - | 56% | 44% | 8.3 |
| 140 | 78 | 2.42 | 709 | 17.3 | - | - | - | 51% | 49% | 8.3 |
| 145 | 81 | 2.51 | 734 | 17.9 | - | - | - | 45% | 55% | 8.3 |
| 150 | 83 | 2.59 | 760 | 18.5 | - | - | - | 40% | 60% | 8.3 |
| 155 | 86 | 2.68 | 785 | 19.1 | - | - | - | 35% | 65% | 8.3 |
| 160 | 89 | 2.76 | 810 | 19.7 | - | - | - | 29% | 71% | 8.3 |
| 165 | 92 | 2.85 | 836 | 20.4 | - | - | - | 24% | 76% | 8.3 |
| 170 | 94 | 2.94 | 861 | 21.0 | - | - | - | 18% | 82% | 8.3 |
| 175 | 97 | 3.02 | 886 | 21.6 | - | - | - | 13% | 87% | 8.3 |
| 180 | 100 | 3.11 | 912 | 22.2 | - | - | - | 8% | 92% | 8.3 |

*Note: Based on 1.5" w.c plenum pressure from Riello Charts



RL 100/2 - L1250

Application(s): drying wheat/sunflowers at normal and low ambient temp / drying corn at normal and low ambient temp.

| Temperature Rise | | Burner Rate | Burner Rate | Fuel Flow Rate | Nozzle Set A | | | Nozzle Set B | | |
|---------------------|---------|-------------|-------------|----------------|--------------|---------------|-------------|--------------|---------------|-------------|
| (deg F) | (deg C) | (MMBTU/hr) | (kW) | (GPH) | Low Fire (%) | High Fire (%) | Nozzle Size | Low Fire (%) | High Fire (%) | Nozzle Size |
| Nozzle Set A | | | | | | | | | | |
| 100 | 56 | 1.73 | 506 | 12.3 | 99% | 1% | 9.0 | - | - | - |
| 105 | 58 | 1.81 | 532 | 13.0 | 94% | 6% | 9.0 | - | - | - |
| 110 | 61 | 1.90 | 557 | 13.6 | 89% | 11% | 9.0 | - | - | - |
| 115 | 64 | 1.99 | 582 | 14.2 | 84% | 16% | 9.0 | - | - | - |
| 120 | 67 | 2.07 | 608 | 14.8 | 79% | 21% | 9.0 | - | - | - |
| 125 | 69 | 2.16 | 633 | 15.4 | 74% | 26% | 9.0 | - | - | - |
| 130 | 72 | 2.25 | 658 | 16.0 | 69% | 31% | 9.0 | - | - | - |
| 135 | 75 | 2.33 | 684 | 16.7 | 64% | 36% | 9.0 | - | - | - |
| 140 | 78 | 2.42 | 709 | 17.3 | 59% | 41% | 9.0 | - | - | - |
| 145 | 81 | 2.51 | 734 | 17.9 | 54% | 46% | 9.0 | - | - | - |
| 150 | 83 | 2.59 | 760 | 18.5 | 49% | 51% | 9.0 | - | - | - |
| 155 | 86 | 2.68 | 785 | 19.1 | 44% | 56% | 9.0 | - | - | - |
| 160 | 89 | 2.76 | 810 | 19.7 | 39% | 61% | 9.0 | - | - | - |
| 165 | 92 | 2.85 | 836 | 20.4 | 33% | 67% | 9.0 | - | - | - |
| 170 | 94 | 2.94 | 861 | 21.0 | 28% | 72% | 9.0 | - | - | - |
| 175 | 97 | 3.02 | 886 | 21.6 | 23% | 77% | 9.0 | - | - | - |
| 180 | 100 | 3.11 | 912 | 22.2 | 18% | 82% | 9.0 | - | - | - |
| 185 | 103 | 3.20 | 937 | 22.8 | 13% | 87% | 9.0 | - | - | - |
| 190 | 106 | 3.28 | 962 | 23.5 | 8% | 92% | 9.0 | - | - | - |
| 195 | 108 | 3.37 | 988 | 24.1 | 3% | 97% | 9.0 | - | - | - |
| Nozzle Set B | | | | | | | | | | |
| 200 | 111 | 3.46 | 1013 | 24.7 | - | - | - | 49% | 51% | 12.0 |
| 205 | 114 | 3.54 | 1038 | 25.3 | - | - | - | 45% | 55% | 12.0 |
| 210 | 117 | 3.63 | 1064 | 25.9 | - | - | - | 41% | 59% | 12.0 |
| 215 | 119 | 3.72 | 1089 | 26.5 | - | - | - | 37% | 63% | 12.0 |
| 220 | 122 | 3.80 | 1114 | 27.2 | - | - | - | 33% | 67% | 12.0 |
| 225 | 125 | 3.89 | 1140 | 27.8 | - | - | - | 30% | 70% | 12.0 |
| 230 | 128 | 3.97 | 1165 | 28.4 | - | - | - | 26% | 74% | 12.0 |
| 235 | 131 | 4.06 | 1190 | 29.0 | - | - | - | 22% | 78% | 12.0 |
| 240 | 133 | 4.15 | 1216 | 29.6 | - | - | - | 18% | 82% | 12.0 |
| 245 | 136 | 4.23 | 1241 | 30.2 | - | - | - | 14% | 86% | 12.0 |
| 250 | 139 | 4.32 | 1266 | 30.9 | - | - | - | 11% | 89% | 12.0 |
| 255 | 142 | 4.41 | 1292 | 31.5 | - | - | - | 7% | 93% | 12.0 |
| 260 | 144 | 4.49 | 1317 | 32.1 | - | - | - | 3% | 97% | 12.0 |

*Note: Based on 1.5" w.c plenum pressure from Riello Charts



RL 70/2 - L1350 or L2550

Application(s): drying wheat/sunflowers at normal and low ambient temp / drying corn at normal ambient temp.

| Temperature Rise | | Burner Rate | Burner Rate | Fuel Flow Rate | Nozzle Set A | | | Nozzle Set B | | |
|---------------------|---------|-------------|-------------|----------------|--------------|---------------|-------------|--------------|---------------|-------------|
| (deg F) | (deg C) | (MMBTU/hr) | (kW) | (GPH) | Low Fire (%) | High Fire (%) | Nozzle Size | Low Fire (%) | High Fire (%) | Nozzle Size |
| Nozzle Set A | | | | | | | | | | |
| 50 | 28 | 1.08 | 317 | 7.7 | 97% | 3% | 5.5 | - | - | - |
| 55 | 31 | 1.19 | 348 | 8.5 | 86% | 14% | 5.5 | - | - | - |
| 60 | 33 | 1.30 | 380 | 9.3 | 76% | 24% | 5.5 | - | - | - |
| 65 | 36 | 1.40 | 412 | 10.0 | 66% | 34% | 5.5 | - | - | - |
| 70 | 39 | 1.51 | 443 | 10.8 | 55% | 45% | 5.5 | - | - | - |
| 75 | 42 | 1.62 | 475 | 11.6 | 45% | 55% | 5.5 | - | - | - |
| 80 | 44 | 1.73 | 506 | 12.3 | 35% | 65% | 5.5 | | | |
| 85 | 47 | 1.84 | 538 | 13.1 | 24% | 76% | 5.5 | | | |
| 90 | 50 | 1.94 | 570 | 13.9 | 14% | 86% | 5.5 | | | |
| 95 | 53 | 2.05 | 601 | 14.7 | 4% | 96% | 5.5 | | | |
| Nozzle Set B | | | | | | | | | | |
| 100 | 56 | 2.16 | 633 | 15.4 | - | - | - | 67% | 33% | 8.3 |
| 105 | 58 | 2.27 | 665 | 16.2 | - | - | - | 60% | 40% | 8.3 |
| 110 | 61 | 2.38 | 696 | 17.0 | - | - | - | 53% | 47% | 8.3 |
| 115 | 64 | 2.48 | 728 | 17.7 | - | - | - | 47% | 53% | 8.3 |
| 120 | 67 | 2.59 | 760 | 18.5 | - | - | - | 40% | 60% | 8.3 |
| 125 | 69 | 2.70 | 791 | 19.3 | - | - | - | 33% | 67% | 8.3 |
| 130 | 72 | 2.81 | 823 | 20.1 | - | - | - | 26% | 74% | 8.3 |
| 135 | 75 | 2.92 | 855 | 20.8 | - | - | - | 20% | 80% | 8.3 |
| 140 | 78 | 3.02 | 886 | 21.6 | - | - | - | 13% | 87% | 8.3 |
| 145 | 81 | 3.13 | 918 | 22.4 | - | - | - | 6% | 94% | 8.3 |

*Note: Based on 1.5" w.c plenum pressure from Riello Charts



RL 100/2 - L1350 or L2550


Application(s): drying wheat/sunflowers at normal and low ambient temp / drying corn at normal and low ambient temp.

| Temperature Rise | | Burner Rate | Burner Rate | Fuel Flow Rate | Nozzle Set A | | | Nozzle Set B | | |
|---------------------|---------|-------------|-------------|----------------|--------------|---------------|-------------|--------------|---------------|-------------|
| (deg F) | (deg C) | (MMBTU/hr) | (kW) | (GPH) | Low Fire (%) | High Fire (%) | Nozzle Size | Low Fire (%) | High Fire (%) | Nozzle Size |
| Nozzle Set A | | | | | | | | | | |
| 80 | 44 | 1.73 | 506 | 12.3 | 99% | 1% | 9.0 | - | - | - |
| 85 | 47 | 1.84 | 538 | 13.1 | 93% | 7% | 9.0 | - | - | - |
| 90 | 50 | 1.94 | 570 | 13.9 | 86% | 14% | 9.0 | - | - | - |
| 95 | 53 | 2.05 | 601 | 14.7 | 80% | 20% | 9.0 | - | - | - |
| 100 | 56 | 2.16 | 633 | 15.4 | 74% | 26% | 9.0 | - | - | - |
| 105 | 58 | 2.27 | 665 | 16.2 | 68% | 32% | 9.0 | - | - | - |
| 110 | 61 | 2.38 | 696 | 17.0 | 61% | 39% | 9.0 | - | - | - |
| 115 | 64 | 2.48 | 728 | 17.7 | 55% | 45% | 9.0 | - | - | - |
| 120 | 67 | 2.59 | 760 | 18.5 | 49% | 51% | 9.0 | - | - | - |
| 125 | 69 | 2.70 | 791 | 19.3 | 42% | 58% | 9.0 | - | - | - |
| 130 | 72 | 2.81 | 823 | 20.1 | 36% | 64% | 9.0 | - | - | - |
| 135 | 75 | 2.92 | 855 | 20.8 | 30% | 70% | 9.0 | - | - | - |
| 140 | 78 | 3.02 | 886 | 21.6 | 23% | 77% | 9.0 | - | - | - |
| 145 | 81 | 3.13 | 918 | 22.4 | 17% | 83% | 9.0 | - | - | - |
| 150 | 83 | 3.24 | 950 | 23.1 | 11% | 89% | 9.0 | - | - | - |
| 155 | 86 | 3.35 | 981 | 23.9 | 4% | 96% | 9.0 | - | - | - |
| Nozzle Set B | | | | | | | | | | |
| 160 | 89 | 3.46 | 1013 | 24.7 | - | - | - | 49% | 51% | 12.0 |
| 165 | 92 | 3.56 | 1045 | 25.5 | - | - | - | 44% | 56% | 12.0 |
| 170 | 94 | 3.67 | 1076 | 26.2 | - | - | - | 39% | 61% | 12.0 |
| 175 | 97 | 3.78 | 1108 | 27.0 | - | - | - | 34% | 66% | 12.0 |
| 180 | 100 | 3.89 | 1140 | 27.8 | - | - | - | 30% | 70% | 12.0 |
| 185 | 103 | 4.00 | 1171 | 28.5 | - | - | - | 25% | 75% | 12.0 |
| 190 | 106 | 4.10 | 1203 | 29.3 | - | - | - | 20% | 80% | 12.0 |
| 195 | 108 | 4.21 | 1235 | 30.1 | - | - | - | 15% | 85% | 12.0 |
| 200 | 111 | 4.32 | 1266 | 30.9 | - | - | - | 11% | 89% | 12.0 |
| 205 | 114 | 4.43 | 1298 | 31.6 | - | - | - | 6% | 94% | 12.0 |
| 210 | 117 | 4.54 | 1330 | 32.4 | - | - | - | 1% | 99% | 12.0 |

*Note: Based on 1.5" w.c plenum pressure from Riello Charts




Burner Air Adjustment



The burner has 2 air adjustments. The first of the two is shown as item 7. This is a screw that should be pre-set for the combustion head. The notches on the adjustment screw should be set to notch number 9. This air adjustment is set while the fan and burner are in a static condition.

The second air adjustment is item 9 which is the internal blower air pressure setting. The adjustment is made to item 8 which is a hydraulic plunger. This is adjusted by rotating the housing until item 9, the air pressure gauge displays 9 inches of water column. The hydraulic valve has a lock collar that must be loosened and then the valve bottom will freely rotate. The adjustment is to be done only when the fan is running and burner is in high fire mode.



The above picture displays the air pressure gauge for the combustion chamber. It utilizes a +/- working range of .2" water column.

If the ignition module will not proceed to light the burner, the gauge could be out of adjustment. For more information about adjusting the Riello burner, see page 10 of the Riello burner lite manual. You must remove cover to turn dial guage to appropriate value.




Fuel Schematic

The fuel tank has a 100' maximum run of black pipe schedule 40. The tank pump will push fuel to base of dryer and then up standpipe to burners. The burners will have cheater loop to recycle access fuel back to burner continuously. This will create less fuel demand from tank on continuous basis. The oil feed must be a nice steady supply without creating air in the system. Air in the lines will cause burner to shutdown and thus shutdown drying process. This drying process is a continuous flow and is designed to shutdown on loss of safety circuit or loss of grain. The safety circuit is to establish that everything is running properly. The loss of grain, wet grain in-feed has run empty.

The fuel flow is one directional and never flows back towards tank. The grain is one pass through dryer from wet to dry basis. Then grain can be stored and managed.

Sample dryer shows L1350 dryer with fuel tank and side view with burners in place.



Operating Procedures

Overview

This section will explain the operation of the primary components of the dryer as well as provide step-by-step procedures to properly start-up and shut-down the machine. Operational and functional descriptions along with adjustment details for primary components will be presented initially, followed by operational procedures for starting up and shutting down the dryer.


Component Adjustments

The following information will provide you with the details you need to properly operate the different components of the dryer and to make any adjustments necessary. The components listed in the pages following do not comprise everything that can be adjusted on the dryer, but rather the components that need to be adjusted based on normal operation.

Air Pressure Switch

The purpose of the Air Pressure Switch is to prove airflow from the fan for safe operation of the burner. Once the pressure switch has been satisfied, operation of the burner and its ignition system are permitted. In the event that air pressure is lost as indicated by a non-illuminated air pressure light, the burner will extinguish.

Depending on the number of burners, this will determine the number of air pressure switches, with one installed per burner. The air pressure switch is adjustable and should be set once the dryer is full of grain. Adjustment of the switch is done in the burner control cabinet and indication of reaching the air pressure switch's setpoint is indicated by the green air pressure light on the outside of the burner control cabinet as well as the amber air pressure light on the remote cabinet.



The safety features associated with the air pressure switch(es) are for your safety and for the protection of the dryer. They should be checked for correct operation at the start of the drying season and periodically during the season as they are designed to protect the dryer from a fire that may result from fan (air flow) failure while the burner is ignited and a flame is present.



Setpoint Check

The following procedure shall be utilized to properly check the air pressure switch(es) setpoint. Note that the air pressure switch for each fan/burner must be checked and set independently.

1. After the dryer has been filled with grain and before the burner is ignited, the operation of each air pressure switch must be checked.
2. All of the fans must be running (including the cooling fans) before the air pressure switches can be accurately adjusted.
3. Start all fans and determine if the air pressure switch light (for the switch that is being verified) on the remote cabinet or the burner control cabinet illuminates once the respective fan has reached its normal operating speed.
4. If the indicator light does not illuminate or comes on too soon (before the fan reaches operating speed), the air pressure switch must be adjusted.

Switch Adjustment

In the event that the indicator light does not illuminate or comes on too soon (before the fan reaches operating speed), the following procedure shall be used to properly set the air pressure switch:

1. Remove the cap on the air pressure switch. Inside the air pressure switch use the slotted screw to make adjustments by turning clockwise or counter-clockwise.
2. Turn the adjusting screw counter-clockwise until the air pressure light comes on. After the air pressure light comes on, turn the adjusting screw counter-clockwise an additional $\frac{1}{4}$ to $\frac{1}{2}$ turn to allow for normal changes in static pressure.


The air pressure light will go out when the fan is turned off because the fan start/stop illuminated switch is wired so that the power flows from the fan start/stop illuminated switch to the air pressure indicator light on the remote cabinet and the burner control cabinet.

If all air pressure switch adjustment is used and the air pressure light does not illuminate, the air pressure switch is defective and must be replaced. Once the switch is replaced, check its operation and make adjustments as previously outlined.

High Limit Switch

The purpose of the High Limit Switch is to provide a safety shutdown in the event that the temperature in any of the plenums has exceeded the high limit setpoint. The high limit switch senses the temperature in the plenum that it is monitoring by means of a capillary bulb temperature sensing device.

Depending on the number of burners, this will determine the number of high limit switches, with one installed per burner. The high limit switch is adjustable and should be set once at the start of a drying season or for a given grain. Adjustment of the switch is done in the burner control cabinet and indication is provided by the amber high limit light on the remote cabinet. The light will normally be illuminated if a high limit condition has not been met. Note that when a high limit setpoint is exceeded, the high limit light for the applicable fan/burner will become non-illuminated as well as all other high limit lights above it because the wiring of the switch/lights are in series. For example on a 6-fan/burner system, if high limit in plenum #3 is exceeded, the high limit for plenum 3 through 6 will no longer be illuminated.



High Limit Switch

Burner Control Cabinet



The safety features associated with the high limit switch(es) are for your safety and for the protection of the dryer. They should be checked for correct operation at the start of the drying season and periodically during the season as they are designed to protect the dryer from a fire that may result from fan (air flow) failure while the burner is ignited and a flame is present.

Setpoint Check and Switch Adjustment

The following procedure shall be utilized to properly check the high limit switch(es) setpoint. Note that the high limit switch for each fan/burner must be checked and set independently. Once the high limit setpoint has been reached, the switch will need to be reset by pressing the small reset button on the top of the device.

After the dryer has been filled with grain and after the burner is ignited, the operation of each high limit switch must be checked.

1. Start the fan, ignite the burner and establish a stable temperature in the plenum.
2. Inside the burner control cabinet, adjust the high limit switch setpoint by turning the small dial counter-clockwise to a temperature below the current temperature in the plenum.
3. Once the high limit switch determines that the temperature in the plenum has exceeded the high limit setpoint, the switch will cause the dryer to shutdown and turn off the respective plenum's high limit light on the remote cabinet.
4. If the high limit switch does not shut down the dryer, it is defective and must be replaced. Once the switch is replaced, check its operation and make adjustments as previously outlined.
5. If the setpoint is exceed and properly shuts down the dryer, the setpoint can be adjusted to a value that is approximately 40 deg F above the desired plenum temperature.



Grain Fill System

The dryer control system features both a manual and an automatic grain filling system. To properly fill the dryer and to measure the grain level, the dryer is equipped with a leveling auger as well as a rotary (bin) level switch and two timers (grain flow timer and fill delay timer) located in the Remote Cabinet. Additionally, there is a green illuminated toggle switch with positions "AUTO", "MAN", and "OFF" on the Remote Cabinet. The following modes of grain fill operation are explained:



Pinnacle Lite Remote Control Cabinet



Grain Fill Switch and Light

OFF

When the grain fill switch is in the OFF position, the level auger will not run. Additionally, the status of the grain flow timer, fill delay timer and the rotary (bin) level switch will not be monitored.



Do not allow anyone to be in the dryer when filling it with grain. Always turn off and lock-out the electrical power supply to the High Voltage Cabinet before allowing anyone to work in the dryer.

MAN

When the grain fill switch is in the MAN position, the grain fill system is setup to run manually. Setting the grain fill system to run manually means that the grain flow timer and the fill delay timer are not monitored and the level auger and the rotary (bin) level switch are the only components being utilized to fill the dryer.

Running the grain fill system manually means that as the rotary (bin) level switch does not sense grain level (the paddle is rotating), the level auger will run, your fill equipment will deliver grain to the dryer and the grain fill switch will illuminate. Once the rotary (bin) level switch senses grain level (the paddle is no longer rotating), the level auger will stop running, your fill equipment will no longer be commanded to operate and the grain fill switch will no longer be illuminated. As the dryer discharges grain and the level in the hopper begins to drop, the rotary (bin) level switch will no longer sense grain level (the paddle will start rotating again), the level auger and your fill equipment will start running again as well as illuminating the grain fill switch. This process will continuously operate cycling the level auger and your fill equipment on/off repeatedly because while running the grain fill system is in manual mode, the grain flow timer and the fill delay timer are not used; this is not a recommended way to operate the dryer. Instead, fill your dryer for the first time in manual mode and switch it to automatic once you are ready to begin continuous flow operation.

AUTO


When the grain fill switch is in the AUTO position, the grain fill system is setup to run automatically. Setting the grain fill system to run automatically means that the grain flow timer and the fill delay timer are used in conjunction with the level auger and the rotary (bin) level switch to fill the dryer.

Running the grain fill system automatically means that as the rotary (bin) level switch does not sense grain level (the paddle is rotating) after the grain fill delay timer has elapsed, the level auger will run, your fill equipment will deliver grain to the dryer and the grain fill switch will illuminate. Once the rotary (bin) level switch senses grain level (the paddle is no longer rotating), the level auger will stop running, your fill equipment will no longer be commanded to operate and the grain fill switch will no longer be illuminated. Once the level auger and your fill equipment stop running, both the fill delay timer and the grain flow timer will start. The fill delay timer sets the time delay duration between when the rotary (bin) level switch senses grain level (the paddle is no longer rotating) and when the level auger and your fill equipment will begin running again. Similarly, the grain flow timer begins to countdown once the rotary (bin) level switch senses grain level (the paddle is no longer rotating), however the grain flow timer is used to detect when the fill equipment is no longer able to provide grain to the dryer. If after the level auger and your fill equipment stop running, the grain flow timer duration has been reached without the rotary (bin) level switch sensing grain level (the paddle is no longer rotating), the system will have encountered a grain flow fault and the dryer will be shutdown.

Setting the Timers

Both the fill delay and the grain flow timers are located in the Remote Cabinet. The following explains the procedure for properly setting up your grain fill system. Note that turning the grain fill switch to OFF and back to AUTO will reset the fill delay and grain flow timers.


1. Set the fill delay timer for the desired time, which is recommended to be 1-2 minutes (60-120 sec). To set the timer, simply turn the dial clockwise or counter-clockwise as necessary.
2. Set the grain flow timer for the desired time, which is recommended to be 5-10 minutes. To set the timer, set the arrows at the bottom of the timer face to X10 (times ten) and to M (minutes). It may be necessary to remove the timer from its socket to make this adjustment. Now turn the timer control knob to 1 (1x10) or 10 minutes.
3. Check the refill time a minimum of six times and calculate the average refill time. Once the average grain refill time has been determined, set the grain flow timer equal to the average refill time plus 5 minutes. This will ensure that the dryer will not shutdown unless the average grain refill time has passed and an additional 5 minutes has elapsed without the grain level being reached.



Temperature Controller

The purpose of the temperature controller is to control the plenum temperature by adjusting the position of the fuel control valve by means of the control valve actuator (LPG & Natural Gas burners) or by cycling the burner to high/low fire (Fuel Oil burners). Depending on the number of burners, this will determine the number of temperature controllers, with one installed per burner.

The temperature controller is located in the Burner Control Cabinet and displays the actual and set point temperature as well as indication of controller output and alarms. Additionally, the temperature controllers are in continuous communication with the Pinnacle Lite control system and the actual temperature and setpoint temperature, as well as other parameters, can be viewed on the HMI touchscreen in the Plenums chapter.



Programs

The temperature controller is pre-programmed from the Mathews Company facility with one of six different programs: Tower, Tower (metric), Profile, Profile (metric), Fuel Oil, and Fuel Oil (metric). The program that is loaded on the controller establishes parameters that are specific to the type of machine the controller is installed on and determines the units of display (degrees Celsius or degrees Fahrenheit). There are several parameters that are adjustable on the controller, however most of them are unused and the default values are left un-altered. The parameters that are changed from the default values when the controllers are initially loaded with one of the six standard controller programs are shown in the table that follows. These parameters should not ever need to be changed, however in the event that parameter adjustments are needed as directed by M-C service personnel, refer to the procedure in the Adjustments section to make program changes.

| Parameter Name | Display Name | Function Level | Program | | | | |
|------------------|--------------|----------------|----------------|----------|------------------|------------|-------------------|
| | | | Default Values | Profile | Profile (Metric) | Fuel Oil | Fuel Oil (Metric) |
| Device | inPt | 5 | nonE | tCK | | tCK | |
| Units | unit | 5 | nonE | F | C | F | C |
| Low Limit | Lo.SC | 2 | 32 | 0 | | 0 | |
| High Limit | hi.SC | 2 | caries | 240 | 116 | 240 | 116 |
| Proportional | bAnd | 1 | 18 | 75 | 24 | 10 | 6 |
| Integral | int.t | 1 | 5.0 | 1.5 | | 0.5 | |
| Derivative | der.T | 1 | 25 | 0 | | 1 | |
| Cycle Time | CYC.t | 1 | 20 | 0.1 | | 0.0 | |
| Output 1 Type | SP1.d | 5 | nonE | Analog | | Relay | |
| Output 2 Mode | SP2.A | 2 | nonE | dev Hi | | None | |
| Output 2 Option | SP2.b | 2 | nonE | Latch | | None | |
| Output 2 Setting | SEt.2 | 1 | 0 | 40 | 23 | 40 | 23 |
| Output 2 Band | bnd.2 | 1 | 3.9 | 5.0 | 2.0 | 7.0 | 4.0 |
| Output 3 Mode | SP3.A | A | nonE | dev Lo | | band | |
| Output 3 Option | SP3.b | A | nonE | Hold | | Latch Hold | |
| Output 3 Setting | SEt.3 | A | 0 | -40 | -23 | 40 | 23 |
| Address | Addr | C | 0 | varies** | | Varies** | |
| Baud Rate | bAud | C | 9600 | 19.2 | | 19.2 | |

**Note: The address number will correspond to the burner number on the machine, i.e. 1-8



Adjustments

All parameters for the temperature controller can be adjusted when it is powered up and operational. While the controller is in the main operating mode, the display will show two numbers; the top number is the actual temperature detected by the thermocouple in the plenum, whereas the bottom number shows the current temperature setpoint.

To make adjustments to the temperature setpoint, follow the procedure as follows:

1. Press * and ▼ to lower the temperature setpoint.
2. Press * and ▲ to raise the temperature setpoint.

To make parameter adjustments, follow the procedure as follows:

1. Hold down ▲ and ▼ simultaneously for 3 seconds.
2. Press ▲ or ▼ separately to page through parameters.
3. When LEVL is displayed, press * and ▼ or * and ▲ to change level.
4. Press ▲ or ▼ to page through the parameters for that level.
5. Press * and ▼ or * and ▲ to change a parameter.

To reset the controller in an alarm condition, follow the procedure as follows:

1. Make sure the condition causing either the low temperature or high temperature alarm has been rectified.
2. Momentarily press ▲ and ▼ simultaneously for 3 seconds.

To automatically tune the PID loop of the controller, follow the procedure as follows:

1. Press ▲ and ▼ simultaneously for 3 seconds.
2. Press ▼ or ▲ until TUNE is displayed.
3. Press the * and ▼ or * and ▲ until At.SP is displayed.
4. Press ▲ and ▼ simultaneously for 3 seconds.
5. You are now auto-tuning. Once TUNE disappears, auto-tuning is complete.
6. To abort auto-tune, press ▲ and ▼ simultaneously for 3 seconds.
7. Press ▼ or ▲ until the word TUNE is displayed.
8. Press the * and ▼ or * and ▲ until oFF is displayed.
9. Press ▲ and ▼ simultaneously for 3 seconds.
10. Auto-tuning is now disabled.

Alarms

The temperature controller not only controls the temperature in the plenum, but it also provide low temperature and high temperature alarms. When the plenum temperature drops below the low temperature setpoint or rises above the high temperature setpoint, an alarm condition will occur. The low and high temperature setpoint parameters are established in the program loaded on the controller as explained in the Programs section. If the low or high temperature alarms occur while the burner is lit, the controller will shutdown the dryer and a Type "C" alarm will be displayed on the Pinnacle Lite HMI touchscreen which is further explained in the Pinnacle Lite Controls Manual. Similarly, if the low or high temperature alarms occur while the burner is not lit, no action is taken, however the Pinnacle Lite HMI touchscreen will display a Type "A" alarm.

Once an alarm condition occurs, the condition causing the alarm needs to be rectified then the controller can be reset as described in the Adjustments section. Similarly, you can also reset the controller on the Pinnacle Lite HMI touchscreen as explained in the Pinnacle Lite Controls Manual. As an alternative, the controller can also be reset by re-powering. This is accomplished by momentarily pressing the corresponding air pressure light button and the high limit button (on the Remote Control Cabinet) simultaneously.

Low temperature alarms are non-latching which means that once the low temperature condition has been rectified, the controller will automatically reset itself. High temperature alarms however are non-latching and not only will the condition causing the alarm need to be rectified, but the controller will need to be reset as previously described.

Normally the plenum temperature setpoint is substantially higher than the ambient temperature before the burner in the plenum is lit. For example, if the ambient temperature is 65 deg F and the plenum temperature setpoint is 220 deg F, this would normally be considered a low temperature alarm condition, however one of the features of the controller is that it inhibits the low temperature alarm during the initial burner ramp-up in the plenum. This means that you will not receive a low temperature alarm unless the temperature has gotten within the setpoint and dropped back down below the low temperature setpoint. This is a nice feature, however please note that although this low temperature alarm is inhibited on the first time the burner is lit, a burner shutdown/cooldown with a consecutive ramp back up will cause the low temperature alarm. In order to avoid this condition, it is required to re-cycle the power to the controller which is done by momentarily pressing the corresponding air pressure light button and the high limit button (on the Remote Control Cabinet) simultaneously.



Variable Frequency Drive (VFD)










The purpose of the variable frequency drive is to control the speed of the discharge metering rolls. The communication from the HMI to the PLC then correlates to the variable frequency drive.

| <i>Drive Parameters</i> | <i>Description</i> | <i>ABB Factory Settings</i> | <i>230V /1 Φ In : 230V /3Φ Load</i> |
|-----------------------------|----------------------|-----------------------------|-------------------------------------|
| 9901 | Language | English | English |
| 9902 | Applied Macro | ABB Standard | ABB Standard |
| 9904 | Control Mode | Scalar - Freq | Scalar - Freq |
| 9905 | Nominal Voltage | 230 V | 230 V |
| 9906 | Nominal Current | 4.7 A | 2.9 A |
| 9907 | Nominal Frequency | 60 Hz | 60 Hz |
| 9908 | Nominal Speed | 1700 rpm | 1755 rpm |
| Start/Stop/Direction | | | |
| 1001 | EXT1 Commands | DI1,2 | DI1 |
| 1002 | EXT2 Commands | NOT SEL | DI1 |
| 1003 | Direction | Request | Forward |
| Reference Select | | | |
| 1102 | EXT1/EXT2 Select | EXT1 | DI2 |
| 1103 | Ref. 1 Select | AI1 | AI1 |
| 1104 | Ref. 1 MIN | 0 Hz | 5 Hz |
| 1105 | Ref. 1 MAX | 60 Hz | 60 Hz |
| 1106 | Ref. 2 Select | AI2 | Keypad (NC) |
| 1107 | Ref. 2 MIN | 0% | 0% |
| 1108 | Ref. 2 MAX | 100% | 100% |
| Constant Speeds | | | |
| 1201 | Const. Speed Select | DI3,4 | NOT SEL |
| Relay Outputs | | | |
| 1401 | Relay Output 1 | Fault(-1) | Fault (-1) |
| Analog Outputs | | | |
| 1501 | AO1 Content Sel. | Output Freq. | Ext. Ref. 1 |
| System Controls | | | |
| 1601 | Run Enable | NOT SEL | DI3 |
| Limits | | | |
| 2003 | Max Current | 8.5 A | 3.4 A |
| 2007 | Min Frequency | 0 Hz | 5 Hz |
| 2008 | Max Frequency | 60 Hz | 60 Hz |
| Start/Stop | | | |
| 2102 | Stop Function | Coast | Ramp |
| 2110 | Torque Boost Current | 100% | 200% |
| Accel/Decel | | | |
| 2202 | Accel Time 1 | 5 sec | 5 sec |
| 2203 | Decel Time 1 | 5 sec | 5 sec |
| Panel Display | | | |
| 3415 | Signal 3 Parameters | Torque | DI1-5 |

* Dipswitches must both be set to ON for SIEMENS S7-1200!

** If programmed by hand, upload to panel, then download full set to drive.

Changing Variable Frequency Drive Parameters

- Check the direction of the motor rotation.
 - If the drive is in remote control (REM shown on the left), switch to local control by pressing .
 - To go to the Main menu, press  if the bottom line shows OUTPUT; otherwise press  repeatedly until you see MENU at the bottom.
 - Press keys / until you see “rEF” and press .
 - Increase the frequency reference from zero to a small value with key .
 - Press  to start the motor.
 - Check that the actual direction of the motor is the same as indicated on the display (FWD means forward and REV reverse).
 - Press  to stop the motor.

To change the direction of the motor rotation:



- Invert the phases by changing the value of parameter **9914** to the opposite, ie from 0 (**NO**) to 1 (**YES**), or vice versa.
- Verify your work by applying input power and repeating the check as described above.

Speed Limits and Acceleration/Deceleration Times

- Set the minimum speed (parameter **2001**).
- Set the maximum speed (parameter **2002**).
- Set the acceleration time 1 (parameter **2202**).

Note: Set also acceleration time 2 (parameter **2205**) if two acceleration times will be used in the application.
- Set the deceleration time 1 (parameter **2203**).

Note: Set also deceleration time 2 (parameter **2206**) if two deceleration times will be used in the application.




Venturi Burner (LPG & NG only)

The Venturi Burner is a Mathews Company proprietary design that effectively mixes process air and fuel for safe and efficient combustion thereby delivering heat to the process air used to dry the grain. In order to ensure that the combustion process is at its peak efficiency, there are adjustments that can be made to not only adjust the air-fuel ratio (primary air), but also adjustments that change the overall shape and size of the flame (secondary air) to ensure adequate flame sensing.

The primary air adjustment controls the air-fuel mixture to provide a clean and efficient flame. The adjustment is similar to the air adjustment on a burner in a gas furnace or stove.

The secondary air adjustment controls the flame pattern. Too much secondary air will keep the flame small and confined. It will also cause the flame to be blown off of the flame sensor, interrupting the flame sensing circuit resulting in gas solenoid valve chatter, or it may keep the burner from lighting.



If the primary and secondary air adjustments have been misadjusted and it is not possible to get acceptable results, time can be saved by shutting down the burner and restoring the burner back to its original default setting. To do this, close the primary air adjustment all the way by loosening the locking bolt touching the center shaft, then turn the primary air adjuster pipe clockwise. If the primary air adjuster pipe turns hard, loosen the four bolts in the corners of the square plate and shift the plate until the air adjuster pipe turns freely. Once complete, tighten the four bolts back into place.

Close the secondary air adjustment by loosening the locknuts on the secondary air adjustment rod. Push the secondary air adjustment rod in all the way and pulling it back approximately 3/8" (9.5mm).

Primary Air

If the flame appears very yellow or orange in color, open the primary air to provide more. If the flame is light blue in color with no yellow or orange at all, then close the primary air slightly until there is just a trace amount of yellow or orange at the tips of the flame. If you are using LPG as your fuel source, allow 5-10 minutes for it to properly vaporize before changing the adjustment.

To adjust the primary air, loosen the locking bolt and turn the primary air adjuster pipe clockwise to decrease the amount of airflow and counterclockwise to increase the amount of airflow. The flame can be viewed through the window or through the view lens in the rear door as the adjustment is made. When the adjustment is finished, re-tighten the locking bolt.

Secondary Air

If the flame is unstable and fluctuates greatly, open the secondary air adjustment slightly. This condition may cause the solenoid valves to chatter. If the flame is confined in a small area and is blowing past the remote sensor and electrode, close the secondary adjustment slightly.

To adjust the secondary air, loosen the locknuts and push the secondary air adjustment rod in to decrease the amount of air. The flame can be viewed through the window as the adjustment is being made. Tighten the locknuts carefully so that the adjustment does not change.

Operational Procedures

The following operational procedures provide a step-by-step guide to starting-up and shutting-down you dryer. These procedures should be followed and used in conjunction with the Pinnacle Lite Controls Manual for HMI touchscreen adjustments.

First Time Start-Up

This start-up procedure assumes that the dryer has not recently been in operation and is not full of grain. For a repeated daily start-up, see the Daily Start-Up procedure portion of this section of the manual.

1. Adjust the high limit switch setpoint to approximately 40 deg F above the desired plenum temperature as explained in the High Limit portion of this section of the manual.. This should be done for all plenum high limit switches.
2. Set the grain fill delay timer and the grain flow timer as explained in the Grain Fill System portion of this section of the manual.
3. Turn the main disconnect located on the High Voltage Cabinet(s) to the on position.
4. On the Remote Control Cabinet, turn the momentary spring-loaded Control Power switch to the START position and release to the ON position. The Control Power light should illuminate.
 - (Applies only to Oil Fire dryer models if not applicable continue to the next step.)** Check to make sure that the fuel pump is primed and has proper pressure for operation. Normal operating pressure should be 10 – 20 psig as indicated on the gauge at the pump. Refer to pages 8 & 9 of the Riello manual.
5. On the Remote Control Cabinet, turn one of the momentary spring-loaded Fan switches to the START position and release to the ON position. The fan should start immediately and the switch should illuminate. Repeat this procedure for all of the fans, allowing time for each fan to get up to speed before starting the next.
6. On the Remote Control Cabinet, turn the Grain Fill switch to the MAN position and allow the dryer to fill completely. The level auger should start immediately, the switch should illuminate and your grain fill equipment should be commended to deliver grain to the dryer.
7. Once the dryer is full of grain, adjust each of the air pressure switches so the air pressure light illuminates as explained in the Air Pressure Switch portion of this section of the manual.
8. Set the plenum temperature setpoints for each plenum. You may refer to the table that follows for suggested drying temperatures based on model number and grain type. Setting the plenum temperature controllers can be done on the temperature controller directly located in the burner control box as explained in the Temperature Controller portion of this section of the manual or it can be done on the HMI touchscreen as explained in the Pinnacle Lite Controls Manual.

- (Applies only to Oil Fire dryer models if not applicable continue to the next step.)** Allow the fans to



run for approximately 2 minutes to allow the Riello burner control to complete an orderly shut down. When the burner reset light illuminates turn the ignition switch to the reset position momentarily to reset the burner.

- Turn the ignition switch to the on position to start the Riello burner firing sequence; this should take approximately 36 seconds. For more information see page 14 of the Riello burner manual.
- As the plenum comes up to temperature and stabilizes the temperature controller will activate and deactivate high fire based on the deviation from setpoint. Refer to page 12 of the Riello manual for more information.

Note: For a complete startup and shutdown procedure relating to the Riello burner see the appendix of this manual

9. Open all manual gas supply valves so that fuel is free to flow to the burner once the gas valves controlled by the ignition system are opened.
10. On the Remote Control Cabinet, turn the ignition switch to the ON or the LO or HI position and after a 15 second delay, the Ignition switch will be illuminated and the burner will be lit.
11. Allow the dryer to warm up and dry the initial load of grain as a batch operation or be prepared to cycle the first batch back into the wet bin so that it may be processed through the dryer again on a continuous flow basis.
12. On the Remote Control Cabinet, turn the Grain Fill switch to the AUTO position. The grain fill system will now operate automatically as outlined in the Grain Fill System portion of this section of the manual.
13. Refer to the Pinnacle Lite Controls Manual for the requirements prior to starting the dryer's discharge. At a minimum, set the discharge mode to Manual on the HMI touchscreen and set the discharge speed setpoint (%) in accordance with the table that follows.
14. On the Remote Control Cabinet, turn the momentary spring-loaded Takeaway switch to the START position and release to the ON position. The discharge auger or conveyor (if equipped) should start immediately, the switch should illuminate and your takeaway equipment should start running. On the Remote Control Cabinet, turn the Metering switch to the ON position. The metering rolls should start immediately and the switch should illuminate. The dryer is now discharging grain and the discharge rate will be established by the Pinnacle Lite Control System. Refer to the Pinnacle Lite Controls Manual for more information.

Daily Shut-Down

This shutdown procedure assumes that the dryer will be put back into operation within 24-48 hours. If the grain drying operation will not resume within 24-48 hours, it is suggested that the dryer be emptied and the grain placed back into the appropriate storage. Grain dryers are not designed to be grain storage devices. Once all the grain has been dried, it needs to be emptied from the dryer and stored appropriately. Grain stored in a dryer for more than one week may cause damage to the machine. For an end-of season shut-down procedure, see the End-of-Season Shut Down portion of this section of the manual.

1. On the Remote Control Cabinet, turn the Metering switch and the Takeaway switch to the OFF position. Both switches should no longer be illuminated, the metering rolls and discharge auger or conveyor (if equipped) as well as your takeaway equipment should be stopped.
2. On the Remote Control Cabinet, turn the Grain Fill switch to the OFF position. The grain fill system will now be shutdown and your fill equipment will no longer be commanded to run.
3. Close the manual hand valves supplying fuel to the dryer. This will ensure the burners will run until all of the fuel in the line has been cleared out. Once the burner is extinguished, turn the ignition switch to the OFF position on the Remote Control Cabinet.

Daily Start-Up

This start-up procedure assumes that the dryer has recently been in operation and is full of grain. For a first time start-up, see the Daily Start-Up procedure portion of this section of the manual.

1. Turn the main disconnect located on the High Voltage Cabinet(s) to the on position.
2. On the Remote Control Cabinet, turn the momentary spring-loaded Control Power switch to the START position and release to the ON position. The Control Power light should illuminate.
3. On the Remote Control Cabinet, turn one of the momentary spring-loaded Fan switches to the START position and release to the ON position. The fan should start immediately and the switch should illuminate. Repeat this procedure for all of the fans, allowing time for each fan to get up to speed before starting the next.
4. Verify the plenum temperature setpoints for each plenum. You may refer to the table that follows for suggested drying temperatures based on model number and grain type. Setting the plenum temperature controllers can be done on the temperature controller directly located in the burner control box as explained in the Temperature Controller portion of this section of the manual or it can be done on the HMI touchscreen as explained in the Pinnacle Lite Controls Manual.
5. Open all manual gas supply valves so that fuel is free to flow to the burner once the gas valves controlled by the ignition system are opened.
6. On the Remote Control Cabinet, turn the ignition switch to the ON or the LO or HI position and after a 15 second delay, the Ignition switch will be illuminated and the burner will be lit.
7. On the Remote Control Cabinet, turn the Grain Fill switch to the AUTO position. The grain fill system will now operate automatically as outlined in the Grain Fill System portion of this section of the manual.
8. Refer to the Pinnacle Lite Controls Manual for the requirements prior to starting the dryer's discharge. At a minimum, set the discharge mode to Manual on the HMI touchscreen and set the discharge speed setpoint (%) in accordance with the table that follows.
9. On the Remote Control Cabinet, turn the momentary spring-loaded Takeaway switch to the START position and release to the ON position. The discharge auger or conveyor (if equipped) should start immediately, the switch should illuminate and your takeaway equipment should start running. On the Remote Control Cabinet, turn the Metering switch to the ON position. The metering rolls should start immediately and the switch should illuminate. The dryer is now discharging grain and the discharge rate will be established by the Pinnacle Lite Control System. Refer to the Pinnacle Lite Controls Manual for more information.

End-of-Season Shut-Down

This shutdown procedure assumes that the dryer will not be put back into operation for an extended period of time and that all of the grain in the dryer will be dried and then subsequently emptied.

1. When the last of the grain to be dried has been put into the dryer, turn the Metering switch and the Takeaway switch to the OFF position on the Remote Control Cabinet. Both switches should no longer be illuminated, the metering rolls and discharge auger or conveyor (if equipped) as well as your takeaway equipment should be stopped.
2. Dry the remaining grain for approximately six minutes per point of moisture to be removed.
3. Close the manual hand valves supplying fuel to the dryer. This will ensure the burners will run until all of the fuel in the line has been cleared out. Once the burner is extinguished, turn the ignition switch to the OFF position on the Remote Control Cabinet.



4. Let the fans continue to run for at least 15-20 minutes to cool the grain in the dryer. Once the grain has been cooled down, shutoff the fans by turning the momentary spring-loaded Fan switches to the OFF position.
5. Set the discharge mode to Manual on the HMI touchscreen and set the discharge speed setpoint (%) as high as your takeaway system will allow.
6. On the Remote Control Cabinet, turn the momentary spring-loaded Takeaway switch to the START position and release to the ON position. The discharge auger or conveyor (if equipped) should start immediately, the switch should illuminate and your takeaway equipment should start running. On the Remote Control Cabinet, turn the Metering switch to the ON position. The metering rolls should start immediately and the switch should illuminate. The dryer is now discharging grain and the discharge rate will be established by the Pinnacle Lite Control System. Refer to the Pinnacle Lite Controls Manual for more information.
7. Allow the grain to be completely emptied from the dryer.
8. On the Remote Control Cabinet, turn the momentary spring-loaded Control Power switch to the OFF position. The Control Power light should no longer be illuminated.
9. Turn the main disconnect located on the High Voltage Cabinet(s) to the off position.
10. Refer to the Maintenance section of this manual for additional information on preparing your dryer for an extended shutdown.

Suggested Plenum Temperatures

Bellow are suggested plenum drying temperatures for a variety of grain types. These numbers represent the temperature that the burner will be putting out into the heating chamber.

| Model Number | Plenum Number | Plenum Drying Temperature | | | | | |
|--------------|---------------|---------------------------|------------|-----------------|------------|---|------------|
| | | Corn | | Sorghum & Wheat | | Canola, Rape, Sunflower Oats, Barley, Soybeans | |
| | | deg F | deg C | deg F | deg C | deg F | deg C |
| L1250-L1350 | Top #2 | 230 | 110 | 170 | 77 | 140 | 60 |
| | Bottom #1 | Cool or 180 | Cool or 82 | Cool or 150 | Cool or 66 | Cool or 130 | Cool or 54 |
| L2550-L2650 | Top #3 | 235 | 113 | 180 | 82 | 140 | 60 |
| | Mid #2 | 225 | 109 | 160 | 71 | 130 | 54 |
| | Bottom #1 | Cool or 200 | Cool or 93 | Cool or 150 | Cool or 66 | Cool or 120 | Cool or 49 |
| L2700-L3100 | Top #4 | 235 | 113 | 180 | 82 | 140 | 60 |
| | Mid #3 | 225 | 109 | 170 | 77 | 130 | 54 |
| | Mid #2 | 200 | 93 | 160 | 71 | 120 | 49 |
| | Bottom #1 | Cool or 180 | Cool or 82 | Cool or 150 | Cool or 66 | Cool or 120 | Cool or 49 |
| L3105-L4145 | Top #6 | 240 | 116 | 180 | 82 | 140 | 60 |
| | Mid #5 | 235 | 113 | 170 | 77 | 140 | 60 |
| | Mid #4 | 225 | 109 | 160 | 71 | 130 | 54 |
| | Mid #3 | 210 | 99 | 150 | 66 | 130 | 54 |
| | Mid #2 | Cool or 200 | Cool or 93 | Cool or 150 | Cool or 66 | Cool or 120 | Cool or 49 |
| | Bottom #1 | Cool or 180 | Cool or 82 | Cool or 150 | Cool or 66 | Cool or 120 | Cool or 49 |
| L5175 | Top #7 | 240 | 116 | 180 | 82 | 140 | 60 |
| | Mid #6 | 235 | 113 | 170 | 77 | 140 | 60 |
| | Mid #5 | 225 | 109 | 170 | 77 | 130 | 54 |
| | Mid #4 | 215 | 102 | 160 | 71 | 130 | 54 |
| | Mid #3 | 210 | 99 | 150 | 66 | 130 | 54 |
| | Mid #2 | Cool or 200 | Cool or 93 | Cool or 150 | Cool or 66 | Cool or 120 | Cool or 49 |
| | Bottom #1 | Cool or 180 | Cool or 82 | Cool or 150 | Cool or 66 | Cool or 120 | Cool or 49 |
| L6205 | Top #8 | 240 | 116 | 180 | 82 | 140 | 60 |
| | Mid #7 | 235 | 113 | 170 | 77 | 140 | 60 |
| | Mid #6 | 230 | 111 | 170 | 77 | 130 | 54 |
| | Mid #5 | 225 | 109 | 170 | 77 | 130 | 54 |
| | Mid #4 | 215 | 102 | 160 | 71 | 130 | 54 |
| | Mid #3 | 210 | 99 | 150 | 66 | 130 | 54 |
| | Mid #2 | Cool or 200 | Cool or 93 | Cool or 150 | Cool or 66 | Cool or 120 | Cool or 49 |
| | Bottom #1 | Cool or 180 | Cool or 82 | Cool or 150 | Cool or 66 | Cool or 120 | Cool or 49 |



Suggested Discharge Rate

Below are suggested discharge rate when drying at a variety of moisture levels. These numbers represent the speed on how fast or slow the dryer unloads the grain.

| | All Heat | | | | | | Heat + Cool | | | | | |
|---------------|------------------|-----------|-------|------------------|-----------|-------|------------------|-----------|-------|------------------|-----------|-------|
| | 20%-15% Moisture | | | 25%-15% Moisture | | | 20%-15% Moisture | | | 25%-15% Moisture | | |
| | bu/hr | tonnes/hr | speed | bu/hr | tonnes/hr | speed | bu/hr | tonnes/hr | speed | bu/hr | tonnes/hr | speed |
| L1250 | 725 | 16.9 | 69% | 500 | 11.6 | 45% | 430 | 10.0 | 37% | 280 | 6.5 | 21% |
| L1350 | 1,080 | 25.2 | 46% | 730 | 17.0 | 28% | 630 | 14.7 | 23% | 410 | 9.6 | 12% |
| L2550 | 1,690 | 39.4 | 77% | 1,040 | 24.2 | 44% | 1,010 | 23.5 | 42% | 645 | 15.0 | 24% |
| L2650 | 1,895 | 44.1 | 87% | 1,170 | 27.3 | 50% | 1,130 | 26.3 | 48% | 735 | 17.1 | 28% |
| L2700 | 2,040 | 47.5 | 95% | 1,270 | 29.6 | 56% | 1,230 | 28.7 | 54% | 800 | 18.6 | 32% |
| L3100 | 2,350 | 54.7 | 51% | 1,490 | 34.7 | 29% | 1,700 | 39.6 | 34% | 1,100 | 25.6 | 19% |
| L3105 | 3,020 | 70.3 | 68% | 1,595 | 37.2 | 32% | 1,900 | 44.3 | 39% | 1,250 | 29.1 | 23% |
| L4145 | 3,700 | 86.2 | 85% | 1,670 | 38.9 | 33% | 2,300 | 53.6 | 49% | 1,350 | 31.4 | 25% |
| L5175 | 4,200 | 97.8 | 98% | 2,080 | 48.4 | 44% | 2,925 | 68.1 | 65% | 1,750 | 40.8 | 35% |
| L6205* | 5,040 | 117.2 | 100% | 2,500 | 58.1 | 55% | 3,660 | 85.1 | 84% | 2,190 | 50.9 | 47% |

*Note: May need to run at lower plenum temperatures for low moisture removal when drying in all heat.

Maintenance

Overview

This section of the manual will explain the factory recommended maintenance and cleaning requirements to keep your Mathews Company grain dryer running efficiently. Failure to follow or comply with these recommendations will impact dryer performance and may limit or void your warranty.

Pre-Season Checks

The following pre-season checks are intended to prepare your dryer for operation and bring any issues that may be present to your attention. Performing these check no later than 1-2 months before you intend to use the machine is recommended so that proper service can be performed and/or replacement parts can be ready before the harvest season begins.

Grain Fill & Discharge System

The following procedure will guide you through the grain fill and discharge system pre-season check. If the results of any of the following procedures are not consistent with what you should observe, service and/or replacement parts may be required. Contact your dealer or refer to the Troubleshooting section of this manual for more information.

1. Place all of the switches on the Remote Control Cabinet to the OFF position. Turn all of the circuit breakers in the bottom cabinet on. Turn the electric power supply to the dryer on.
2. On the Remote Control Cabinet, turn the momentary spring-loaded Control Power switch to the START position and release to the ON position. The Control Power light should illuminate.
3. On the Remote Control Cabinet, turn the Grain Fill switch to the MAN position. The level auger should start immediately and the switch should illuminate.
4. On the Remote Control Cabinet, turn the momentary spring-loaded Takeaway switch to the START position and release to the ON position. The discharge auger or conveyor (if equipped) should start immediately and the switch should illuminate.
5. On the Remote Control Cabinet, turn the Metering switch to the ON position. The metering rolls should start immediately and the switch should illuminate.

Belt Adjustment

All belts will eventually seat themselves in the pulley grooves and the tension may have to be re-adjusted. If the belts squeal when the motor starts, they are not tight enough. Never apply belt dressing as this will damage the belt and cause early belt failure.

Discharge Auger Belt

To adjust the belt tension on the discharge auger, loosen the unload auger motor mounting locknuts. Turn the locknut on the J-bolt to adjust the tension.

Level Auger Belt

Adjust the belt tension for the level auger by loosening the locknuts and raising the motor mount plate evenly with the four adjusting nuts, and then tighten the locknuts.



Fans & Burners

The following procedure will guide you through the fan and burner system pre-season check. Perform this procedure for all fans and burners installed on the machine. If the results of any of the following procedures are not consistent with what you should observe, service and/or replacement parts may be required. Contact your dealer or refer to the Troubleshooting section of this manual for more information.

1. Turn all switches on the Remote Control Cabinet to the off position and turn the electric power supply to the dryer off.
2. Close the burner gas manifold hand valve for each burner (handle 90° relative to the piping).
3. In order to test the burners without grain in the dryer, the air pressure switch will need to be jumpered. To do this, place a jumper wire with an alligator clip between the terminal of the fan start switch and the air pressure light terminal with the yellow wire of the burner being tested. Both the switch and light are located on the inside of the Remote Cabinet door.



This is only a temporary procedure for checking the burner. Under normal operation, never operate the dryer with the air pressure switches disconnected or bypassed. This safety air pressure switch is for your protection and the protection of the dryer.

4. Open all manual gas supply valves so that fuel is free to flow to the burner once the gas valves controlled by the ignition system are opened.
5. Turn the electric power supply to the dryer on.
6. On the Remote Control Cabinet, turn the momentary spring-loaded Control Power switch to the START position and release to the ON position. The Control Power light should illuminate.
7. On the Remote Control Cabinet, turn the momentary spring-loaded Fan switch to the START position and release to the ON position. The fan should start immediately, the switch should illuminate, and the air pressure light should illuminate.
8. Open the manual gas valve 1/4 of the way open to control the fuel flow to the burner once it has been lit.
9. Turn the ignition switch to the LO position and after a 15 second delay, the Ignition switch will be illuminated and the burner will be lit.
10. Let the burner run for at least two minutes to verify that it is properly operating.



Lubrication

Maintaining proper lubrication of all moving components of your dryer is key to its efficient and safe operation. The following table below outlines all recommended lubrication. Note that some of the items may not be applicable based on configured options, model or accessories.

| Item | Lubrication Required | Interval |
|-----------------------------|---|--|
| 50:1 Gearbox Oil Level | Fill 1/4" over gear with SAE 90 gear lubricant | Maintain proper level. Check every 100 hours |
| 50:1 Gearbox Grease Fitting | Uses (5) strokes of gun grease | At the beginning and end of the season. |
| Universal Joints | Use (1) strokes of gun grease | Every 50 hours of operation. |
| Motors | Lubricate with SR-2 (Chevron) grease or equivalent | Prior to operation and at the end of the season. |
| Motor Bearings | Use Exxon Corp-Plyres-em producto or Chevron, Inc-SRI#2. Grease should be lithium based. | At the beginning and the end of the season. |
| Centrifugal Fan Bearings | Use only #2 consistency lithium based grease with high quality mineral oil with rust and oxidation inhibitor. Use Shell Alvania #2 Mobil Mobilux #2 or Texaco Multifak #2 | At the beginning of the season and every 100 hours until the end of the season. |
| Unload Auger Bearings | SHell Avania #2, Mobil Mobilux #2 or Texaco Multifak #2 | Grease every 100 hours, unless extremely dirty conditions, once daily / weekly. |
| Metering Roll Bearings | Use grade #2 mineral oil lithium or lithium complex base grease. | At the beginning and the end of the season. Internal bearings are brass and do not need lubrication. |

Seasonal Cleaning

During the course of the drying season, it is important to keep the dryer operating at its peak efficiency by performing periodic maintenance and cleaning of the equipment. When the screens of a dryer are clean, the air moves freely through the grain walls. As debris builds up inside the dryer, this can result in the combustion of debris which may lead to a fire. As such, cleaning of the grain dryer should be performed on a daily basis. Try to keep the surroundings of the dryer clean at all times to prevent breeding grounds for insects and other pests.



The recommended method for cleaning the dryer is air or water, preferably from a compressed-air source or even a vacuum, however, using a non-metallic brush or broom also works. Be aware that if using water to clean the dryer, the combination of water and residue can form a paste, making the surfaces sticky and more difficult to remove.

Outer Screens

The outer screens of the dryer need to be kept as clean as possible for safety and performance reasons. The perforation of the screens allow heated air, saturated with moisture from the grain, to exit to the atmosphere. This process also creates a damp environment on the outside of the screens, creating a buildup of fines and dust which reduces air flow resulting in a decrease of capacity and higher cost of drying.

Cleaning of the outer screens can be done during the drying process, but it may temporarily affect the discharge capacity if water is used. The preferred way to clean is to brush down the screens while grain is being dried as this will help push material out of the perforations in the screens. The discharge rate should increase after cleaning of the dryer because more surface area is now being exposed to the heated air passing through the grain columns.

Inner Screens

The procedure for cleaning the inner screens is similar to that of cleaning the outer screens. When cleaning the inside of the dryer, the use of a protective breathing mask is recommended. Using a non-metallic brush or broom, sweep the inner screens and channel rings going from top to bottom. Check the burner to make sure the wires look good and the burner is clean of debris. Sweep the plenum floors and remove any debris.

Post-Season Maintenance

After the drying season, the following steps are recommended to put your dryer into a condition suitable for an extended period of non-operational time.

1. Disconnect all power and turn off the gas supply.
2. Perform one final cleaning of the dryer inside and out as previously explained in the Seasonal Cleaning section of the manual. Use a power washer on the outer screens if dirt has filled the perforations on the screens.
3. Open the plenum access doors and sweep out all foreign material.
4. Visually inspect all bearings to see if there is indication of one in need of replacement. Inspect the drive belts and chains and note if any are in need of replacement or lubrication.
5. Grease all fan motor bearings and fan bearings as recommended in the Lubrication section of the manual.
6. Use a vacuum cleaner to remove any dirt from the control cabinet.



Troubleshooting

The Troubleshooting section will help with diagnosing your dryer in case of a dryer shut down. This section will explain situations that you may run into and will help you come up with a resolution to get your dryer back to operation.

Diagnosing a Dryer Shutdown

The safety of your dryer is in the hands of the safety circuit. These are a series of components that are tied together. If one fails the system will shutdown insuring the safety of your grain dryer.

Safety Circuit Overview

The contacts for incoming hot and neutral are found in the High Voltage cabinet.

The 120 volt input power to the dryer circuit for dryer controls comes from the bottom side of the transformer and runs to the top of the 8 amp mini-breaker. This breaker should be turned off and the voltage should be checked before turning the mini-breaker on. If the voltage reads anything outside of 125-volts, the supply voltage needs to be checked before powering on the mini-breaker.

Next to the mini breaker is a neutral block, which feeds all neutrals throughout the entire dryer. This neutral is connected to the neutral from the secondary side of the transformer that is standard equipment.

The incoming neutral line is connected to **TB5** (white wire) and the hot line is on **TB33** (after circuit breaker). The incoming 120-volt supply is an 8 amp mini-breaker.

Using a volt meter, hook one lead to **TB5** and set the meter to AC voltage (sign wave or “V”)

- Start by opening the Remote Cabinet and place a jumper wire between **TB33** and **TB34**. This will bypass the door switch on the Remote Cabinet and help with the process of diagnosing the problem. This is just a temporary jumper wire and should be removed once problem is resolved.
- In the Remote Cabinet place the second lead on **TB33**. If 110 or 120-volts show on the meter, then the mini-breaker is good if no voltage appears on the meter, then the mini breaker is tripped or off.
- In the Remote Cabinet place the second lead on **TB53**. Turn the power switch to the **ON** position. If it shows 120-volts, then move to the next step. If no voltage is read on the meter, then there is a problem with the power on or the safety interlock switch on the remote cabinet door.
- In the High Voltage Cabinet place the second lead on **TB53**. Turn the power switch to the **ON** position. If it shows 120-volts, then move to the next step. If no voltage is read on the meter, then there is a problem with the power on or the safety interlock switch on the remote cabinet door.
- In the High Voltage Cabinet place second lead on **TB19**, if it shows 120-volts, move to the next step. If there is no voltage on the meter, reset all manual motor protectors as the AC drive unit may have went into fault. To reset the AC drive, turn off the mini breaker for the drive. Wait until the AC drive unit screen goes blank. Restore the mini-breaker to the ON position and the drive will restart automatically.
- In the High Voltage Cabinet place the second lead on **TBC5**, if it shows 120-volts then move onto the next step. If there is no voltage on the meter, then the jumper from C5 to C6 has become disconnected. If the end-user has pulled the jumper and installed take away and fill equipment into the safety circuit,




check to see if the customer's remote starter equipment needs to be reset.

- In the High Voltage Cabinet place the second lead on **TBC6**, if it shows 120-volts then move onto the next step. If there is no voltage on the meter, then the jumper from C5 to C6 has become disconnected. If the end-user has pulled the jumper and installed take away and fill equipment into the safety circuit, check to see if the customer's remote starter equipment needs to be reset.
- In the High Voltage Cabinet place the second lead on **TB22**, if it shows 120-volts then move onto the next step. If there is no voltage on the meter, then check connection between **TBC6** and **TB22**.
- In the High Voltage Cabinet place the second lead on **TB25**, if it shows 120-volts, move onto the next step. If there is no voltage on the meter, then the whisker switch on the dump door has tripped. Check the customer's takeaway system.
- In the High Voltage Cabinet place the second lead on **TB257(if equipped with plenum door switch(es))**, if it shows 120-volts then move onto the next step. If there is no voltage on the meter, then one of the plenum door switches is open. Check to see if the plenum doors are tightly shut or if the switch is mis-adjusted.
- Place the second lead on **TB20**, if it shows 120-volts, move onto the next step. If there is no voltage on the meter, then the first high limit has tripped it must be manually reset on the high limit itself.
- Continue to check the other high limits by following the process above and check TB28 (Burner #2) TB283 (Burner #3) TB248 (Burner #4) TB285 (Burner #5) TB286 (Burner #6) TB287 (Burner #7).
- In the High Voltage Cabinet place the second lead on **TB10**, if it shows 120-volts, move onto the next step. If there is no voltage on the meter, check the connection between **TB20** and TB10.
- In the High Voltage Cabinet place the second lead on **TB23**, if it shows 120-volts move onto the next step. If there is no voltage on the meter, then the linear limits if equipped have overheated and must be checked. When linear limits overheat (218°F), they will automatically reset when the temperature drops below 218°F. If they do not reset, they will need to be replaced. These can be checked by powering off and running continuity test through each linear limit module.
- In the High Voltage Cabinet place the second lead on **TB24**; if it shows 120-volts, the safety circuit is completed. If there is no voltage on the meter, then there is a problem with the main relay, 0-60 minute timer, or the relay/timer board. There is a DC rectifier on the side of the board if this goes bad then the board has seen a spike in voltage and needs to be replaced.
- **TB24** is the main supply distribution point that will feed voltage to the fill circuit, fan/burner circuit, and discharge circuit. These three circuits are all independently powered up.

Safety Circuit Schematic

The safety circuit below will help you diagnose a dryer shut down. This is used to help diagnose the main components on your Mathews Company grain dryer that are linked in a series to insure safety.



REV: 12-23-2014 PER: K. VEUGELER



Customer Interface

Customer connections are for remote equipment, and are used to interface the grain dryer with your fill and takeaway equipment. The grain dryer does not supply power for these interfaces. An auxiliary power source should be used to power your equipment.

Customer Connections

- **C1-C2** = remote fill equipment
- **C3-C4** = remote discharge equipment
- **C5-C6** = dryer safety circuits for remote starters

C1-C2. **C1** and **C2** are a dry set of contacts that close when the dryer fill cycle begins. When this closes, the dryer will start the customer's equipment.

C3-C4 **C3** and **C4** are a dry set of contacts that close when the dryer discharge system begins. When this closes, the dryer will start the customer's equipment.

C5-C6 is part of the dryer safety circuit and carries 120 volts as long as the dryer power switch is in the ON position. The dryer is delivered with a jumper across **C5** and **C6** to allow complete testing of the safety circuit. The jumper can be removed and the two wires that run from **C5** and **C6** can be connected to external motor starter overloads that will be engaged when the dryer is running. Remember that the dryer is providing power from **C5** to **C6** and must be tied to a dry set of contacts on the customers equipment.

Temperature Controller

If in case you run into a problem with the temperature controller this section will help diagnose the situation.

Always Overshoots the Setpoint Temperature

If the temperature is consistently overshooting the set point and tripping the alarm on the controller, adjustments to the controller are necessary.

- Press the up and down arrows 3 second till tune is displayed.
- Press the up arrow once till bAnd is displayed.
- Increasing the proportional band will help with overshoot.
- Hit the up arrow 3 more times until dAC is displayed. The derivative approach control works in conjunction with the proportional band to control overshoot.
- It must also be noted that increasing the dAC will additionally help with overshoot.



The three components for controlling overshoot are gas pressure, proportional band, and derivative approach control.

Unable to Reach Setpoint Temperature

If the setpoint cannot be achieved, even when the valve is 100% open, there is not enough gas pressure to obtain the selected plenum temperature. Adjust the pressure to obtain proper temperature. The controller will start to control the opening of the valve. The closer to the set point, the more the controller will shut the valve until the desired temperature is reached.

Plenum Temperature Will Not Hold Satisfactorily

- Adjust the gas pressure (Lower for Overshoot : Higher for Low Temp).
- Loosen the linkage on the arm connecting the modutrol motor and the proportional valve.
- Then attempt to move the shaft on the butterfly valve to see if the valve is in working order.
- Attempt to tune at the set point.



Plenum Temperature must be close to the setpoint to start this function

- Press both arrow keys simultaneously and hold down for 3 seconds. Display will show tune off.
- Press ▲ arrow up until display reads bAnd-[number]
- Press * and arrow until number is twenty (20).
- Press down arrow until display reads tune off. Press * and up arrow until display shows *tune –At.SP.*
- Hold down both arrows for three seconds for the auto tuning function.



If in danger of becoming “lost in program mode,” press the ▼ and ▲ together for 3 seconds to return to display mode, check the adjustments above and try again.

When in program mode, after 60 seconds of key inactivity, the display will revert to either inPt: none or, if the initial configuration has been completed, the measured value. Any setting already completed will be retained. To inhibit automatic program exit select ProG StAY in level 4.

Controller Fault Codes

(-AL-) This indicates that both the high and low plenum temperature conditions shutdown the dryer. You can reset the controller by either holding the High Limit, and Air Pressure button in the Remote cabinet. You can also do this directly on the Temperature controller by holding the two outside buttons.

(iNPT- FAiL) If these two words will flash back and forth. This condition is an invalid plenum chamber temperature signal back to the Temperature Controller. Check the temperature input device wires to Temperature Controller. This could also mean that that the Plenum RTD has gone bad and needs to be replaced.

(dAtA - FAiL) If these two words will flash back and forth. This condition is failure of an internal component on the controller. The Temperature Controller needs to be replaced.

(tunE - FAiL) These two words will flash back and forth. The Temperature Controller could not complete the auto tune process. This will occur when trying to auto tune. Something happened in the process to make the auto tuning process become corrupt. Restart the auto tuning process again to establish a good set of PID values to properly control temperature.



Variable Frequency Drive (VFD)

In case that you run into a error code on the variable frequency drive (VFD) listed below are the display faults that will show up on the main display of the drive.

Fault Code Description

Described below is the fault code and a description of the fault. This will also give you an action to help resolve the issue.

| CODE | FAULT | CAUSE | WHAT TO DO |
|------|-----------------------|--|---|
| 0001 | OVERCURRENT (2310) | Output current has exceeded trip level. | |
| | | Sudden load change or stall. | Check motor load and mechanics. |
| | | Insufficient acceleration time. | Check acceleration time (2202 and 2205). Check the possibility of using vector control. |
| | | Incorrect motor data. | Check that motor data (Group 99) is equal to motor rating plate values. If using vector control, perform ID run (9910). |
| | | Motor and/or drive is too small for the application. | Check sizing. |
| | | Damaged motor cables, damaged motor or wrong motor connection (star/delta). | Check motor, motor cable and connections (including phasing). |
| | | Internal fault of the drive. Drive gives an overcurrent fault after start command even when the motor is not connected (use scalar control in this trial). | Replace the drive. |
| 0002 | DC OVERVOLT (3210) | Excessive intermediate circuit DC voltage. DC overvoltage trip limit is 420 V for 200 V drives and 840 V for 400 V drives. | |
| | | Supply voltage is too high or noisy. Static or transient overvoltage in the input power supply. | Check input voltage level and check power line for static or transient overvoltage |
| | | If the drive is used in a floating network, DC overvoltage fault may appear | In a floating network, remove the EMC screw from the drive. |

| CODE | FAULT | CAUSE | WHAT TO DO |
|------|---------------------|--|--|
| | | <p>If the overvoltage fault appears during deceleration, possible causes are:</p> <ul style="list-style-type: none"> • Overvoltage controller disabled. • Deceleration time is too short. • Faulty or undersized braking chopper. | <ul style="list-style-type: none"> • Check that overvoltage controller is on (parameter 2005 OVERVOLT CTRL). • Check deceleration time (2203, 2206). • Check brake chopper and resistor (if used). DC overvoltage control must be deactivated when brake chopper and resistor is used (parameter 2005 OVERVOLT CTRL). Retrofit drive with brake chopper and brake resistor. |
| 0003 | DEV OVERTEMP (4210) | Drive IGBT temperature is excessive. The fault trip limit depends on the drive type and size. | |
| | | Ambient temperature is too high. | Check ambient conditions. |
| | | Airflow though the inverter is not free. | Check air flow and free space above and below the drive. |
| | | Fan is not working properly | Check fan operation. |
| | | Overloading of the drive. | 50% overload is allowed for one minute in ten minutes. If higher switching frequency (parameter 2606) is used. |
| 0004 | SHORT CIRC (2340) | Short-circuit in motor cable(s) or motor. | |
| | | Damaged motor or motor cable. | Check motor and cable insulation. Check motor winding |
| | | Internal fault of the drive. Drive gives an overcurrent fault after start command even when the motor is not connected (use scalar control in this trial). | Replace the drive. |
| 0006 | DC UNDERVOLT (3220) | Intermediate circuit DC voltage is not sufficient. | Check input power supply and fuses. |
| | | Undervoltage controller disabled. | Check that undervoltage controller is on (parameter 2006 UNDERVOLT CTRL). |



| CODE | FAULT | CAUSE | WHAT TO DO |
|------|--|---|---|
| | | Missing input power line phase. | Measure the input and DC voltage during start, stop and running by using a multimeter or check parameter <i>0107 DC BUS VOLTAGE</i> . |
| | | Blown fuse | Check the condition of input fuses. |
| | | Rectifier bridge internal fault. | Replace the drive. |
| 0007 | AI1 LOSS (8110) (programmable fault function <i>3001, 3021</i>) | Analog input AI1 signal has fallen below limit defined by parameter <i>3021 AI1 FAULT LIMIT</i> . | |
| | | Analog input signal is weak or does not exist. | Check the source and wire connections of the analog input. |
| | | Analog input signal is lower than fault limit. | Check parameters <i>3001 AI<MIN FUNCTION</i> and <i>3021 AI1 FAULT LIMIT</i> . |
| 0008 | AI2 LOSS (8110) (programmable fault function <i>3001, 3022</i>) | Analog input AI2 signal has fallen below limit defined by parameter <i>3022 AI2 FAULT LIMIT</i> . | . |
| | | Analog input signal is weak or does not exist. | Check the source and wire connections of analog input. |
| | | Analog input signal is lower than fault limit. | Check parameters <i>3001 AI<MIN FUNCTION</i> and <i>3021 AI1 FAULT LIMIT</i> . |

| CODE | FAULT | CAUSE | WHAT TO DO |
|------|--|---|---|
| 0009 | MOT OVERTEMP (4310) (programmable fault function 3005...3009 / 3504) | Motor temperature estimation is too high. | |
| | | Excessive load or insufficient motor power | Check motor ratings, load and cooling. |
| | | Incorrect start-up data. | Check start-up data. Check fault function parameters 3005...3009 . Minimize IR compensation to avoid heating (parameter 2603 IR COMP VOLT). Check frequency of the motor (low running frequency of motor with high input current can cause this fault). Let the motor cool down. The necessary cooling time period depends on the value of parameter 3006 MOT THERM TIME . Motor temperature estimation is counted down only when the drive is powered on. |
| | | Measured motor temperature has exceeded the fault limit set by parameter 3504 FAULT LIMIT . | Check value of fault limit. Check that actual number of sensors corresponds to value set by parameter 3501 SENSOR TYPE . Let the motor cool down. Ensure proper motor cooling: Check the cooling fan, clean cooling surfaces, etc. |
| 0010 | PANEL LOSS (5300) (programmable fault function 3002) | Control panel selected as active control location for drive has ceased communicating. | Check panel connection. Check fault function parameters. Check parameter 3002 PANEL COMM ERR . Check control panel connector. Refit control panel in mounting platform. If the drive is in external control mode (REM) and is set to accept start/stop, direction commands or references through control panel: Check group 10 START/STOP/DIR and 11 REFERENCE SELECT settings. |
| 0011 | ID RUN FAIL (FF84) | Motor ID run is not completed successfully. | Check motor connection. Check start-up data (group 99 START-UP DATA). Check maximum speed (parameter 2002). It should be at least 80% of motor nominal speed (parameter 9908). |



| CODE | FAULT | CAUSE | WHAT TO DO |
|------|---|--|--|
| 0012 | MOTOR STALL (7121) (programmable fault function 3010...3012) | Motor is operating in stall region due to eg excessive load or insufficient motor power. | Check motor load and drive ratings. Check fault function parameters 3010...3012 . |
| 0014 | EXT FAULT 1 (9000) (programmable fault function 3003) | External fault 1 | Check external devices for faults. Check parameter 3003 EXTERNAL FAULT 1 setting. |
| 0015 | EXT FAULT 2 (9001) (programmable fault function 3004) | External fault 2 | Check external devices for faults. Check parameter 3004 EXTERNAL FAULT 2 setting. |
| 0016 | EARTH FAULT (2330) (programmable fault function 3017) | Drive has detected earth (ground) fault in motor or motor cable. | Check motor. Check motor cable. Motor cable length must not exceed maximum specifications. Note: Disabling earth fault (ground fault) may damage drive. |
| | | Drive internal fault. | Internal short-circuit may cause earth fault indication. This has happened if fault 0001 appears after disabling the earth fault. Replace the drive. |
| 0017 | UNDERLOAD (FF6A) (programmable fault function 3013...3015) | Motor load is too low due to eg release mechanism in driven equipment. | Check for problem in driven equipment. Check fault function parameters 3010...3012 . Check motor power against drive power. |
| 0018 | THERM FAIL (5210) | Temperature of the drive exceeds the operating level of the thermistor. | Check that the ambient temperature is not too low. |
| | | Drive internal fault. Thermistor used for drive internal temperature measurement is open or short-circuited | Replace the drive. |
| 0021 | CURR MEAS (2211) | Drive internal fault. Current measurement is out of range. | Replace the drive. |

| CODE | FAULT | CAUSE | WHAT TO DO |
|------|--|--|---|
| 0022 | SUPPLY PHASE (3130) (programmable fault function 3016) | Intermediate circuit DC voltage is oscillating due to missing input power line phase or blown fuse. | Check input power line fuses and installation. Check for input power supply imbalance. Check the load. |
| | | Trip occurs when DC voltage ripple exceeds 14% of nominal DC voltage. | Check fault function parameter 2619 DC STABILIZER . |
| 0023 | ENCODER ERR (7301) 5003) | Communication fault between pulse encoder and pulse encoder interface module or between module and drive. | Check pulse encoder and its wiring, pulse encoder interface module and its wiring and parameter group 50 ENCODER settings. |
| 0024 | OVERSPEED (7310) 0306 bit 7 | Motor is turning faster than 120% of the highest allowed speed due to incorrectly set minimum/maximum speed, insufficient braking torque or changes in load when using torque reference. Operating range limits are set by parameters 2001 MINIMUM SPEED and 2002 MAXIMUM SPEED (in vector control) or 2007 MINIMUM FREQ and 2008 MAXIMUM FREQ (in scalar control). | Check minimum/maximum frequency settings (parameters 2001 MINIMUM SPEED and 2002 MAXIMUM SPEED). Check adequacy of motor braking torque. Check applicability of torque control. Check need for brake chopper and resistor(s). |
| 0027 | CONFIG FILE (630F) | Internal configuration file error | Replace the drive. |
| 0028 | SERIAL 1 ERR (7510) (programmable fault function 3018 , 3019) | Fieldbus communication break | Check status of fieldbus communication. Check fault function parameter 3018 COMM FAULT FUNC and 3019 COMM FAULT TIME settings. Check connections and/or noise on the line. Check if master can communicate. |
| 0029 | EFB CON FILE (6306) | Configuration file reading error | Error in reading the configuration files of the embedded fieldbus. See fieldbus user's manual. |



| CODE | FAULT | CAUSE | WHAT TO DO |
|------|--|---|--|
| 0030 | FORCE TRIP (FF90) | Trip command received from fieldbus | Fault trip was caused by fieldbus. See fieldbus user's manual. |
| 0034 | MOTOR PHASE (FF56) | Motor circuit fault due to missing motor phase or motor thermistor relay (used in motor temperature measurement) fault. | Check motor and motor cable. Check motor thermistor relay (if used). |
| 0035 | OUTP WIRING (FF95) (programmable fault function 3023) | Incorrect input power and motor cable connection (ie input power cable is connected to drive motor connection). | Possible power wiring error detected. Check that input power connections are not connected to drive output. Fault can be declared if input power is delta grounded system and motor cable capacitance is large. This fault can be disabled by parameter 3023 WIRING FAULT . |
| 0036 | INCOMPATIBLE SW (630F) | Loaded software is not compatible. | Loaded software is not compatible with the drive. Contact your local ABB representative. |
| 0037 | CB OVERTEMP (4110) | Drive control board overheated. Fault trip limit is 95 °C. | Check for excessive ambient temperature. Check for fan failure. Check for obstructions in air flow. Check the dimensioning and cooling of cabinet. |
| 0044 | SAFE TORQUE OFF (FFA0) | STO (Safe torque off) requested and it functions correctly. Parameter 3025 STO OPERATION is set to react with fault. | If this was not expected reaction to safety circuit interruption, check cabling of safety circuit connected to STO terminals X1C. If different reaction is required, change value of parameter 3025 STO OPERATION . Reset fault before starting. |
| 0045 | STO1 LOST (FFA1) | STO (Safe torque off) input channel 1 has not de-energized, but channel 2 has. Opening contacts on channel 1 might have been damaged or there is a short-circuit. | Check STO circuit cabling and opening of contacts in STO circuit. |
| 0046 | STO2 LOST (FFA2) | STO (Safe torque off) input channel 2 has not de-energized, but channel 1 has. Opening contacts on channel 2 might have been damaged or there is a short-circuit. | Check STO circuit cabling and opening of contacts in STO circuit. |

| CODE | FAULT | CAUSE | WHAT TO DO |
|------|------------------------------|---|---|
| 0101 | SERF CORRUPT (FF55) | Drive internal error. | Replace the drive. |
| 0103 | SERF MACRO (FF55) | | |
| 0201 | DSP T1 OVERLOAD (6100) | Drive internal error. | If fieldbus is in use, check the communication, settings and contacts. Write down fault code and contact your local ABB representative. |
| 0202 | DSP T2 OVERLOAD (6100) | | |
| 0203 | DSP T3 OVERLOAD (6100) | | |
| 0204 | DSP STACK ERROR (6100) | | |
| 0206 | CB ID ERROR (5000) | Drive internal error. | Replace the drive. |
| 1000 | PAR HZRPM (6320) | Incorrect speed/frequency limit parameter setting | <p>Check parameter settings. Check that following applies:</p> <ul style="list-style-type: none"> • <i>2001 MINIMUM SPEED < 2002 MAXIMUM SPEED</i> • <i>2007 MINIMUM FREQ < 2008 MAXIMUM FREQ</i> • <i>2001 MINIMUM SPEED / 9908 MOTOR NOM SPEED, 2002 MAXIMUM SPEED / 9908 MOTOR NOM SPEED, 2007 MINIMUM FREQ / 9907 MOTOR NOM FREQ and 2008 MAXIMUM FREQ / 9907 MOTOR NOM FREQ</i> are within range. |
| 1003 | PAR AI SCALE (6320) | Incorrect analog input AI signal scaling | <p>Check parameter group <i>13 ANALOG INPUTS</i> settings. Check that following applies:</p> <ul style="list-style-type: none"> • <i>1301 MINIMUM AI1 < 1302 MAXIMUM AI1</i> • <i>1304 MINIMUM AI2 < 1305 MAXIMUM AI2.</i> |



| CODE | FAULT | CAUSE | WHAT TO DO |
|------|--|---|---|
| 1004 | PAR AO SCALE (6320) | Incorrect analog output AO signal scaling | Check parameter group 15 ANALOG OUTPUTS settings. Check that following applies: <ul style="list-style-type: none"> • 1504 MINIMUM AO1 < 1505 MAXIMUM AO1. |
| 1005 | PAR PCU 2 (6320) | Incorrect motor nominal power setting | Check parameter 9909 MOTOR NOM POWER setting. Following must apply: <ul style="list-style-type: none"> • $1.1 < (9906 \text{ MOTOR NOM CURR} \cdot 9905 \text{ MOTOR NOM VOLT} \cdot 1.73 / P_N) < 3.0$ Where $P_N = 1000 \cdot 9909 \text{ MOTOR NOM POWER}$ (if units are in kW) or $P_N = 746 \cdot 9909 \text{ MOTOR NOM POWER}$ (if units are in hp). |
| 1006 | PAR EXT RO (6320) (programmable fault function 3027) | Incorrect relay output extension parameters | Check parameter settings. Check that following applies: <ul style="list-style-type: none"> • Output relay module MREL-01 is connected to drive. See parameter 0181 EXT MODULE STATUS. • 1402 RELAY OUTPUT 2, 1403 RELAY OUTPUT 3 and 1410 RELAY OUTPUT 4 have non-zero values. See <i>MREL-01 output relay module user's manual</i> (3AUA0000035974 [English]). |
| 1007 | PAR FBUSMISS (6320) | Fieldbus control has not been activated. | Check fieldbus parameter settings. |
| 1009 | PAR PCU 1 (6320) | Incorrect motor nominal speed/frequency setting | Check parameter settings. Following must apply for induction motor: <ul style="list-style-type: none"> • $1 < (60 \cdot 9907 \text{ MOTOR NOM FREQ} / 9908 \text{ MOTOR NOM SPEED}) < 16$ • $0.8 < 9908 \text{ MOTOR NOM SPEED} / (120 \cdot 9907 \text{ MOTOR NOM FREQ} / \text{Motor poles}) < 0.992$ Following must apply for permanent magnet synchronous motor: <ul style="list-style-type: none"> • $9908 \text{ MOTOR NOM SPEED} / (120 \cdot 9907 \text{ MOTOR NOM FREQ} / \text{Motor poles}) = 1.0$ |
| 1015 | PAR USER U/F (6320) | Incorrect voltage to frequency (U/f) ratio voltage setting. | Check parameter 2610 USER DEFINED U1 ... 2617 USER DEFINED F4 settings. |

| CODE | FAULT | CAUSE | WHAT TO DO |
|------|--------------------|--|--|
| 1017 | PAR SETUP 1 (6320) | Only two of the following can be used simultaneously: MTAC-01 pulse encoder interface module, frequency input signal or frequency output signal. | Disable frequency output, frequency input or encoder: <ul style="list-style-type: none"> • change transistor output to digital mode (value of parameter <i>1804 TO MODE</i> = 0 [<i>DIGITAL</i>]), or • change frequency input selection to other value in parameter groups <i>11 REFERENCE SELECT</i>, <i>40 PROCESS PID SET 1</i>, <i>41 PROCESS PID SET 2</i> and <i>42 EXT / TRIM PID</i>, or • disable (parameter <i>5002 ENCODER ENABLE</i>) and remove MTAC-01 pulse encoder interface module. |



Fuel Oil Burner Faults

Below is a fault table that will help with the diagnostics of a fuel oil burner. These codes will pop up on the display of the burner.

| Symbol | Fault | Probable Cause | Solution |
|--------|--|--|--|
| ◀ | The Burner Does Not Start | A limit or safety control device is open Control box lock-out Oil pressure switch tripped Motor protection tripped No electrical power supply Flame safeguard fuse blown Contact II of servomotor does not operate flame safeguard terminals 11 - 8 Pump is jammed Defective motor command control device Defective flame safeguard Defective electrical motor | Adjust or Replace Reset Control Box Adjust Pressure Switch or Eliminate Pressure Reset Thermal Cut-Out Close All Switches - Check Connections Replace Adjust Cam II or replace servomotor Replace Replace Replace Replace |
| | The Burner Does Not Start and A Function Lock-Out Occurs | Flame Simulation Photocell Short - Circuit Missing phase thermal cut-out trips | Replace control box Replace photocell Reset thermal cut-out when third phase is re-connected |
| ▲ | The burner starts but stops at maximum air damper setting | Contact I of servomotor does not operate, flame safeguard terminals 9-8 | Adjust cam I or replace servomotor |
| ■ | The burner starts and then goes into lock-out | Fault in flame detection circuit | Replace flame safeguard |
| ▼ | The burner remains in pre-purging phase | Contact III of servomotor does not operate flame safeguard terminals 10 - 8 | Adjust cam III or replace servomotor |
| 1 | After pre-purge and the safety time, the burner goes to lock-out and the flame does not appear | No fuel in tank; water on tank bottom Inappropriate head and air damper adjustments Light oil solenoid valves fail to open Nozzle clogged, dirty, or deformed Dirty or poorly adjusted firing electrodes Grounded electrode due to broken insulation High voltage cable defective or grounded High voltage cable deformed by high temperature Ignition transformer defective Poor electrical connections of valves or transformer Defective flame safeguard Pump unprimed Pump/motor coupling broken Pump suction line connected to return line Valves up-line from pump closed filters dirty: line - pump - nozzle Incorrect motor rotation direction | Top up fuel level or suck up water Adjust Check connections; replace coil Replace Adjust or clean Replace Replace Replace and protect Replace Check Replace Prime pump Replace Correct connection Open Clean Change motor electrical connections |
| | The flame ignites normally but the burner locks out when the safety time has elapsed | Defective photocell or flame safeguard Dirty photo-cell | Replace photocell or flame safeguard Clean |
| | Firing with pulsations or flame detachment, (lift off) delayed firing | Poorly adjusted head Poorly adjusted or dirty firing electrodes Poorly adjusted fan air gate; too much air Nozzle unsuited for burner or boiler Defective nozzle Inappropriate pump pressure | Adjust Adjust Adjust See Nozzle Table Replace Adjust |

| | | | |
|---|--|--|--|
| 2 | The burner does not pass to 2nd stage | Control device TR does not close Defective control box | Adjust or replace Replace |
| | Uneven fuel supply | Check if cause is in pump or fuel supply system | Feed burner from tank Located near burner |
| | Internally rusted pump | Water in tank | Remove water from tank bottom with separate pump |
| | Noisy pump, unstable pressure | Air has entered the suction line Tank/burner height difference too great Piping diameter too small Suction filters clogged Suction valves closed Paraffin solidified due to low temperature | Tighten connectors Feed burner with loop circuit Increase Clean Open Add additive to light oil |
| | Pump loses prime after prolonged pause | Return pipe not immersed in fuel Air enters suction piping | Bring to same height as suction pipe Tighten connectors |
| | Pump leaks light oil | Leakage from sealing organ | Replace pump |
| | Smoke in flame -Dark | Not enough air Nozzle worn or dirty Nozzle filter clogged Erroneous pump pressure Flame stability disk, dirty, loose, or deformed Boiler room air vents insufficient Too much air | Adjust head and fan damper Replace Clean or replace Adjust Clean, tighten in place, or replace Increase Adjust head and fan damper |
| | Dirty combustion head | Nozzle or filter dirty Unsuitable nozzle delivery or angle Loose nozzle Impurities on flame stability disk Wrong head adjustment or not enough air Blast tub length unsuited to boiler | Replace See recommended nozzles Tighten Clean Adjust, open air damper Contact boiler manufacturer |
| I | During operation, the burner stops in lock-out | Dirty or defective photocell | Clean or replace |



Common Diagnostic Issues

If in case that you run into an issue, listed below are common issues that may occur while operating your Mathews Company grain dryer.

Problem:

Dryer will not reach operating temperature, or it reaches it slowly.

Possible Cause/Solution:

1. Low gas pressure. Increases gas pressure on the main gas regulatory.
2. Check for water in the gas train by opening the drain valve.
3. Make sure the dryer is completely full of grain by entering the heat plenum chamber and looking for daylight in one of the grain columns.
4. Make sure that the gas butterfly valve is being driven wide open by the modutrol motor. If not, check the motor or motor linkage. Also check to make sure that there is not a block within the gas piping. There should be 10 pounds on the primary regulator and 1 to 2 pounds on the secondary.

Problem:

Blower motor(s) will not start.

Possible Cause/Solution:

1. Check that the fan circuit breaker and the fan switch are on. Also, check for a defective switch or bad wire connections.
2. Verify closing of the fan motor contactor. Check voltage on the load side of the contactor.
3. Inspect the contactor for defective contact or a burned out coil.
4. Inspect connections, and check voltage applied to the motor leads to determine if the motor is defective.

If the motor starts slowly, check for low voltage during starting due to excessive voltage drop in power supply wiring.

Problem:

Burner will not fire.

Possible Cause/Solution:

1. Check gas supply for possible obstruction or closed valves. Refill tank; replace or repair parts as required.
2. Inspect gas solenoid valves for defective coils or improper wiring. Replace the valve or coil if the valve will not open with proper voltage applied (115 volts).

Problem:

Burner will not fire, but gauge shows gas pressure.

Possible Cause/Solution:

1. Check that the igniter is properly gapped and has a strong spark.
2. Inspect the porcelain and electrodes for damage or cracking. Clean or replace if necessary.
3. Machine does not have chassis ground.
4. Check solenoids for proper operation.

Problem:

Uneven drying, some kernels appear brown while others are under dried. Uneven heat exiting from dryer columns.

Possible Cause/Solution:

1. Check plenum temperature setting. Some varieties of grain are more sensitive to higher operating temperatures. It may be necessary to lower the plenum operating temperature to accommodate this.

Problem:

Grain is not moving through columns.

Possible Cause/Solution:

1. Check the dryer for fine material buildup inside the columns.
2. Avoid leaving the dryer columns full for long periods at a time (2-3 days) while not operating the dryer, or during rainy weather.
3. Empty the dryer and clean regularly. Do not allow fine material to gather in the plenum chamber.

Problem:

Difficult lighting the burner

Possible Cause/Solution:

1. Fan must be ON to achieve air pressure light.
2. Ignition switch set to the ON position. This applies 120 VAC at L1 (0 volts at L2 Neutral) of the ignition board.
3. After pre-purge time, the ignition board should power out 120 VAC at V1 (V2 neutral) for a trial ignition period to eliminate the gas valve light and gas valve light. The ignition trial time is 7 seconds. If the trial is not successful, voltage outputs stop.
4. Check the gas solenoid operation by listening for a click/snap or feeling the vibration as they open. If the solenoid doesn't open, check the wiring and coil for damage, bad connections, etc.
5. Check the spark plug (igniter) for spark. Check the high voltage wire for damage, good connections.
6. Replace the ignition board.



Problem:

The burner lights but does not stay on.

Possible Cause/Solution:

(NOTE: This is most likely due to the flame sensing)


1. Ensure flame sense probe is located in the flame.
2. Inspect the sense wire for damage and for loose or wet connections.
3. Check that sense wire is routed separately from the high voltage ignition wire.
4. Check the ignition board (B.GND) is grounded separately from all other connections. Sharing a ground connection can cause problems.
5. Clean sense probe with fine steel wool.


Burner may have to be grounded at the burner body directly to the burner housing

Appendix

Normal Start Up Procedure (Oil Fire Model Dryers)

The purpose of this flow chart is to show the normal startup sequence of the Riello light oil fired burner.





To select TruDry mode enter the current mid-grain setpoint in the discharge screen and press TruDry; the text should turn green.



In TruDry mode the system will adjust the discharge rate to maintain the mid-grain setpoint.





The dryer will run like this with occasional adjustment until the supply of grain is insufficient at which point the grain flow timer will shutdown the machine after set time elapses.



General Safety Control Circuit Shutdown (Oil Fire Model Dryers)


The purpose of this flow chart is to show the general safety control circuit shutdown process of the Riello light oil fired burner.






Plenum Temperature High Limit Shutdown (Oil Fire Model Dryers)

The purpose of this flow chart is to show the plenum temperature high limit shutdown process of the Riello light oil fired burner.




Loss of Air Pressure Shutdown (Oil Fire Model Dryers)

The purpose of this flow chart is to show the loss of air pressure shutdown process of the Riello light oil fired burner.



Low Fuel Pressure Shutdown (Oil Fire Model Dryers)

The purpose of this flow chart is to show the low fuel pressure shutdown process of the Riello light oil fired burner.



Section 8

Notes







GRAIN DRYER
SPECIALISTS



Mathews Company
www.MathewsCompany.com

Crystal Lake, IL
phone: 815-459-2210
fax: 815-459-5889
email: mcsales@mathewscountry.com