


\$2.00



**Model 375**  
(EM, EMS, B-115 and B-12)  
**Continuous Flow  
Grain Dryers**



# OPERATOR'S MANUAL


Form No. D176, June 1984  
(Replaces DM 1078)

**Mathews Co./**

500 Industrial Ave., Crystal Lake, IL 60014, U.S.A.  
815/459-2210 Telex 72-2488

# TABLE OF CONTENTS

	Page No.
Set-Up Instructions .....	2 & 3
Safety Guards .....	3
Moisture Control and Air Pressure Switch .....	4
Control Cabinet - Indicator Lights and Control Switches .....	4
Wet Holding Hopper and Peak Assembly - Set-Up Instructions .....	5
Wet Holding Hopper Assembly .....	6
Peak Assembly .....	6
Operating Instructions .....	6A, 6B, 7 & 8
LP Gas Manifold Assembly .....	9
LP Gas Piping Diagram .....	9
Burner Assembly .....	10
Drive Reduction Base .....	11 & 11A
Ratchet Assembly .....	11
Metering System .....	12
Variable Speed Mount and Crank .....	11B & 13
Variable Speed Pulley .....	11B & 13
Tractor P.T.O. Shaft .....	14
Load Switch (optional) .....	14
Electric Fan Drive .....	15
P.T.O. Fan Drive .....	16
Dryer Cut-Away .....	17
Dryer Electrical System Polarity & Gound Check .....	18
Lubrication .....	18
Ignition - Electrode Positioning .....	19
Trouble-Shooting .....	20
Wiring Diagram - B-12 - Standard & Canadian Controls .....	21
Wiring Diagram - B-115 - Standard & Canadian Controls .....	22
Wiring Diagram - EM Single Phase - Standard & Canadian Controls .....	23
Wiring Diagram - EM 3 Phase - Standard & Canadian Controls .....	24
All-Heat Conversion .....	25
Parts Ordering and Owners Notice .....	26



# DANGER

1. KEEP ALL GUARDS IN PLACE.
2. STOP MOTORS OR ENGINE BEFORE ADJUSTING, LUBRICATING, CLEANING, OR UNCLOGGING MACHINES, UNLESS OTHERWISE SPECIFICALLY RECOMMENDED IN THE "OPERATOR'S MANUAL".
3. WAIT FOR ALL MOVEMENT TO STOP BEFORE SERVICING THE MACHINE.
4. KEEP HANDS, FEET AND CLOTHING AWAY FROM POWER DRIVEN PARTS.
5. KEEP OFF EQUIPMENT UNLESS SEAT OR PLATFORM FOR OPERATION AND OBSERVATION IS PROVIDED.
6. KEEP ALL OTHERS OFF.
7. USE FLASHING WARNING LIGHTS WHEN OPERATING ON HIGHWAYS EXCEPT WHEN PROHIBITED BY LAW.
8. MAKE CERTAIN EVERYONE IS CLEAR OF MACHINE BEFORE STARTING OPERATION.

# SET-UP INSTRUCTIONS

NOTE: The end of the dryer with the fan is considered the front. Left and Right is determined by standing behind the dryer and looking at the rear door.

1. Place dryer in a level position.

A. Permanent installation:

Place dryer on concrete slab or piers with planks between concrete and skids. Anchor dryer down to prevent blow over.

B. For Portable or Temporary installation:

Place planks under full length of skids. Remove wheels or dig holes for wheels. Full weight of dryer must rest on the dryer skids. Dryer should be anchored down to prevent blow over.

2. Install Variable Speed Crank Assembly - see page 13.

3. Install lower ladder, set up Wet Holding Hopper and install Peak - see pages 5 & 6.

4. Install all safety guards. See page 3.

5. Connect electrical power to dryer. For all electrical connections, refer to the proper wiring diagrams in rear of this manual.

A. For "E" Model Single Phase dryers connect customer supplied fused power lines to the top lugs of the magnetic starter in the starter box and connect the ground line to the ground lug.

NOTE: For Canadian Control Models be sure to connect the Neutral line to the Neutral lug.

B. For "E" Model Three Phase dryers connect customer supplied fused power lines to the top lugs of the magnetic starter in the starter box. Connect the ground line to the ground lug. Then connect the 115V control power line onto one of the 115V legs of the three phase power coming into the lugs at the top of the magnetic starter.

NOTE: Damage to the controls can result if the 115V control line is connected to the 230V leg of the three phase power.

C. For B115 Models connect grounded, three-line 115V power line to the three-pronged, fused, male plug on the outside of the control cabinet. Be sure that polarity of the plug and the supply cord are the same. See polarity check, page 18.

D. For B12 Models connect battery cables from control cabinet direct to the tractor battery terminals. Brown to negative (-) post, Red to positive (+) post. The connections must be this way or blown fuses and failures in the ignition system will result.

(Continued on page 3)


# SET-UP INSTRUCTIONS...Cont.

6. On "B" models, remove snap ring from Jackshaft, item 21, page 16, and install PTO shaft and connect to dryer shear flange using one 3/8-16 x 2 1/4 special shear bolt, part number 0018133, supplied with the dryer. DO NOT use hardened bolts or standard long thread bolts. Re-install the snap ring on Jackshaft.
7. Position tractor so there is only a small angle on the universal joints of the PTO shaft. Connect PTO to tractor power take off. BE SURE that the guard over the universal joint and shear flange at dryer and the tractor guard over the power take off are in place.
8. Connect gas supply to machine.
  - A. L.P. Gas - Advise your L.P. Gas supplier that the dryer takes liquid from the tanks (not vapor). When the gas system is connected to the dryer, be sure an Excess Flow Valve is installed at the tank, preferably the one furnished with the dryer as it will shut off quicker (in case of line breakage) than those normally furnished by the gas supplier. In any case NEVER have two Excess Flow Valves on the same line.

Use a minimum of 1/2" ID gas line between tank and dryer. For distances over 100 feet use a 3/4" ID diameter line. Connect the gas line from the tank to the short flexible hose on the dryer.

- B. Natural Gas - A minimum of 5 lbs. of operating pressure is required on all models. Use minimum two-inch line from Natural Gas regulator to dryer. Use reducing bushing to 1 1/4" just before connecting to pipe outside dryer control cabinet.



## GUARDS FOR ELECTRIC AND P.T.O. MODELS



REF. #	PART #	ITEM
1.	1284866	Front Guard Mount Angle
2.	1284887	Front Guard Top
3.	1280083	P.T.O. Shear Flange Guard
4.	1285761	Front Guard Screen
4-A	1284890	Front Guard Hole Cover
5.	1218956	Fan Guard
6.	1218255	5/16 - 18 x 1 1/2" J-Bolt
7.	0008176	5/16 Flat Washer
8.	0008166	5/16 - 18 Wing Nut


# SAFETY CONTROLS

REF. NO.	PART NO.	DESCRIPTION
1	1216851	Thermoswitch (Moisture Control)
2	1210031	Thermoswitch Shield Weldment
3	0008184	#8 x 1/2 Sheet Metal Screw
4	1217018	High Limit Switch
5	1216849	Air Pressure Switch
6	1210169	Air Pressure Tube Weld Wire Filter Retainer
8	1215716	Air Pressure Tube Filter
9	1280160	Air Pressure Switch Cover
10	1210081	High Limit Shield
11	1218000	1/4" Pipe Lock Nut



USE STANDARD ILL. WITH  
HIGH LIMIT AND RAIN GUARD

## CONTROL CABINET — INDICATOR LIGHTS AND CONTROL SWITCHES



Item	Part #	Description
1, 2, 3, 4	1216808	115V Lamp Ass'y Complete
	1286860	12V Lamp Ass'y Complete
	1216977	Lamp Cover, Clear Lens Only
	1226810	115V Light Bulb Only
	1216978	12V Light Bulb Only
5	1216815	Ignition Toggle Switch
6	1216807	Moisture Control Toggle Switch
7	1216806	Load Toggle Switch (Included with optional load switch kit 1239076)

The Control Cabinet consists of temperature and safety controls. There are four lights wired in series with controls to indicate operation.

### Indicator Lights:

- No. 1 Lights when electric power is on.
- No. 2 Lights when fan is running and dryer is full of grain (air pressure completes circuit to ignition switch).
- No. 3 Lights when high limit control circuit is closed.
- No. 4 Lights when Fenwal Ignition Switch is turned on, electrodes are firing, and the gas solenoid is open.

# WET HOLDING HOPPER & PEAK ASSEMBLY SET-UP INSTRUCTIONS (REFER TO ILLUSTRATIONS PAGE 6)

## WET HOLDING HOPPER

The hopper is shipped folded down and must be assembled at the installation.

NOTE: Inspect and remove all foreign material from feed rolls and augers. Avoid dropping nuts, bolts, parts, etc. down the grain columns. If anything is accidentally dropped, it must be removed before filling dryer.

Use  $\frac{3}{8}$ -16  $\times$   $\frac{3}{4}$ " bolts and  $\frac{3}{8}$ -16 Whiz Nuts through steps 1 and 2.

STEP 1: Fold up the front and rear Hopper Panel Assemblies and their two adjoining side Hopper Panel Assemblies. Bolt them together along the corner seams. Put a plank on top of heat chamber cross angles to walk on. Avoid standing on grain column tie straps.

STEP 2: Bolt the bottom flanges of all the Hopper Panel Assemblies to the Galvanized Angles, to which the hinges are fastened.

NOTE: Place a  $\frac{3}{8}$  flat washer between the head of the bolt and Hopper Panel.

STEP 3: Fasten Ladder Mounting Brackets to right rear Hopper Panel Assembly using  $\frac{5}{16}$ -18  $\times$   $\frac{3}{4}$ " bolts and  $\frac{5}{16}$ -18 Whiz Nuts.

STEP 4: Bolt Ladder to Ladder Mounting Brackets using  $\frac{5}{16}$ -18  $\times$   $\frac{3}{4}$ " bolts and  $\frac{5}{16}$ -18 Whiz Nuts.

## PEAK ASSEMBLY

NOTE: Leave all bolts loose (finger tight) until Step 5.

STEP 1: Beginning at front of dryer, install two Peak Panels, Ref. 1, to the top of the inner perforated screens, one on each side. Use  $\frac{5}{16}$ -18  $\times$   $\frac{3}{4}$ " Truss Head Screws and  $\frac{5}{16}$ -18 Whiz Nuts. The head of screw should be on the inside of grain column. DO NOT bolt the peak panels to the End Hopper Panel Assemblies until Step 5.

STEP 2: Bolt a Hopper Cap, Ref. 2, onto these first two Peak Panels using  $\frac{5}{16}$ -18  $\times$   $\frac{3}{4}$ " Truss Head Screws and  $\frac{5}{16}$ -18 Whiz Nuts. The Whiz Nut must be inside the air chamber.

STEP 3: After two sets of Hopper Peak Panels are in place, install  $3\frac{1}{4}$ " Inner Hopper Cross Ties, Ref. 4. Install  $2\frac{9}{16}$ " Inner Hopper Support Angles, Ref. 5, at the center hole along the Hopper Peak Panel seams. Use  $\frac{5}{16}$ -18  $\times$   $1\frac{1}{4}$ " bolts and  $\frac{5}{16}$ -18 Whiz Nuts. The other end of the Inner Hopper Support Angles fasten at the third bolt holes down from the top along the vertical seam of the Inner Perforated Screens on each side. Remove the  $\frac{5}{16}$ -18  $\times$   $\frac{1}{2}$ " bolt, and replace with  $\frac{5}{16}$ -18  $\times$   $\frac{3}{4}$ " bolts, to hold the Support Angle. These angles should be installed at each seam of the Hopper Peak Panels.


STEP 4: Continue along the dryer installing sets of two Peak Panels (one on each side), fastening to inner perforated screens, Hopper Cap, and to each other using  $\frac{5}{16}$ -18  $\times$   $\frac{3}{4}$ " bolts and  $\frac{5}{16}$ -18 Whiz Nuts. Install Inner Hopper Support Angles and Cross Ties after each set of Peak Panels.

STEP 5: Install the hopper seal angles, Ref. 3, at each end of the Peak. Then bolt the Hopper Peak panels to the Hopper End Panel Assemblies using  $\frac{5}{16}$ -18  $\times$   $\frac{3}{4}$ " bolts and  $\frac{5}{16}$ -18 Whiz Nuts. The head of the bolts should be on the outside of the Hopper.

**TIGHTEN ALL BOLTS AT THIS POINT.**


The Hopper and Peak are now complete.

# 375 WET HOLDING HOPPER ASSEMBLY




REF. #	PART #	DESCRIPTION	REF. #	PART #	DESCRIPTION
1	1282052	End Hopper Flange Stiffener	9	0008119	3/8-16 x 3/4 HHCS
2	1282051	Side Hopper Flange Stiffener	10	0008168	3/8-16 Whiz Nut
3	1284824	Hopper Side Panel	11	0008106	5/16-18 x 3/4 HHCS
4	1284822	Hopper Ind Panel - Upper	12	0008169	5/16-18 Whiz Nut
5	1284823	Hopper End Panel - Lower	13	0008103	5/16-18 x 1/2 Truss Head
6	1280162	4 Foot Ladder	14	1282660	Ladder Mount Bracket
7	1282661	Ladder Mounting Angle	15	1284808	Load Switch Hopper Panel
8	1288957	Hopper Hinge	16	1282996	Cover Plate

## PEAK ASSEMBLY



REAR OF DRYER




REF. #	PART #	DESCRIPTION
1	1282891	Perf. Peak Panel
	1272834	Solid Peak Panel
2	1282991	Hopper Cap
3	1282908	Hopper Seal Angle
4	1282012	Horizontal Peak Angle 31 1/4" Long
5	1282003	Vertical Peak Angle 29 1/4" Long

# Operating Instructions

For M-C Model 375 EM, EMS, B-115 & B-12 Continuous Flow Grain Dryers  
(Starting w/Serial No. 43657)


## Start-Up

1. Flip all switches on the control panel to the **OFF** position. Be sure that the gas main hand valve in the cabinet is closed (handle 90° to the piping). Also, be sure that the modulating valve in the cabinet has not been turned all the way in to the wide open position. The "T" handle should be half way between the closed and fully open position.
2. **EM and EMS Models** - Turn on the electric power supply to the dryer.  
**B-115 Models** - Connect a grounded three wire 115V electric power supply cord to the three blade fused male plug on the outside of the control cabinet. Be sure that the polarity of the electric power supply cord is the same as the male plug on the cord coming out of the control cabinet. The ignition board will "lock out" if the electric power supply polarity is not the same as the dryer electrical system. See "Polarity Check" in the Operator's Manual.  
**B-12 Models** - Connect the battery cables from the control cabinet direct to the tractor battery terminals. **Brown** to the negative (-) post and **Red** to the positive (+) post. If these connections are reversed, the ignition board will "lock out".
3. The "POWER" and "HIGH LIMIT" lights will be **ON**. If the "HIGH LIMIT" light is not on, push the reset button on the high limit switch located just above the control cabinet.
4. For the initial filling, flip the hopper level toggle switch on the control panel to the **AUTOMATIC** position. The load switch in the wet holding hopper will stop the filling conveyor when the dryer is full.
5. **LP Gas** - Open the tank supply valve and open (lift up) the liquid line hand valve (flip valve) at the dryer. **Nat. Gas** - Open supply valve.
6. Start the fan. The "AIR PRESSURE" light will come **ON** when the fan comes up to speed. If the light does not come on or comes on too soon (before the fan is up to speed) the air pressure switch must be adjusted. See Operator's Manual.



LP Gas Model

(Gas main hand valve in closed position)



LP Gas Model

7. Flip the ignition switch **ON**. Open the gas main hand valve ¼ of the way. The "GAS VALVE" light will be **ON** and the burner will light. After the flame is established, slowly open the gas main hand valve all the way (handle parallel to the piping).
8. **LP Gas Only** - Check the reading on the gas pressure gauge. It should be approximately 8 to 10 pounds (less in mild weather). If not, turn the gas pressure regulator adjusting screw in to increase or out to decrease pressure.
9. Adjust the modulating valve to obtain the desired temperature, see chart below. Turn



the "T" handle **IN** to increase temperature and **OUT** to decrease temperature.

### Drying Chart

Type of Grain	Drying Temperature
Corn	180°F to 200°F
Grain Sorghum	160°F to 180°F
Wheat or Oats	160°F to 170°F
Soybeans or Barley	130°F to 140°F
Seed Grains	Not over 110°F

10. Be sure that moisture control switch is in the **OFF** position. It will take approximately 6 minutes per point of moisture removed to dry the first load of grain in the heating section.

The cooling section will have wet grain in it (unless the dryer is being operated "ALL HEAT") and will not be dried on the first run. This grain will have to be recycled back into the heating section.

11. When the first load is dry, flip the moisture control switch to the **MANUAL** position. This will activate the ratchet solenoids and the unloading auger will begin unloading grain.

12. When dried grain begins to auger out, test it for moisture content. If moisture content is too high, decrease the unloading speed. If moisture content is too low, increase the unloading speed. See Operator's Manual.

Wait 1 hour to allow the dryer to react to the change. Recheck the moisture content and adjust the unloading speed again if necessary.

13. When the dryer has discharged grain at the desired moisture content for 1 hour, flip the moisture control switch to the "AUTOMATIC" position. Set the moisture control on each side of the dryer, see chart below.

### Approximate Moisture Control Setting for Corn and Most Small Grains

Operating Temperature	Set Control Dial At	To Get % Moisture
140°F	3.5	13 - 14%
180°F	4.0	14 - 15%
180°F	4.5	13 - 15%
180°F	5.0	12 - 13%

**NOTE:** If the dryer is being operated "ALL HEAT" the chart above can be used as a starting point. In most cases the final moisture control setting will be 1 to 3 marks lower than the settings shown in the chart. The final setting must be determined under actual drying conditions with each individual dryeration or combination drying system.

14. **EM, EMS and B-115 Models Only** - If the grain take away system fails, the dryer will continue to discharge grain until the rear discharge overload door is raised by the grain. When the overload door raises, the dryer will shut down and all of the lights on the panel will be out.

When the problem has been corrected and the rear discharge overload door closes, the "POWER and HIGH LIMIT" lights on the panel will come on. Flip the ignition switch **OFF**, restart the fan and burner.

### Shut Down

1. Close the LP Gas supply valve at the tank or close the natural gas supply valve. Operate the burner until the flame goes out. Flip the ignition switch **OFF**.
2. Close the gas main hand valve in the cabinet (handle 90° to the piping).
3. **LP Gas** - Close the liquid line flip valve at the dryer (handle parallel to the pipe).
4. Flip the hopper level switch **OFF**.
5. Run the fan 20 minutes to cool the grain in the dryer, then turn it **OFF**.
6. Turn off the electric power supply to the dryer.

**NOTE:** Do not turn off the electric power supply if the upper control cabinet heat bulb is to remain on (not on Model B-12).

# OPERATING INSTRUCTIONS

(Below Serial No. 43657)

1. Be sure all electrical power and gas valves are turned off.
  2. Be sure there is adequate clearance between fan and fan housing and between the fan and the burner.
  3. Before proceeding make sure all safety guards are in place, see page 3.
  4. Be sure all switches on the control cabinet are in the "OFF" position.
  5. Turn on electrical power to the dryer. On B115 Models plug in the three-pronged plug outside the control cabinet. On B-12 Models connect the battery. REMEMBER: Red to Positive (+) terminal and Brown to Negative (-) terminal. The "Power On" and "High Limit" lights should glow. Trouble: See page 20.
  6. Be sure that the adjusting screws of the pressure regulator and the modulating valve are not turned all the way in. This could result in damage to the valves from excessive pressure or may cause difficulty in starting the burner.
  7. Fill the dryer with grain. If the dryer is equipped with the optional load switch kit, a toggle switch is located on the control cabinet marked "Level Auger". This switch will activate a 115V coil in a standard magnetic starter used to start and stop the electric motor on the grain filling conveyor. (Magnetic starter not included in load switch kit.)
    - A. AUTOMATICALLY OPERATED FILLING: When the toggle switch is flipped to the "Automatic" position the filling conveyor should run until the dryer is full of grain and then automatically shut off.
    - B. MANUALLY OPERATED FILLING: When the toggle switch is flipped to the "Manual" position the filling conveyor will run continuously. NOTE: Care must be taken not to overflow the top of the dryer. The "Manual" operation is more or less a "stand-by" system in the event of damage to the automatic switch assembly in the hopper.
  8. Slowly open the gas supply line. On LP dryers the flip valve--Item 18, page 9, should also be opened slowly. Check thoroughly for gas leaks--both inside and outside the dryer.
  9. Start the fan. If dryer is full, the "Air Pressure Switch" light should come on. Trouble: see page 20. At this time the Air Pressure Switch should be adjusted. See top of page 4, Item #5. Remove the red plastic cap to expose the adjusting screw. Turn screw into the unit until the Air Pressure Switch light goes out. Then back the screw out until the light comes back on and then about 1/2 turn further out. This should assure that the burner will go out if the dryer runs low on grain or the fan loses RPM.
- STARTING THE BURNER**
10. INITIAL START UP OF A NEW DRYER. Partially open hand valve--Item 20, page 9.

NOTE: The hand valve is shown fully closed on page 9. Flip on the Ignition Switch. The main Heat Valve Light should glow. turn Pressure Regulator Adjusting Screw in or out until 5-7 pounds of pressure is reached on the dial gauge. Adjust the pressure regulator only when the hand valve is open and the Main Heat Valve light is glowing. If the burner does not ignite in 6-7 seconds, turn the Ignition Switch to "OFF", wait one minute and try again.
- SETTING TEMPERATURE**
11. The temperature is regulated by the Modulating Valve. To increase the temperature, turn the handle in. To reduce the temperature, turn the handle out. (See Drying Chart on Page 8 for suggested operating temperatures of various grains.)
  12. The cooling section of the dryer will have wet grain in it, and will not be dried on the first run. This grain will have to be recycled back into the heating section.
  13. Make sure Automatic Moisture Control Switch is in "OFF" position. In order to dry all the grain in the upper section, it will require approximately one hour of continuous heat to dry the first load from 30% to 15% moisture and proportionately less for moistures under 30%.
  14. After approximately one hour of drying on the first load, turn Moisture Control Switch to "Manual" position. This will engage Ratchet Solenoids and begin unloading the grain. When grain in cooling section has moved through and dried grain begins to auger out, after about 45 minutes, test it for moisture content. If moisture content is too high, slow the unloading down. If moisture content is too low, speed unloading up.

# OPERATING INSTRUCTIONS....Cont.

(Below Serial No. 43657)

15. To change the speed of unloading, a combination of two adjustments is available.

(A) By turning Variable Crank arm **CLOCKWISE** to **SPEED UNLOADING** and **COUNTER CLOCKWISE** TO **SLOW UNLOADING**. This is normally used for fine adjustment.

**CAUTION:**

Do not put extreme pressure on belts. **ADJUST VARIABLE SPEED PULLEY ONLY WHEN MACHINE IS OPERATING.**

(B) The Feed Rolls can be adjusted independently of the auger by sliding the "Connecting Arm" along the slotted bracket on the Eccentric Sprocket. The Eccentric Sprocket is located in the lower part of the speed reduction assembly on the drive end of the dryer. Moving the Connecting Arm **TOWARDS THE CENTER** of the sprocket will **DECREASE** the stroke and **SLOW** down the **UNLOADING** of the Feed Rolls. Moving it **AWAY** from the **CENTER** of the sprocket will **INCREASE** the stroke and **SPEED UP** the **UNLOADING** of the feed rolls. **CAUTION: NEVER MAKE ADJUSTMENT ON SPROCKET UNTIL IT HAS COME TO A COMPLETE STOP.**

Normal factory setting is for two teeth. When removing more than 10 points of moisture, it may require slowing down to one tooth. When removing less than 10 points of moisture, it may require increasing to three or more teeth.

**NOTE:** Be careful not to discharge more grain out of the Feed Rolls than the Auger can carry away!

16. After your dryer is operating properly and is discharging grain at the desired moisture content for one hour, switch to "Automatic Moisture Control". Flip the "Moisture Control Switch" to Automatic position, then set the Moisture Control on each side of the dryer by turning the indicator knob to the point that will just maintain Feed Roll operation. Most likely each moisture control will have a slightly different setting. Normally they will be set within the limits shown in the following chart.

**APPROXIMATE SETTING FOR SHELLED CORN AND MOST SMALL GRAINS**

Thermometer Setting	Set Control Dial At	To Get— Percent Moisture
140°	3.5	13-14%
180°	4.0	14-15%
180°	4.5	13-15%
180°	5.0	12-13%

If the moisture content of the grain coming out of the dryer starts to increase, increase the setting of the control one mark at a time until the correct moisture content is reached. Allow ample time between adjustments for machine to correct itself, suggested time to be 1 hour.

Adjust the unloading mechanism to correspond with the rate of feeding of the grain by the automatic control. These adjustments will only be slight if you have had your dryer operating correctly before switching it to "Automatic Moisture Control."

The speed of the Variable Drive should be fast enough to cause the Automatic Moisture Controls to operate intermittently but having the Feed Rolls engaged 85% to 90% of the time. If the unloading mechanism is working too slow, the Moisture Control Solenoids will operate constantly and the grain will come out drier than desired.

16. If you have followed the instructions carefully your dryer will operate continuously without watching or adjusting as long as you keep it full of grain.

**17. SUGGESTED DRYING CHART**

Types of Grain	Drying Temp.
Corn	180°F to 200°F
Grain Sorghum	160°F to 180°F
Wheat or Oats	160°F to 170°F
Soybeans or Barley	130°F to 140°F

**SHUT-OFFS AND RESTARTS**

When stopping the dryer, shut off the heat and let the grain cool. (Turn off Ignition Switch and run fan for 15 to 20 minutes with cool air.) Shut off Hand Valve, Flip Valve, and Tank Valve on LP models.


To re-start, open Tank Valve, Flip Valve, turn on Ignition Switch, and gradually open Hand Valve. Remember to open Hand Valve gradually to prevent freeze ups.

**FINAL SHUT DOWN OF DRYER**

Your dryer is a continuous flow dryer, and it is necessary to hold the grain in the dryer for a period of time when finishing a crop or at the end of the season. Ratchet Pawls should be disengaged by flipping Moisture Control Switch to OFF. This will give the grain remaining in the dryer time to become dried. Allow about 30 minutes of drying time for high moisture grain (30%) and proportionately less for drier grain. Then turn Moisture Control Switch to Manual position for emptying. At end of season, lubricate all moving parts and remove the unloading auger pan underneath the dryer.

# LP GAS MANIFOLD


*S/N ?  
Piping for Mult. Dors. ?*




REF #	PART #	DESCRIPTION
1	1288019	3/4" Union Elbow Ex. Hvy.
2	1218005	3/4" x 1 1/2" Nipple Ex. Hvy.
3	1218060	3/4" Strainer
4	1288006	3/4" x 6" Nipple Ex. Hvy.
5	1217006	3/4" REGO Regulator
6	1218067	3/4" x 1 1/2" Nipple Std.
7	1218074	3/4" 90° Elbow Std.
8	1278008	3/4" x 6" Nipple Std.
9	1288035	3/4" Side Outlet Tee
10	1218030	3/4" to 1/2" Reducing Bushing
11	1218039	1/2" 90° Street Elbow
12	1207002	Pressure Gauge
13	1218007	3/4" x 2" Nipple Std.
14	1218050	3/4" Cap Std.
15	1218008	3/4" x 3" Nipple Std.
16	1217002	3/4" Gas Solenoid Valve for 115V
16A	1217025	3/4" Gas Solenoid Valve for 12V
17	1218029	3/4" to 1/2" Reducing Bushing
18	1218013	1/2" x Close Nipple
19	1217012	1/2" Modulating Valve
20	1217011	3/4" Hand Valve
21	1218007	3/4" x Close Nipple
22	1288039	3/4" Union Elbow Std.
23	1227002	Power Element 90° to 210° "B"
24	1227001	Replacement Coil for 115V Dryers
24A	1227024	Replacement Coil for 12V Dryers

# LP GAS PIPING DIAGRAM



REF. #	PART #	DESCRIPTION
1	1258064	3/4" x 19 1/2" Ex. Hvy. Nipple
2	1218027	3/4" x 90° Ex. Hvy. Elbow
3	1218083	3/4" x 9" Ex. Hvy. Nipple
4	1218072	3/4" Ex. Hvy. Union
5	1218098	3/4" x 5" Ex. Hvy. Nipple
6	1218032	3/4" to 1/2" x 90° Ex. Hvy. Red. Elbow
7	1218071	1/2" x 90° Ex. Hvy. Street Elbow
8	1210336	Vaporizer
9	1288010	1/2" Ex. Hvy. Union Elbow
10	1218041	1/2" x 16 1/2" Ex. Hvy. Nipple
11	1218036	1/2" x 90° Ex. Hvy. Elbow
12	1288036	1/2" x 28 1/2" Ex. Hvy. Nipple
13	1218035	1/2" Ex. Hvy. Tee
14	1217014	Relief Valve Adapter
15	1217013	Relief Valve
16	1218048	1/2" x 90° Std. Street Elbow
17	1208047	1/2" x 2" Ex. Hvy. Nipple
18	1217015	1/2" Liquid Line Hand Valve
19	1217005	Inlet Hose
20	1218019	3/4" x 20" Std. Nipple
21	1218074	3/4" x 90° Std. Elbow
22	1218067	3/4" x 1 1/2" Std. Nipple
23	1218028	3/4" Std. Union
24	1288038	1/2" x 18 1/2" Std. Nipple
25	1218049	3/4" x 6 1/2" Std. Nipple
26	1238049	1 1/4" to 3/4" x 90° Std. Red. Elbow



# 375 BURNER ASSEMBLY



Ref.	Part No.	Description	Ref.	Part No.	Qty.	Description
1	1280178	Orifice	14	1252870		Front Floor Panel - Left
2	1210322	Burner Tube	15	1252871		Front Floor Panel - Right
3	1210336	Vaporizer	16	1282881		Front Floor Panel - Center
4	1215987	Burner Gas Lead Tube	17	1238065		1 1/4" x 14" Long Pipe
5	1211241	Burner Unit	18	1282027		Air Pressure Tube Brkt.
6	1215988	Face Plate Insert	19	1214468		Burner Locator Strip
7	121 0316	Ignition Tube	20	1215744		High Voltage Wire - For Style Electrode (Below S/N 43657)
8	1214867	Air Chamber Mtg. Brkt.		1281550		Ignition Wire, 32" - For Style Electrode (S/N 43657 & Up)
9	1212640	Electrode Mt. Brkt. (Below S/N 43657)	21	1215742		Low Voltage Wire - For Style Electrode (Below S/N 43657)
	1282936	Electrode Mt. Plate (S/N 43657 & Up)		1281551		Secondary Ignition Wire, 32" For Style 2 Electrode (S/N 43657 & Up)
10	1216926	Electrode - Style 1 (Below S/N 43657)	22	1215738		3" to 1 1/4" Reducing Bush.
	1286995	Electrode - Style 2 (S/N 43657 & Up)	23	1212980		Orifice Seal Plate
11	1215501	Burner Head	Not Shown			1212882 Sensing Bulb Clip
12	1210081	High Limit Shield			1212883 Sensing Bulb Bracket	
13	1210169	Air Pressure Tube			1282880 Burner Tube Baffle	




NOTE: On Style 2 electrodes,  
wires can be connected to either terminal.


# DRIVE REDUCTION BASE

(Below Serial No. 39490)

REF.	PART #	DESCRIPTION
1	1280155	Jackshaft Bracket Weldment
2	1281067	Eccentric Sprocket Assembly - Includes - 2A & 2B
2A	1280103	Eccentric Sprocket Slide Weldment
2B	0008106	5/16-18 x 3/4 HHCS
	0008173	5/16 Flatwasher
	0008169	5/16-18 Whiz Nut
3	1286213	12" O.D. x 1" Bore Pulley
4	1286419	RC-40-B x 18-T x 1" Bore Sprocket
5	1286416	RC-35-B x 16-T x 1" Bore Sprocket
6	1286305	RC-35 x 112 Pitch Chain
7	1285023	375 Jackshaft
8	0016008	1" Bearing With Collar
9	0016014	1" 3-Bolt Bearing Stamping
10	0016100	V-Belt B-56 Prime Mover
11	0008168	3/8 - 16 Whiz Nut
12	0008122	3/8-16 x 1" Carriage Bolt
13	0008298	1/4 x 3/4 Woodruff Key
14	1286306	RC-40 x 194 Pitch Chain




# RATCHET ASSEMBLY # 1281413



REF.	PART #	DESCRIPTION
1	1280223	Ratchet Guide Arm Weldment
2	1216856	115V Ratchet Solenoid
	1256883	12V Ratchet Solenoid
3	1210029	Solenoid Weight
4	1215724	Ratchet Dog
5	0008144	1/2-13 x 3 1/2" HHCS - left side
6	0008138	1/2-13 x 1 1/2" HHCS - right side
7	1216859	Jiffy Clip
8	0008170	1/2-13 Whiz Nut
9	0008186	6-32 x 1/2" Round Head Screw
10	0008185	6-32 Whiz Nut
11	0008199	1/8 x 1" Cotter Key

# 375 DRIVE REDUCTION BASE ASSEMBLY

(Starting w/Serial No. 39490)




M-C 440


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0008122	2	3/8-16 x 1" Carriage Bolts	12	1286309	1	RC-40 x 74 Pitch Primary Reduction Chain
2	1286121	1	BX54 Belt		1286313	1	RC-40 x 210 Pitch Unloading Auger Drive Chain
3	1286213	1	12" O.D. 1" Bore Pulley	13	0018164	1	1/2-13 x 2" Carriage Bolt
4	1216405	2	RC40 B16T 1" Bore Sprocket	14	0008299	1	5/8" S.A.E. Flatwasher
5	1285026	1	Upper Jackshaft	15	0008136	2	1/2-13 x 1" Carriage Bolt
6	0008298	4	1/4" x 3/4" Woodruff Key	16	1281069	1	Eccentric Sprocket Ass'y.
7	0008123	8	3/8-16 x 1 1/4" Hex-Hd. Capscrew	17	0018257	2	1/2" S.A.E. Flatwasher
8	1276000	4	1" Pillow Block Bearing	18	000 8175	1	1/2" Standard Flatwasher
9	- - -6524	1	1/4" x 1 1/4" Spacer	19	0008170	3	1/2-13 Whiznuts
10	1285027	1	Lower Jackshaft	20	0018111	1	5/16-18 Clipnut
11	1286421	1	RC40 B-48T 1" Bore Sprocket	21	1280239	1	Reduction Base Weldment
				22	0008168	8	3/8-16 Whiznut

# Variable Speed Mount and Crank

(S/N 39490 & Up)



Ref.	Part No.	Description
1	1285192	Variable Speed Crank
2	1253425	Variable Speed Brkt. Arm
3	1218102	Roll Pin ¼ x 1½
4	0008176	⅝ Flat Washer
5	1215190	Variable Crank Nut
6	0008170	½-13 Whiz Nut
7	0008140	½-13 x 2 HHCS
8	0008199	⅛ x 1 Cotter Key
9	1281066	Adjusting Arm Ass'y.
10	1284060	Variable Speed Base
10A	1285053	Variable Speed Arm Pivot
11	1288165	½" Washer
12	1283444	Base Mount Bracket
13	1283445	Base Mount Bracket Support
14	1286217	Variable Speed Pulley Ass'y.
		See page 13
	1286236	Variable Speed Pulley Ass'y.
		Shown below.
15	1288166	½-13 x 2½ HHCS Grd. #5
16	1286121	BX-54 Belt
17	1216104	BX-61 Belt



## Variable Speed Pulley 128 6236


Ref.	Part No.	Qty.	Description
1	122 6213	1	Straight 3/16 Drive Zerk
2	122 6200	1	Outer Retaining Ring
3	122 6201	2	Retaining Washer
4	122 6203	6	Spring Pin
5	122 6202	1	End Bell Assembly
6	122 6204	2	Spring Retainer
7	122 6205	1	Spring
8	122 6207	3	Cam Follower
9	122 6208	1	Slide Face Assembly

Ref.	Part No.	Qty.	Description
10	122 6215	1	Center Face Assembly
11	122 6209	2	Lube Seal
12	122 6210	3	Sleeve Bearing
13	122 6211	1	Sleeve Assembly
14	122 6212	1	Slide Face Key
15	122 6216	1	Fixed Face
16	122 6214	1	Shaft Assembly
17	122 6217	1	Inner Retaining Ring

When ordering replacement parts:  
 Ref. 9 includes Ref. 8  
 Ref. 13 includes Ref. 11, 12 & 14  
 Ref. 16 includes Ref. 1, 2, 3 & 17




# 375 METERING SYSTEM



REF. #	PART #	TITLE	REF. #	PART #	TITLE
1	1280191	Feed Roll Outboard Br'g. Mount	17	1286418	Unload Auger Sprocket (RC - 40 - B 45 - T Sprk't.)
2	1216022	1 1/4" Bore Wood Bearing - Complete	18	1286018	1-7/16" Pillow Block Br'g.
3	1286011	Nylon Ratchet Bushing	19	1286414	RC-40 Idler Sprocket
4	1216404	Ratchet Wheel	20	0008257	3/8-16 x 5 HHCS Full Thread
5	1281413	Ratchet Assembly—See Page 11	21	1284492	RC-40 Take Up Brk't.
6	1216856	Solenoid (115V.)	22	0018136	3/8-16 x 3 1/4 HHCS - Grd. #5
6A	1256883	Solenoid (12V.)	23	1280079	Unloading Auger
7	1281261	Transfer Arm	24	1282733	Unloading Auger Pan
8	1282652	Ratchet Stop Dog Mount Plate	25	1281186	Feed Roll Ass'y. (Left & Right)
9	1210355	Ratchet Stop Dog Mount	26	1285998	Output Shaft
10	1210354	Ratchet Stop Dog	27	1280096	Unload Auger Discharge
11	1218162	3/8-16 x 1 1/2 HH Shoulder Bolt	28	1284712	Unload Auger Discharge Cover
12	1281258	Base Panel Access Cover	29	0016003	1 1/2 Bearing w/ Collar
13	1280224	Idler Bracket (Bolt-On)	30	0016004	3-Bolt 1 1/2 Br'g. Stamping
14	1285996	Input Shaft	31	1214438	Feed Roll End Washer
15	1281063	Feed Roll Bearing w/ Bronze Bushing			


# VARIABLE SPEED MOUNT AND CRANK

(Below Serial No. 39490)




REF. #	PART #	DESCRIPTION
1	1285192	Variable Speed Crank
2	1210320	Variable Speed Crank Mount Bracket
3	1218102	Roll Pin ¼ × 1½
4	0008176	⅝ Flat Washer
5	1215190	Variable Crank Nut
6	0008170	½-13 Whiz Nut
7	0008140	½-13 × 2 HHCS
8	0008199	⅛ × 1 Cotter Key
9	1281066	Adjusting Arm Ass'y.
10	1284060	Variable Speed Base
10A	1285053	Variable Speed Arm Pivot
11	1288165	½" Washer
12	1283444	Base Mount Bracket
13	1283445	Base Mount Bracket Support
14	1286217	Variable Speed Pulley Ass'y.
	1286236	Variable Speed Pulley Ass'y. - Page 11B
15	1288166	½-13 × 2½ HHCS Grd. #5
16	0016100	B-56 Belt
17	1286105	B-63 Belt

# VARIABLE SPEED PULLEY 1286217



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	1228919	Snap Ring	7	1228910	Center Sheave & Spindle Ass'y.
2	1228918	Outer Spring Cover	8	1228914	Inner Sheave & Spindle Ass'y.
3	1228906	Set Collar 1½" I.D. (4404-6)	9	0008996	¼-28 Nft. Straight Zerk
4	1228917	Spring	10	0008201	5/16-18 × 5/16 Socket Head Set Screw Knurled Cup Point
5	1228916	Inner Spring Cover			
6	1228915	Outer Sheave w/Bushing			


# TRACTOR P.T.O. SHAFT




REF.	PART NO.	DESCRIPTION
1	0016600	PTO Drive Shaft
2	0026620	Tractor Half Assembly w/O.D. Yoke
3	0026627	Male Shaft & Yoke Weldment
4	0026628	Universal Joint Repair Kit
5	0027651	Quick Detachable Yoke Assembly
6	0026629	Safety Lock Pin & Spring Kit
7	0026624	Female Guard Tube
8	0026626	Bell Shield
9	0026625	External Snap Ring
10	0026606	3/8" Diameter Ball
11	0026621	Complete Machine Half PTO w/Shear Flange
12	0026622	Female Shaft & Yoke Weld- ment
13	0027652	Flange Yoke 1-1/4 Bore
14	0026623	Male Guard Tube

## LOAD SWITCH 1201011 USED IN KIT 1239076

REF. NO.	PART NO.	DESCRIPTION
1	1272832	Load Switch Mn't. Plate
2	1208996	Diaphragm
3	1205200	Merc. Switch Brk't. Washer
4	1202946	Mount Bracket
5	1206801	Merc. Switch Clip
6	1206800	Mercury Switch
7	0008157	6-32 Hex Nut
8	1254486	Level Switch Weight
9	1205201	Level Switch Housing
10	1206802	Terminal Strip
11	0008188	8-32 Hex Nut
12	0008210	1/4-20 Hex Nut
13	0008184	#8 x 1/2 Self Drilling Sheet Metal Screw
14	0008192	8-32 x 3/4 Screw
15	0008105	5/16 - 18 x 1/2 HHCS
16	0008169	5/16 - 18 Whiz Nut
17	0008212	1/4 x 20 x 1/2 R.D. Head
18	1216920	18/2 Dynaprene Cable
19	1256901	Strain Relief Bushing
20	1207981	L.A. Control Switch Cover
21	---	#6 Lockwasher
22	0008280	6-32 x 3/8 R.D. Head




# FAN DRIVE ELECTRIC




REF. #	PART #	DESCRIPTION
1	1284284	Mount Frame Strut
2	1210258	Motor Mount Base Weldment
3	1210337	9 Blade - 18° Fan
4	1280167	Stand Off Motor Mount Weldment
5	1216924	10 HP Motor 1 Ø 55 Amp
6	1216233	V-Pulley 4" O.D. × 1 3/8 Bore
7	1216239	SK Bushing 1 3/8 Bore
8	0008165	3/4-10 Hex Nut
9	0008177	3/4 Flatwasher
10	0008182	3/4 Lockwasher
11	0008123	3/8-16×1 1/4 HHCS
12	1218117	5/16-18 × 1 3/4 Socket Head Cap Screw - Grade 5
13	0008168	3/8-16 Whiz Nut

# FAN DRIVE P.T.O.



REF.	QTY.	PART #	TITLE	REF.	QTY.	PART #	TITLE
1	1	1215078	Fan Shaft	14	2	1283940	Mount Frame Adj. Angle
2	1	0016203	V-Pulley 3V6.0 × 4 Groove	15	1	1280177	Mount Frame Base
3	1	1206220	SDS Bushing 1½ Bore	16	1	1285065	Jackshaft 375B
4	4	1216003	1½ Bore P.B. Bearing	17	1	0017650	Shear Flange 1¼" Bore
5	1	1206218	1B 4.40D × 1½ Bore V. Pulley	18	5	0018998	Woodruff Key
6	1	1280049	Fan Pedestal	19	1	1238160	½-13 × 6 Full Thread HHCS
7	1	1210337	9 Blade 18° Fan	20	1	1236216	SF 1½ Bushing
8	1	1216229	SK Bushing 1½ Bore	21	1	0018250	Snap Ring 1¼"
9	1	1286100	4/3V - 1000 Belt	22	2	0018133	¾-16 × 2¼" Spec. Shear Bolt
10	1	1283402	Tensioning Bracket	23	2	0018149	¾" Lock Nut
11	1	0016201	Flat Idler w/Brg's Bearings	24	3	1218117	5/16 - 18 × 1¾ Socket Head Cap Screw - Grade 5
12	1	1216235	4/3V 19.0 Pulley				
13	2	1284284	Mount Frame Strut				

# 375 CUT-AWAY



For Guard Installation—  
See Page 3


REF. #	PART #	TITLE
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11	1218956	Wet Holding Hopper Ass'y. —See Page 6
12	0016600	Inner Peak Ass'y. —See Page 6
13	1201037	Inner Perf. Sheet Cross Angle
14	1280128	End Panel To Hopper Joiner Angle
15	1201028	Left Rear End Panel
16	0018993	Left Front End Panel
17	1278990	Right Rear End Panel
18	1282890	Right Front End Panel
19	1280225	Panel Above Fan
19A	1282995	375 Orifice Weld
20	0211037	For "E" Model Fan Drive Ass'y. See Page 15
21	0211044	For "B" Model Fan Drive Ass'y. See Page 16
22	1218254	Fan Guard
23	1282953	Drive Reduction Base —See Page 11
23A	1282994	P.T.O. Shaft —See Page 14
24	1212928	Portabilities For 375 Includes:
25	1210299	Pole
26	1211113	Wheel Mount & Hub Assembly
27	1252871	Wheel
28	1252872	Tires (Optional)
29	1282881	Unload Auger Cover
30	1282739	Metering System —See Page 12
31	1282974	Inner Screen Mount Weld.
32	1282951	Screen Cover
33	1252732	Control Cab. Door - Upper
34	1282888	Control Cab. Door - Lower
35	1282715	Control Cabinet Weld.
36	1281183	Control Cab. Door Latch ("T" - Handle)
37	1282876	L.P. Piping Ass'y. —See Page 9
38	1282945	Lower Inside Screen - w/o Cleanout Hole
39	1282971	Lower Inside Screen - with Cleanout Hole
40	1282965	Unit Floor Panel
41	1212952	Heat Chamber Door Frame
42	1282380	Heat Chamber Door Ass'y.
43	1217018	Right Front Floor Panel
44	1218973	Left Front Floor Panel
45	1280160	Center Front Floor Panel
46	1213356	Lower Screen Mn't. Angle
47	1216849	Inner End Screen
48	1214656	Lower Outside Screen

TITLE

PART #

REF. #

# DRYER ELECTRICAL SYSTEM POLARITY & GROUND TEST




Using a 115 Volt Neon Circuit Tester, insert as shown. It should light, proving two things:

- 1) The right hand slot is hot.
- 2) the ground hole is properly grounded.

If the Tester does not light when inserted as shown, (AND THIS WAY ONLY) have an electrician look at your service as there is something wired wrong. This is the Standard Electrical Code for all wiring. The Dryer Electrical System must be properly polarized for the Fenwal Ignition System.

## NOTE

If an extension cord is used, it MUST be a Three Wire Cord with a Three Prong Plug and a Three Hole Socket wired to the above code.



(Above) The Three Prong Fused Male Plug Pig Tail as it comes out of the Dryer Control Cabinet.

## LUBRICATION

All bearings on the unload auger and the speed reduction assembly are pre-lubricated and require no further attention. The bearings on the fan shafts of the dryer should be lubricated with regular gun grease every 100 hours of operation. CAUTION: DO NOT OVER GREASE. Excess greasing blows out seals. All other parts - ratchets, ratchet drive and chains, should be oiled with number 10 oil daily. Variable Speed Pulley, PTO Jackshaft bearings, and the PTO shaft and U-Joints should also be lubricated about every 100 hours of operation. At the end of your drying season, grease and oil all parts to prevent rust.

CARE SHOULD BE TAKEN TO AVOID GETTING OIL INTO THE RATCHET PAWL SOLENOIDS OR ON BELTS.

# IGNITION

## OPERATION

Upon a call for heat, power is applied to the control board, creating the spark and powering the gas valve. Electronic timing allows the system to continue to spark and hold the gas valve open for a specified trial for ignition period (approx. 7 seconds). If a flame is not present at the end of the trial for ignition period, the system will lockout. If a flame is present, the system will continue to operate, provided the electrodes are immersed in the flame.

In the spark source, a capacitor is charged and discharged rapidly through the primary of high voltage transformer. The current to charge the capacitor also energizes the valve control circuit so that as long as this action continues, the valve will remain open. The capacitor is discharged by a solid state switch, triggered by a neon circuit.

The flame detector monitors the spark current and the flame conductance to ground. If the spark of the flame is not present, feedback to the spark source removes power from the valve control circuit.

## LOCATION OF ELECTRODE TIP

The electrode assembly should be located so that the tips are inside the flame envelope and about 1/2 inch above the base of the flame. **IMPORTANT:** Ceramic insulator should not be within or close to the flame pattern. Study the illustration before positioning the electrodes.

**NOTE:** Electrode assemblies are precision components and should not be adjusted or disassembled. Electrodes should have a gap spacing of 0.125 (+ or -) 0.032". If this spacing is not correct, return the electrode assembly to the factory for replacement. Electrodes within their ceramic casing are **NOT** field adjustable. Adjust only the electrode mounting bracket. **WARNING: HIGH VOLTAGE.**

## SAFETY CHECKS




1. Manually shut off the gas supply and apply power to the control board. The system shall lockout after the trial for ignition period. Check that there is no voltage output between terminals B and V2 using a suitable voltmeter or neon tester.
2. Manually open the gas valve and apply power to the control unit. The system shall lockout after the trial for ignition period and there shall be no voltage between terminals B and V2 under the following conditions:
  - (1) The low voltage electrode is shorted to the ground.
  - (2) The high voltage electrode is shorted to the ground.The electrodes are shorted together.

## NOTE

Recycle system before each test.

## REPAIRS

The Ignition System is not field repairable. Faulty units should be returned to the factory for repair or replacement.





# TROUBLE SHOOTING


PROBLEM	SOME POSSIBLE CAUSES AND SOLUTIONS	PROBLEM	SOME POSSIBLE CAUSES AND SOLUTIONS
1. Lights do not work.	(a) No electricity. Light bulbs burned out. (b) Fuse blown. (c) Broken or loose wire.	5. Heat shuts off	(a) Dryer has run low on grain. (b) Modulating Valve faulty. (c) High Limit Control tripped out. (d) Solenoid faulty. (e) Out of gas. (f) Faulty or broken electrodes. (g) Machine not grounded.
2. High Limit Light does not work.	(a) Light bulb burned out. (b) High Limit tripped out. (Reset by pushing Red Button.) (c) Switch itself burned out. (Replace)	6. Not enough heat.	(a) Valves from gas supply are not fully open. (b) Increase pressure at pressure regulator. (On LP units, this is set at factory for approximately 7 - 8 pounds. However, to increase gas flow on LP units, turn adjusting screw in.) (c) Burner partially plugged. Remove and clean. (d) Hand valve not fully open. (e) Adjust Modulating Valve.
3. Air Pressure Switch not functioning.	(a) Dryer must be full of grain to operate. If dryer runs out of grain, the air will escape freely and loss of air pressure causes air pressure switch to open circuit. (b) Air tube from pressure switch into dryer may be filled with chaff. (Clean) (c) Adjust setting for less pressure. To close circuits, turn adjusting screw counter clockwise. CAUTION: DO NOT adjust to point that lights will stay on when fans are not running.	7. Gas Lines frosting up.	(a) When first starting burner, open the Main Hand Valve only partially until the unit becomes warm. (b) Gas valve on tank not completely open. (c) Dirty strainer-clean. (d) Check gas line for leaks. (e) On LP machine, vaporizer not in flame enough.
4. If flame does not light. (Fenwal Ignition)	(a) Electrodes not positioned in flame properly. (b) Electric Power not on. (c) Polarity of 115 Volts coming to dryer reversed or 15 amp fuse in plug or in control cabinet blown. (d) Machine not grounded. (e) Gas not on. Modulating valve not open far enough. (f) Gas solenoid not opening. (Faulty or loose wire). (g) High Limit Control (reset) tripped out. (h) Air Pressure Switch not functioning. (i) Broken wire from ignition board to electrodes. (j) Ignition board faulty--replace only. (k) Push reset button on ignition board.	8. Automatic Moisture Control does not work	(a) Switch in dial control is faulty or there is a loose or broken wire to the dial control. Check and make replacement. IN THE MEANTIME, OPERATE ON MANUAL. (b) Loose or broken wire at toggle switch, ratchet solenoid, or in rubber cord. (c) Switch or solenoid burned or shorted out. (d) Dial set too high.







# WIRING DIAGRAM 375 EM 3 PHASE STANDARD & CANADIAN CONTROLS



# 375 ALL HEAT CONVERSION

It is possible to operate your Model 375 Dryer as "all-heat" for use with "combination drying" or "dryeration" system. These systems save fuel and energy and produce even finer quality grain.


**NOTE:** "All Heat Conversion Kits" were shipped with all dryers starting w/SN 34284. To convert dryers below S/N 34284 to all heat, order LP or NAT Gas Conversion Kit below.

To convert the machine, install Kit 1279062 - L.P., 1279063 - NAT. consisting of:



- 3 - 1211241 Burner Unit Weld.
- 4 - 1210316 Ignition Tube Weld.
- 4 - 1214468 Burner Locator Strips and either:
  - 3 - 1215987 Burner Gas Lead Tubes for LP Gas or,
  - 3 - 1235999 Burner Gas Lead Tubes for Nat. Gas

Then follow these steps:

1. Remove the center front floor panel, item 16, page 10.
2. Remove the three  $\frac{3}{8}$ " pipe plugs from the bottom three holes of the burner head, item 11, page 10.
3. Install the three new burner units and gas lead tubes in the same manner that the five existing burner units are mounted.
4. Install the burner locator strips and ignition tube weldments between each burner unit making sure that the ignition tube ends are fitted tightly into the corners of the flanges of the burner units.
5. Be sure that the small spot of weld on the gas lead tubes is facing the rear of the dryer.



## Electrical Components

Starting with S/N 46799 - The reference numbers in this list are shown in the  or  symbols on the wiring diagrams.

Ref.	Part No.	Description	Ref.	Part No.	Description
1	120 6800	Mercury Switch		128 7001	1¼" Solenoid Valve in Gas
2	121 6849	Air Pressure Switch			Manifold (All USA & Canadian
3	121 7018	High Limit Switch			670 & 970, & USA 675
4	121 6925	115V Ignition Board (Incl. Ref. 8)			thru 1195)
5	123 6887	Differential Air Pressure Switch (Canadian Dryers Only)			<b>115V Natural Gas Solenoid Valves</b>
6		<b>Terminal Track Ass'y. (Incl. cages &amp; end locks)</b>		128 7001	1¼" Solenoid Valve in Gas
	127 1020	For Two Burner Control Cabinet			Manifold (All USA & Canadian
	128 1354	For Three Burner Control Cabinet			375 thru 1195)
	128 1402	For Model 375 (12V)			<b>12V Solenoid Valves</b>
	128 1429	For Model 375 (115V)		123 6890	½" Solenoid Valve
		<b>Terminal Track &amp; End Locks</b>		121 7025	¾" Solenoid Valve
	121 5200	Track - 1⅞" x 6½"	10	128 6916	6 Amp. Fuse (NON-6)
	203 5200	Track - 1⅞" x 4½"		128 6967	10 Amp. Fuse (NON-10)
	121 6818	End Lock Ass'y.		128 6852	15 Amp. Fuse (NON-15)
		<b>Cage Assemblies</b>		121 6970	15 Amp. Fuse (FRN 15)
	121 6824	3 Way - Yellow		120 6837	20 Amp. Fuse (FRN 20)
	121 6830	6 Way - Black		128 6936	25 Amp. Fuse (FRN 25)
	121 6831	6 Way - Yellow	11	128 6851	Fuse Holder
	121 6839	6 Way - White	12	128 6845	Stop Button (Red)
7	128 6995	Electrode (Above S/N 43656)	13	128 6844	Start Button (Black)
	121 6926	Electrode (Below S/N 43657)	14	124 6848	8 Amp. Circuit Breaker (SCR Drive)
	124 6883	Electrode (Below S/N 43657)	15	121 6808	125V Indicator Lamp Ass'y.
8	122 6814	Ignition Reset (0.1 Amp.)		122 6810	125V Indicator Lamp
9		<b>115V LP Gas Solenoid Valves</b>		122 6800	Indicator Lamp Lens (Clear)
	125 7082	½" Solenoid Valve in LP Liquid Line (All USA and Canadian 375 thru 1195)	16	121 6815	SPST ON-OFF Toggle Switch
	121 7002	¾" Solenoid Valve in Gas Manifold (All USA & Canadian 375 & 665, & Canadian 675 thru 1195)	17	120 6827	Momentary Contact Toggle Switch
			18	121 6807	DPDT ON-OFF-ON Toggle Switch
			19	124 6890	.2 to 8 Minute Adj. Timer w/Brkt.
				127 6802	60 Second Timer w/Brkt.
				127 6821	2 Minute Timer w/Brkt.
				128 6960	3 Minute Timer w/Brkt.
				128 6847	5 Minute Timer w/Brkt.
			20	124 6841	Light Bulb Socket

Continued on next page

Ref.	Part No.	Description	Ref.	Part No.	Description
21	124 6850	25W Rough Service Bulb	48	127 6855	Transformer-208V (750VA)
	124 6842	50W Rough Service Bulb		127 6827	Transformer-230/460V (750VA)
22	021 6810	Relay Socket		127 6829	Transformer-230/460/575V (750VA)
23	021 6809	Relay		128 6897	Transformer-230/460/575V (2000VA)
24	021 6816	Timer Socket		128 6856	Transformer-230/460V (3000VA)
25	021 6815	60 Minute Adjustable Timer		124 6845	Transformer-230/460/575V (3000VA)
26	121 6963	Dual Range Thermoswitch	49	124 6891	Ten Turn Potentiometer
27	121 6851	Single Range Thermoswitch	50	124 6892	Multi-Dial
28	121 6856	115V Ratchet Solenoid	51	124 6893	Thermistor (Zytron)
29	124 6836	SCR Board (Morse)	52	124 6894	Potentiometer (Zytron)
	124 6874	SCR Board (Dart)	53	124 6889	Temperature Controller (Zytron)
30	124 6838	Potentiometer	54	121 6806	SPDT ON-OFF-ON Toggle Switch
31	124 6839	Potentiometer Knob	55	124 6895	3PDT ON-OFF-ON Toggle Switch
32	124 6837	1/3 HP DC Motor	56	124 6896	30 Minute Delay
33	128 6957	Splitter Block	57	121 6805	10 Amp. GLH Fuse
34	124 6831	10 Second, Timer w/Brkt.	71	121 6825	Temperature Read-Out Meter
35	124 6872	Flame Sensing Probe		122 6821	Rebuilt Temperature Read-Out Meter (8 position scale)
36	127 6812	Resistor (10W - 3K OHM)		122 6822	Rebuilt Temperature Read-Out Meter (6 position scale)
37	121 6806	SPDT ON-OFF-ON Toggle Switch	72	121 6828	Adjustable High Limit
38	121 6803	Male 3 Wire Plug w/o 10 Amp. Fuse	73	121 6965	Cold Grain Warning Bell
39	128 6992	Bin Level Indicator (Inside Mt.)	74	125 6907	115V AC Control Relay
	128 7003	Bin Level Indicator (Outside Mt.)	75	125 6911	115V Starter Relay
40	128 6860	12V Indicator Lamp Ass'y.	76	121 6827	Thermistor Probe (3")
	121 6978	12V Indicator Lamp	77	123 7025	Vent Solenoid Valve - Nat. Gas
	122 6800	Indicator Lamp Lens (Clear)	78	123 7017	Manual Reset Shut-Off Valve (3")
41	125 6883	12V Ratchet Solenoid		123 7020	Manual Reset Shut-Off Valve (1")
42	121 6990	12V Relay	79	123 7018	Pressure Switch - Nat. Gas
43	121 6962	12V Ignition Board		123 7021	Pressure Switch - LP Gas
44	121 6956	Linear Limit Control (138")	80	123 7019	Transducer - Nat. Gas
	128 6850	Linear Limit Control (92")		123 7022	Transducer - LP Gas
45	123 6854	Light Fixture Cpt.	81	021 6800	Mercury Switch (2 Way)
	123 6898	Red Glass Globe			
	125 6823	100W Rough Service Bulb			
46	123 6868	Horn (Alarm Buzzer)			
47	- - - - -	Magnetic Starters (See Bulletin D-8-86)			







## **INSTRUCTIONS FOR ORDERING PARTS**

To eliminate error and speed delivery:


1. Write your **NAME** and **ADDRESS** on your order **PLAINLY**.
2. Explain **WHERE** and **HOW** to make shipment.
3. **GIVE MODEL NAME, NUMBER, and SERIAL NUMBER** that is stamped on the **NAME PLATE** of your product.
4. Order from your **PARTS LIST** as this is the **ONLY** means we have of identifying the parts you need. Order by **QUANTITY DESIRED**, the **PART NUMBER**, and the description **OF PART**.
5. Order your parts from your **LOCAL M-C DEALER** or **DISTRIBUTOR**.
6. **INSPECT ALL SHIPMENTS ON RECEIPT**. If any parts are damaged or missing, file a claim with the carrier before accepting.
7. Do not return parts to Mathews Company without a "Return Goods Authorization" from the factory. A list of all returned parts, a letter of explanation, and your name and address should be included with the shipment. **TRANSPORTATION CHARGES MUST BE PREPAID**.



## **OWNERS NOTICE**

**TO INSURE WARRANTY CLAIMS, BE CERTAIN TO FILL  
OUT AND MAIL WARRANTY CARD WITHIN 30 DAYS.**

**NOTE:** The Company reserves the right to incorporate any changes in design without obligation to make these changes on units previously sold.



*Iron Horse Quality*