


CONTINUOUS GRAIN DRYER

ASSEMBLY-OPERATION AND MAINTENANCE INSTRUCTIONS



MODELS
375 EM
375 B115
375 B12


DM1078

MATHEWS COMPANY

P.O. BOX 70, 500 INDUSTRIAL AVE.
CRYSTAL LAKE ILL., 60014 · U.S.A.

TABLE OF CONTENTS

	Page No.
Set-Up Instructions	2 & 3
Safety Guards	3
Moisture Control and Air Pressure Switch	4
Control Cabinet - Indicator Lights and Control Switches	4
Wet Holding Hopper and Peak Assembly - Set-Up Instructions	5
Wet Holding Hopper Assembly	6
Peak Assembly	6
Operating Instructions	7 & 8
LP Gas Manifold Assembly	9
LP Gas Piping Diagram	9
Burner Assembly	10
Drive Reduction Base	11
Ratchet Assembly	11
Metering System	12
Variable Speed Mount and Crank	13
Variable Speed Pulley	13
Tractor P.T.O. Shaft	14
Load Switch (optional)	14
Electric Fan Drive	15
P.T.O. Fan Drive	16
Dryer Cut-Away	17
Dryer Electrical System Polarity & Ground Check	18
Lubrication	18
Ignition - Electrode Positioning	19
Trouble-Shooting	20
Wiring Diagram - B-12 - Standard & Canadian Controls	21
Wiring Diagram - B-115 - Standard & Canadian Controls	22
Wiring Diagram - EM Single Phase - Standard & Canadian Controls	23
Wiring Diagram - EM 3 Phase - Standard & Canadian Controls	24
All-Heat Conversion	25
Parts Ordering and Owners Notice	26



DANGER

1. KEEP ALL GUARDS IN PLACE.
2. STOP MOTORS OR ENGINE BEFORE ADJUSTING, LUBRICATING, CLEANING, OR UNCLOGGING MACHINES, UNLESS OTHERWISE SPECIFICALLY RECOMMENDED IN THE "OPERATOR'S MANUAL".
3. WAIT FOR ALL MOVEMENT TO STOP BEFORE SERVICING THE MACHINE.
4. KEEP HANDS, FEET AND CLOTHING AWAY FROM POWER DRIVEN PARTS.
5. KEEP OFF EQUIPMENT UNLESS SEAT OR PLATFORM FOR OPERATION AND OBSERVATION IS PROVIDED.
6. KEEP ALL OTHERS OFF.
7. USE FLASHING WARNING LIGHTS WHEN OPERATING ON HIGHWAYS EXCEPT WHEN PROHIBITED BY LAW.
8. MAKE CERTAIN EVERYONE IS CLEAR OF MACHINE BEFORE STARTING OPERATION.

SET-UP INSTRUCTIONS

NOTE: The end of the dryer with the fan is considered the front. Left and Right is determined by standing behind the dryer and looking at the rear door.

1. Place dryer in a level position.

A. Permanent installation:

Place dryer on concrete slab or piers with planks between concrete and skids. Anchor dryer down to prevent blow over.

B. For Portable or Temporary installation:

Place planks under full length of skids. Remove wheels or dig holes for wheels. Full weight of dryer must rest on the dryer skids. Dryer should be anchored down to prevent blow over.

2. Install Variable Speed Crank Assembly - see page 13.

3. Install lower ladder, set up Wet Holding Hopper and install Peak - see pages 5 & 6.

4. Install all safety guards. See page 3.

5. Connect electrical power to dryer. For all electrical connections, refer to the proper wiring diagrams in rear of this manual.

A. For "E" Model Single Phase dryers connect customer supplied fused power lines to the top lugs of the magnetic starter in the starter box and connect the ground line to the ground lug.

NOTE: For Canadian Control Models be sure to connect the Neutral line to the Neutral lug.

B. For "E" Model Three Phase dryers connect customer supplied fused power lines to the top lugs of the magnetic starter in the starter box. Connect the ground line to the ground lug. Then connect the 115V control power line onto one of the 115V legs of the three phase power coming into the lugs at the top of the magnetic starter.

NOTE: Damage to the controls can result if the 115V control line is connected to the 230V leg of the three phase power.

C. For B115 Models connect grounded, three-line 115V power line to the three-pronged, fused, male plug on the outside of the control cabinet. Be sure that polarity of the plug and the supply cord are the same. See polarity check, page 18.

D. For B12 Models connect battery cables from control cabinet direct to the tractor battery terminals. Brown to negative (-) post, Red to positive (+) post. The connections must be this way or blown fuses and failures in the ignition system will result.

(Continued on page 3)


SET-UP INSTRUCTIONS...Cont.

6. On "B" models, remove snap ring from Jackshaft, item 21, page 16, and install PTO shaft and connect to dryer shear flange using one 3/8-16 x 2 1/4 special shear bolt, part number 0018133, supplied with the dryer. DO NOT use hardened bolts or standard long thread bolts. Re-install the snap ring on Jackshaft.
7. Position tractor so there is only a small angle on the universal joints of the PTO shaft. Connect PTO to tractor power take off. BE SURE that the guard over the universal joint and shear flange at dryer and the tractor guard over the power take off are in place.
8. Connect gas supply to machine.
 - A. L.P. Gas - Advise your L.P. Gas supplier that the dryer takes liquid from the tanks (not vapor). When the gas system is connected to the dryer, be sure an Excess Flow Valve is installed at the tank, preferably the one furnished with the dryer as it will shut off quicker (in case of line breakage) than those normally furnished by the gas supplier. In any case NEVER have two Excess Flow Valves on the same line.

Use a minimum of 1/2" ID gas line between tank and dryer. For distances over 100 feet use a 3/4" ID diameter line. Connect the gas line from the tank to the short flexible hose on the dryer.

- B. Natural Gas - A minimum of 5 lbs. of operating pressure is required on all models. Use minimum two-inch line from Natural Gas regulator to dryer. Use reducing bushing to 1 1/4" just before connecting to pipe outside dryer control cabinet.


GUARDS FOR ELECTRIC AND P.T.O. MODELS




REF. #	PART #	ITEM
1.	1284866	Front Guard Mount Angle
2.	1284887	Front Guard Top
3.	1280083	P.T.O. Shear Flange Guard
4.	1285761	Front Guard Screen
4.-A	1284890	Front Guard Hole Cover
5.	1218956	Fan Guard
6.	1218255	5/16 - 18 x 1 1/2" J-Bolt
7.	0008176	5/16 Flat Washer
8.	0008166	5/16 - 18 Wing Nut

SAFETY CONTROLS

REF. NO.	PART NO.	DESCRIPTION
1	1216851	Thermoswitch (Moisture Control)
2	1210031	Thermoswitch Shield Weldment
3	0008184	#8 x 1/2 Sheet Metal Screw
4	1217018	High Limit Switch
5	1216849	Air Pressure Switch
6	1210169	Air Pressure Tube Weld Wire Filter Retainer
8	1215716	Air Pressure Tube Filter
9	1280160	Air Pressure Switch Cover
10	1210081	High Limit Shield
11	1218000	1/4" Pipe Lock Nut



CONTROL CABINET — INDICATOR LIGHTS AND CONTROL SWITCHES



Item	Part #	Description
1, 2, 3, 4	1216808	115V Lamp Ass'y Complete
	1286860	12V Lamp Ass'y Complete
	1216977	Lamp Cover, Clear Lens Only
	1226810	115V Light Bulb Only
	1216978	12V Light Bulb Only
5	1216815	Ignition Toggle Switch
6	1216807	Moisture Control Toggle Switch
7	1216806	Load Toggle Switch (Included with optional load switch kit 1239076)

The Control Cabinet consists of temperature and safety controls. There are four lights wired in series with controls to indicate operation.

Indicator Lights:

- No. 1 Lights when electric power is on.
- No. 2 Lights when fan is running and dryer is full of grain (air pressure completes circuit to ignition switch).
- No. 3 Lights when high limit control circuit is closed.
- No. 4 Lights when Fenwal Ignition Switch is turned on, electrodes are firing, and the gas solenoid is open.

WET HOLDING HOPPER & PEAK ASSEMBLY SET-UP INSTRUCTIONS (REFER TO ILLUSTRATIONS PAGE 6)

WET HOLDING HOPPER

The hopper is shipped folded down and must be assembled at the installation.

NOTE: Inspect and remove all foreign material from feed rolls and augers. Avoid dropping nuts, bolts, parts, etc. down the grain columns. If anything is accidentally dropped, it must be removed before filling dryer.

Use 5/16-18 x 3/4" bolts and 5/16-18 Whiz Nuts through steps 1 and 2.

STEP 1: Fold up the front and rear Hopper Panel Assemblies and their two adjoining side Hopper Panel Assemblies. Bolt them together along the corner seams. Put a plank on top of heat chamber cross angles to walk on. Avoid standing on grain column tie straps.

STEP 2: Bolt the bottom flanges of all the Hopper Panel Assemblies to the Galvanized Angles, to which the hinges are fastened.

NOTE: Place a 3/8 flat washer between the head of the bolt and Hopper Panel.

STEP 3: Fasten Ladder Mounting Brackets to right rear Hopper Panel Assembly using 5/16-18 x 3/4" bolts and 5/16-18 Whiz Nuts.

STEP 4: Bolt Ladder to Ladder Mounting Brackets using 5/16-18 x 3/4" bolts and 5/16-18 Whiz Nuts.

PEAK ASSEMBLY

NOTE: Leave all bolts loose (finger tight) until Step 5.

STEP 1: Beginning at front of dryer, install two Peak Panels, Ref. 1, to the top of the inner perforated screens, one on each side. Use 5/16-18 x 3/4" Truss Head Screws and 5/16-18 Whiz Nuts. The head of screw should be on the inside of grain column. DO NOT bolt the peak panels to the End Hopper Panel Assemblies until Step 5.

STEP 2: Bolt a Hopper Cap, Ref. 2, onto these first two Peak Panels using 5/16-18 x 3/4" Truss Head Screws and 5/16-18 Whiz Nuts. The Whiz Nut must be inside the air chamber.

STEP 3: After two sets of Hopper Peak Panels are in place, install 3 1/4" Inner Hopper Cross Ties, Ref. 4. Install 2 9/4" Inner Hopper Support Angles, Ref. 5, at the center hole along the Hopper Peak Panel seams. Use 5/16-18 x 1 1/4" bolts and 5/16-18 Whiz Nuts. The other end of the Inner Hopper Support Angles fasten at the third bolt holes down from the top along the vertical seam of the Inner Perforated Screens on each side. Remove the 5/16-18 x 1/2" bolt, and replace with 5/16-18 x 3/4" bolts, to hold the Support Angle. These angles should be installed at each seam of the Hopper Peak Panels.


STEP 4: Continue along the dryer installing sets of two Peak Panels (one on each side), fastening to Inner perforated screens, Hopper Cap, and to each other using 5/16-18 x 3/4" bolts and 5/16-18 Whiz Nuts. Install Inner Hopper Support Angles and Cross Ties after each set of Peak Panels.

STEP 5: Install the hopper seal angles, Ref. 3, at each end of the Peak. Then bolt the Hopper Peak panels to the Hopper End Panel Assemblies using 5/16-18 x 3/4" bolts and 5/16-18 Whiz Nuts. The head of the bolts should be on the outside of the Hopper.

TIGHTEN ALL BOLTS AT THIS POINT.


The Hopper and Peak are now complete.

375 WET HOLDING HOPPER ASSEMBLY



REF. #	PART #	DESCRIPTION	REF. #	PART #	DESCRIPTION
1	1282052	End Hopper Flange Stiffener	9	0008119	3/8-16 x 3/4 HHCS
2	1282051	Side Hopper Flange Stiffener	10	0008168	3/8-16 Whiz Nut
3	1284824	Hopper Side Panel	11	0008106	5/16-18 x 3/4 HHCS
4	1284822	Hopper Ind Panel - Upper	12	0008169	5/16-18 Whiz Nut
5	1284823	Hopper End Panel - Lower	13	0008103	5/16-18 x 1/2 Truss Head
6	1280162	4 Foot Ladder	14	1282660	Ladder Mount Bracket
7	1282661	Ladder Mounting Angle	15	1284808	Load Switch Hopper Panel
8	1288957	Hopper Hinge	16	1282996	Cover Plate

PEAK ASSEMBLY



REF. #	PART #	DESCRIPTION
1	1282891	Perf. Peak Panel
	1272834	Solid Peak Panel
2	1282991	Hopper Cap
3	1282908	Hopper Seal Angle
4	1282012	Horizontal Peak Angle 31 1/4" Long
5	1282003	Vertical Peak Angle 29 1/4" Long

OPERATING INSTRUCTIONS

1. Be sure all electrical power and gas valves are turned off.
 2. Be sure there is adequate clearance between fan and fan housing and between the fan and the burner.
 3. Before proceeding make sure all safety guards are in place, see page 3.
 4. Be sure all switches on the control cabinet are in the "OFF" position.
 5. Turn on electrical power to the dryer. On B115 Models plug in the three-pronged plug outside the control cabinet. On B-12 Models connect the battery. REMEMBER: Red to Positive (+) terminal and Brown to Negative (-) terminal. The "Power On" and "High Limit" lights should glow. Trouble: See page 20.
 6. Be sure that the adjusting screws of the pressure regulator and the modulating valve are not turned all the way in. This could result in damage to the valves from excessive pressure or may cause difficulty in starting the burner.
 7. Fill the dryer with grain. If the dryer is equipped with the optional load switch kit, a toggle switch is located on the control cabinet marked "Level Auger". This switch will activate a 115V coil in a standard magnetic starter used to start and stop the electric motor on the grain filling conveyor. (Magnetic starter not included in load switch kit.)
 - A. AUTOMATICALLY OPERATED FILLING: When the toggle switch is flipped to the "Automatic" position the filling conveyor should run until the dryer is full of grain and then automatically shut off.
 - B. MANUALLY OPERATED FILLING: When the toggle switch is flipped to the "Manual" position the filling conveyor will run continuously. NOTE: Care must be taken not to overflow the top of the dryer. The "Manual" operation is more or less a "stand-by" system in the event of damage to the automatic switch assembly in the hopper.
 8. Slowly open the gas supply line. On LP dryers the flip valve--Item 18, page 9, should also be opened slowly. Check thoroughly for gas leaks--both inside and outside the dryer.
 9. Start the fan. If dryer is full, the "Air Pressure Switch" light should come on. Trouble: see page 20. At this time the Air Pressure Switch should be adjusted. See top of page 4, Item #5. Remove the red plastic cap to expose the adjusting screw. Turn screw into the unit until the Air Pressure Switch light goes out. Then back the screw out until the light comes back on and then about 1/2 turn further out. This should assure that the burner will go out if the dryer runs low on grain or the fan loses RPM.
- ### STARTING THE BURNER
10. INITIAL START UP OF A NEW DRYER. Partially open hand valve--Item 20, page 9.

NOTE: The hand valve is shown fully closed on page 9. Flip on the Ignition Switch. The main Heat Valve Light should glow. turn Pressure Regulator Adjusting Screw in or out until 5-7 pounds of pressure is reached on the dial gauge. Adjust the pressure regulator only when the hand valve is open and the Main Heat Valve light is glowing. If the burner does not ignite in 6-7 seconds, turn the Ignition Switch to "OFF", wait one minute and try again.
- ### SETTING TEMPERATURE
11. The temperature is regulated by the Modulating Valve. To increase the temperature, turn the handle in. To reduce the temperature, turn the handle out. (See Drying Chart on Page 8 for suggested operating temperatures of various grains.)
 12. The cooling section of the dryer will have wet grain in it, and will not be dried on the first run. This grain will have to be recycled back into the heating section.
 13. Make sure Automatic Moisture Control Switch is in "OFF" position. In order to dry all the grain in the upper section, it will require approximately one hour of continuous heat to dry the first load from 30% to 15% moisture and proportionately less for moistures under 30%.
 14. After approximately one hour of drying on the first load, turn Moisture Control Switch to "Manual" position. This will engage Ratchet Solenoids and begin unloading the grain. When grain in cooling section has moved through and dried grain begins to auger out, after about 45 minutes, test it for moisture content. If moisture content is too high, slow the unloading down. If moisture content is too low, speed unloading up.

OPERATING INSTRUCTIONS....Cont.

15. To change the speed of unloading, a combination of two adjustments is available.
 (A) By turning Variable Crank arm **CLOCKWISE** to **SPEED UNLOADING** and **COUNTER CLOCKWISE** TO **SLOW UNLOADING**. This is normally used for fine adjustment.

CAUTION:

Do not put extreme pressure on belts. **ADJUST VARIABLE SPEED PULLEY ONLY WHEN MACHINE IS OPERATING.**

- (B) The Feed Rolls can be adjusted independently of the auger by sliding the "Connecting Arm" along the slotted bracket on the Eccentric Sprocket. The Eccentric Sprocket is located in the lower part of the speed reduction assembly on the drive end of the dryer. Moving the Connecting Arm **TOWARDS THE CENTER** of the sprocket will **DECREASE** the stroke and **SLOW** down the **UNLOADING** of the Feed Rolls. Moving it **AWAY** from the **CENTER** of the sprocket will **INCREASE** the stroke and **SPEED UP** the **UNLOADING** of the feed rolls. **CAUTION: NEVER MAKE ADJUSTMENT ON SPROCKET UNTIL IT HAS COME TO A COMPLETE STOP.**

Normal factory setting is for two teeth. When removing more than 10 points of moisture, it may require slowing down to one tooth. When removing less than 10 points of moisture, it may require increasing to three or more teeth.

NOTE: Be careful not to discharge more grain out of the Feed Rolls than the Auger can carry away!

16. After your dryer is operating properly and is discharging grain at the desired moisture content for one hour, switch to "Automatic Moisture Control". Flip the "Moisture Control Switch" to Automatic position, then set the Moisture Control on each side of the dryer by turning the indicator knob to the point that will just maintain Feed Roll operation. Most likely each moisture control will have a slightly different setting. Normally they will be set within the limits shown in the following chart.

APPROXIMATE SETTING FOR SHELLED CORN AND MOST SMALL GRAINS

Thermometer Setting	Set Control Dial At	To Get— Percent Moisture
140°	3.5	13-14%
180°	4.0	14-15%
180°	4.5	13-15%
180°	5.0	12-13%

If the moisture content of the grain coming out of the dryer starts to increase, increase the setting of the control one mark at a time until the correct moisture content is reached. Allow ample time between adjustments for machine to correct itself, suggested time to be 1 hour.

Adjust the unloading mechanism to correspond with the rate of feeding of the grain by the automatic control. These adjustments will only be slight if you have had your dryer operating correctly before switching it to "Automatic Moisture Control."

The speed of the Variable Drive should be fast enough to cause the Automatic Moisture Controls to operate intermittently but having the Feed Rolls engaged 85% to 90% of the time. If the unloading mechanism is working too slow, the Moisture Control Solenoids will operate constantly and the grain will come out drier than desired.

16. If you have followed the instructions carefully your dryer will operate continuously without watching or adjusting as long as you keep it full of grain.

17. **SUGGESTED DRYING CHART**

Types of Grain	Drying Temp.
Corn	180°F to 200°F
Grain Sorghum	160°F to 180°F
Wheat or Oats	160°F to 170°F
Soybeans or Barley	130°F to 140°F

SHUT-OFFS AND RESTARTS


When stopping the dryer, shut off the heat and let the grain cool. (Turn off Ignition Switch and run fan for 15 to 20 minutes with cool air.) Shut off Hand Valve, Flip Valve, and Tank Valve on LP models.

To re-start, open Tank Valve, Flip Valve, turn on Ignition Switch, and gradually open Hand Valve. Remember to open Hand Valve gradually to prevent freeze ups.

FINAL SHUT DOWN OF DRYER

Your dryer is a continuous flow dryer, and it is necessary to hold the grain in the dryer for a period of time when finishing a crop or at the end of the season. Ratchet Pawls should be disengaged by flipping Moisture Control Switch to OFF. This will give the grain remaining in the dryer time to become dried. Allow about 30 minutes of drying time for high moisture grain (30%) and proportionately less for drier grain. Then turn Moisture Control Switch to Manual position for emptying. At end of season, lubricate all moving parts and remove the unloading auger pan underneath the dryer.


LP GAS MANIFOLD




REF #	PART #	DESCRIPTION
1	1288019	3/4" Union Elbow Ex. Hvy.
2	1218005	3/4" x 1 1/2" Nipple Ex. Hvy.
3	1218060	3/4" Strainer
4	1288006	3/4" x 6" Nipple Ex. Hvy.
5	1217006	3/4" REGO Regulator
6	1218067	3/4" x 1 1/2" Nipple Std.
7	1218074	3/4" 90° Elbow Std.
8	1278008	3/4" x 6" Nipple Std.
9	1288035	3/4" Side Outlet Tee
10	1218030	3/4" to 1/4" Reducing Bushing
11	1218039	1/4" 90° Street Elbow
12	1207002	Pressure Gauge
13	1218007	3/4" x 2" Nipple Std.
14	1218050	3/4" Cap Std.
15	1218008	3/4" x 3" Nipple Std.
16	1217002	3/4" Gas Solenoid Valve for 115V
16A	1217025	3/4" Gas Solenoid Valve for 12V
17	1218029	3/4" to 1/2" Reducing Bushing
18	1218013	1/2" x Close Nipple
19	1217012	1/2" Modulating Valve
20	1217011	3/4" Hand Valve
21	1218007	3/4" x Close Nipple
22	1288039	3/4" Union Elbow Std.
23	1227002	Power Element 90° to 210°-"B"
24	1227001	Replacement Coil for 115V Dryers
24A	1227024	Replacement Coil for 12V Dryers

LP GAS PIPING DIAGRAM

REF. #	PART #	DESCRIPTION
1	1258064	3/4" x 19 1/2" Ex. Hvy. Nipple
2	1218027	3/4" x 90° Ex. Hvy. Elbow
3	1218083	3/4" x 9" Ex. Hvy. Nipple
4	1218072	3/4" Ex. Hvy. Union
5	1218098	3/4" x 5" Ex. Hvy. Nipple
6	1218032	3/4" to 1/2" x 90° Ex. Hvy. Red. Elbow
7	1218071	1/2" x 90° Ex. Hvy. Street Elbow
8	1210336	Vaporizer
9	1288010	1/2" Ex. Hvy. Union Elbow
10	1218041	1/2" x 16 1/2" Ex. Hvy. Nipple
11	1218036	1/2" x 90° Ex. Hvy. Elbow
12	1288036	1/2" x 28 1/2" Ex. Hvy. Nipple
13	1218035	1/2" Ex. Hvy. Tee
14	1217014	Relief Valve Adapter
15	1217013	Relief Valve
16	1218048	1/2" x 90° Std. Street Elbow
17	1208047	1/2" x 2" Ex. Hvy. Nipple
18	1217015	1/2" Liquid Line Hand Valve
19	1217005	Inlet Hose
20	1218019	3/4" x 20" Std. Nipple
21	1218074	3/4" x 90° Std. Elbow
22	1218067	3/4" x 1 1/2" Std. Nipple
23	1218028	3/4" Std. Union
24	1288038	1/2" x 18 1/2" Std. Nipple
25	1218049	3/4" x 6 1/2" Std. Nipple
26	1238049	1 1/4" to 3/4" x 90° Std. Red. Elbow




375 BURNER ASSEMBLY



REF. #	PART #	TITLE
1	1280178	Orifice Weld.
2	1210322	Burner Tube Weld.
3	1210336	Vaporizer
4	1215987	Burner Gas Lead Tube
5	1211241	Burner Unit
6	1215988	Face Plate Insert
7	1210316	Ignition Tube Weld.
8	1214867	Air Chamber Mounting Bracket
9	1212640	Electrode Mounting Bracket (2 For 12 Volt DC)
10	1216926	Electrode (2 For 12 Volt DC)
11	1215501	Burner Head
12	1210081	High Limit shield
13	1210169	Air Pressure Tube Weld.
14	1252870	Front Floor Panel - Left
15	1252871	Front Floor Panel - Right
16	1282881	Front Floor Panel - Center
17	1238065	1 1/4" x 14" -Long Pipe
18	1282027	Air Pressure Tube Brk't.
19	1214468	Burner Locater Strip
20	1215744	High Voltage Wire
21	1215742	Low Voltage Wire*
		*(For 12 Volt DC Electric System, See Page 21)
22	1215738	3" to 1 1/4" Reducing Bush.
23	1212980	Orifice Seal Plate


(NOT SHOWN)	1212882	Sensing Bulb Clip
	1212883	Sensing Bulb Bracket
	1282880	Burner Tube Baffle

375 DRIVE REDUCTION BASE ASSEMBLY




REF.	QTY.	PART #	DESCRIPTION
1	2	0008122	3/8-16 x 1" Carriage Bolts
2	1	1286121	BX54 Belt
3	1	1286213	12" O.D. 1" Bore Pulley
4	2	1216405	RC40 B16T 1" Bore Sprocket
5	1	1285026	Upper Jackshaft
6	4	0008298	1/4" x 3/4 Woodruff Key
7	8	0008123	3/8-16 x 1 1/4" HHCS
8	4	1276000	1" Pillow Block Bearing
9	1	6524000	1/4" x 1 1/4" Spacer
10	1	1285027	Lower Jackshaft
11	1	1286421	RC40 B-48T 1" Bore Sprocket
12	1	1286308	#40 x 74 Pitch Chain
13	1	0018164	1/2-13 x 2" Carriage Bolt
14	1	0008299	5/8" S.A.E. Flatwasher
15	2	0008136	1/2-13 x 1" Carriage Bolt
16	1	1281069	Eccentric Sprocket Assembly
17	2	0018257	1/2" S.A.E. Flatwasher
18	1	0008175	1/2" Standard Flatwasher
19	3	0008170	1/2-13 Whiznuts
20	1	0018111	5/16-18 Clipnut
21	1	1280239	Reduction Base Weldment
22	8	0008168	3/8-16 Whiznut

375 METERING SYSTEM




REF. #	PART #	TITLE	REF. #	PART #	TITLE
1	1280191	Feed Roll Outboard Br'g. Mount	17	1286418	Unload Auger Sprocket
2	1216022	1 1/4" Bore Wood Bearing - Complete	18	1286018	(RC - 40 - B 45 - T Sprk't.)
3	1286011	Nylon Ratchet Bushing	19	1286414	1-7/16" Pillow Block Br'g.
4	1216404	Ratchet Wheel	20	0008257	RC-40 Idler Sprocket
5	1281413	Ratchet Assembly—See Page 11	21	1284492	3/8-16 x 5 HHCS Full Thread
6	1216856	Solenoid (115V.)	22	0018136	RC-40 Take Up Brk't.
6A	1256883	Solenoid (12V.)	23	1280079	3/8-16 x 3/4 HHCS - Grd. #5
7	1281261	Transfer Arm	24	1282733	Unloading Auger
8	1282652	Ratchet Stop Dog Mount Plate	25	1281186	Unloading Auger Pan
9	1210355	Ratchet Stop Dog Mount	26	1285998	Feed Roll Ass'y. (Left & Right)
10	1210354	Ratchet Stop Dog	27	1280096	Output Shaft
11	1218162	3/8-16 x 1 5/8 HH Shoulder Bolt	28	1284712	Unload Auger Discharge
12	1281258	Base Panel Access Cover	29	0016003	Unload Auger Discharge Cover
13	1280224	Idler Bracket (Bolt-On)	30	0016004	1 1/4 Bearing w/ Collar
14	1285996	Input Shaft	31	1214438	3-Bolt 1 1/4 Br'g. Stamping
15	1281063	Feed Roll Bearing w/ Bronze Bushing	32	1280075	Feed Roll End Washer
16	1281411	Connecting Arm			U.A. Front Plate

VARIABLE SPEED MOUNT AND CRANK




REF. #	PART #	DESCRIPTION
1	1285192	Variable Speed Crank
2	1210320	Variable Speed Crank Mount Bracket
3	1218102	Roll Pin 1/4 x 1 1/2
4	0008176	3/8 Flat Washer
5	1215190	Variable Crank Nut
6	0008170	1/2-13 Whiz Nut
7	0008140	1/2-13 x 2 HHCS
8	0008199	1/8 x 1 Cotter Key
9	1281066	Adjusting Arm Ass'y.
10	1284060	Variable Speed Base
10A	1285053	Variable Speed Arm Pivot
11	1288165	1/2" Washer
12	1283444	Base Mount Bracket
13	1283445	Base Mount Bracket Support
14	1286217	Variable Speed Pulley Assembly
15	1288166	1/2-13 x 2 1/2 HHCS Grd. #5
16	0016100	B-56 Belt
17	1286105	B-63 Belt

VARIABLE SPEED PULLEY 1286217



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	1228919	Snap Ring	7	1228910	Center Sheave & Spindle Ass'y.
2	1228918	Outer Spring Cover	8	1228914	Inner Sheave & Spindle Ass'y.
3	1228906	Set Collar 1 1/2" I.D. (4404-6)	9	0008996	1/4-28 Nft. Straight Zerk
4	1228917	Spring	10	0008201	5/16-18 x 5/16 Socket Head Set Screw Knurled Cup Point
5	1228916	Inner Spring Cover			
6	1228915	Outer Sheave w/Bushing			


TRACTOR P.T.O. SHAFT




REF.	PART NO.	DESCRIPTION
1	0016600	PTO Drive Shaft
2	0026620	Tractor Half Assembly w/O.D. Yoke
3	0026627	Male Shaft & Yoke Weldment
4	0026628	Universal Joint Repair Kit
5	0027651	Quick Detachable Yoke Assembly
6	0026629	Safety Lock Pin & Spring Kit
7	0026624	Female Guard Tube
8	0026626	Bell Shield
9	0026625	External Snap Ring
10	0026606	3/8" Diameter Ball
11	0026621	Complete Machine Half PTO w/Shear Flange
12	0026622	Female Shaft & Yoke Weld- ment
13	0027652	Flange Yoke 1-1/4 Bore
14	0026623	Male Guard Tube

LOAD SWITCH 1201011 USED IN KIT 1239076

REF. NO.	PART NO.	DESCRIPTION
1	1272832	Load Switch Mn't. Plate
2	1208996	Diaphragm
3	1205200	Merc. Switch Brk't. Washer
4	1202946	Mount Bracket
5	1206801	Merc. Switch Clip
6	1206800	Mercury Switch
7	0008157	6-32 Hex Nut
8	1254486	Level Switch Weight
9	1205201	Level Switch Housing
10	1206802	Terminal Strip
11	0008188	8-32 Hex Nut
12	0008210	1/4-20 Hex Nut
13	0008184	#8 x 1/2 Self Drilling Sheet Metal Screw
14	0008192	8-32 x 3/4 Screw
15	0008105	5/16 - 18 x 1/2 HHCS
16	0008169	5/16 - 18 Whiz Nut
17	0008212	1/4 x 20 x 1/2 R.D. Head
18	1216920	18/2 Dynaprene Cable
19	1256901	Strain Relief Bushing
20	1207981	L.A. Control Switch Cover
21	---	#6 Lockwasher
22	0008280	6-32 x 3/8 R.D. Head




FAN DRIVE ELECTRIC



REF. #	PART #	DESCRIPTION
1	1284284	Mount Frame Strut
2	1210258	Motor Mount Base Weldment
3	1210337	9 Blade - 18° Fan
4	1280167	Stand Off Motor Mount Weldment
5	1216924	10 HP Motor 1 Ø 55 Amp
6	1216233	V-Pulley 4" O.D. × 1 3/8 Bore
7	1216239	SK Bushing 1 3/8 Bore
8	0008165	3/4-10 Hex Nut
9	0008177	3/4 Flatwasher
10	0008182	3/4 Lockwasher
11	0008123	3/8-16×1 1/4 HHCS
12	1218117	5/16-18 × 1 3/4 Socket Head Cap Screw - Grade 5
13	0008168	3/8-16 Whiz Nut


FAN DRIVE P.T.O.



GENSLER

REF.	QTY.	PART #	TITLE	REF.	QTY.	PART #	TITLE
1	1	1215078	Fan Shaft	14	2	1283940	Mount Frame Adj. Angle
2	1	0016203	V-Pulley 3V6.0 x 4 Groove ✓	15	1	1280177	Mount Frame Base
3	1	1216229	SDS Bushing 1 5/8 Bore	16	1	1285065	Jackshaft 375B
4	4	1216003	1 5/8 Bore P.B. Bearing	17	1	0017650	Shear Flange 1 1/4" Bore
5	1	1206218	1B 4.40D x 1 5/8 Bore V. Pulley	18	5	0018998	Woodruff Key
6	1	1280049	Fan Pedestal	19	1	1238160	1/2-13 x 6 Full Thread HHCS
7	1	1210337	9 Blade 18° Fan	20	1	1236236	SF 1 5/8 Bushing
8	1	1216229	SK Bushing 1 5/8 Bore	21	1	0018250	Snap Ring 1 1/4"
9	1	1286100	4/3V - 1000 Belt	22	2	0018133	3/8-16 x 2 1/4" Spec. Shear Bolt
10	1	1283402	Tensioning Bracket	23	2	0018149	3/8" Lock Nut
11	1	0016201	Flat Idler w/Brg's Bearings	24	3	1218117	5/16 - 18 x 1 3/4 Socket Head Cap Screw - Grade 5
12	1	1216235	4/3V 19.0 Pulley				
13	2	1284284	Mount Frame Strut				

375 CUT-AWAY




REF. #	PART #
1	1282014
2	1282650
3	1282866
4	1282831
5	1282867
6	1282833
7	1282839
8	1280178
9	1218956
10	0016600
11	1201037
12	1280128
13	1201028
14	0018993
15	1278990
16	1282890
17	1280225
18	1282995
19	0211037
19A	0211044
20	0210014
21	1218254
22	1282953
23	1282994
23A	1212928
24	1210299
25	1211113
26	1252871
27	1252872
28	1282881
29	1282739
30	1282974
31	1282951
32	1252732
33	1282888
34	1282715
35	1281183
36	1282876
37	1282945
38	1282971
39	1282965
40	1212952
41	1282380
42	1217018
43	1218973
44	1280160
45	1213356
46	1216849
47	1214656
48	

TITLE
Wet Holding Hopper Ass'y. —See Page 6
Inner Peak Ass'y. —See Page 6
Inner Perf. Sheet Cross Angle
End Panel To Hopper Joiner Angle
Left Rear End Panel
Left Front End Panel
Right Rear End Panel
Right Front End Panel
Panel Above Fan
375 Orifice Weld
For "E" Model Fan Drive Ass'y. See Page 15
For "B" Model Fan Drive Ass'y. See Page 16
Fan Guard
Drive Reduction Base —See Page 11
P.T.O. Shaft —See Page 14
Portabilities For 375 Includes:
Pole
Wheel Mount & Hub Assembly
Wheel
Tires (Optional)
Unload Auger Cover
Metering System —See Page 12
Inner Screen Mount Weld.
Screen Cover
Control Cab. Door - Upper
Control Cab. Door - Lower
Control Cabinet Weld.
Control Cab. Door Latch ("T" - Handle)
L.P. Piping Ass'y. —See Page 9
Lower Inside Screen - w/o Cleanout Hole
Lower Inside Screen - with Cleanout Hole
Unit Floor Panel
Heat Chamber Door Frame
Heat Chamber Door Ass'y.
Right Front Floor Panel
Left Front Floor Panel
Center Front Floor Panel
Lower Screen Mn't. Angle
Inner End Screen
Lower Outside Screen
Screen Mn't. Angle
Panel Below Door
Rear Door Frame
Rear Door Ass'y.
Panel Above Door
Outer Screen
Moisture Control Screen
Outer End Screen
Screen Stiffener
Hopper Joiner Angle
High Limit Switch
Thermometer
Rain Guard
Orifice Reinforcing Flange
Air Pressure Switch
Control Cabinet Hinge

For Guard Installation—
See Page 3

DRYER ELECTRICAL SYSTEM POLARITY & GROUND TEST




Using a 115 Volt Neon Circuit Tester, insert as shown. It should light, proving two things:

- 1) The right hand slot is hot.
- 2) the ground hole is properly grounded.

If the Tester does not light when inserted as shown, (AND THIS WAY ONLY) have an electrician look at your service as there is something wired wrong. This is the Standard Electrical Code for all wiring. The Dryer Electrical System must be properly polarized for the Fenwal Ignition System.

NOTE

If an extension cord is used, it MUST be a Three Wire Cord with a Three Prong Plug and a Three Hole Socket wired to the above code.



(Above) The Three Prong Fused Male Plug Pig Tail as it comes out of the Dryer Control Cabinet.

LUBRICATION

All bearings on the unload auger and the speed reduction assembly are pre-lubricated and require no further attention. The bearings on the fan shafts of the dryer should be lubricated with regular gun grease every 100 hours of operation. CAUTION: DO NOT OVER GREASE. Excess greasing blows out seals. All other parts - ratchets, ratchet drive and chains, should be oiled with number 10 oil daily. Variable Speed Pulley, PTO Jackshaft bearings, and the PTO shaft and U-Joints should also be lubricated about every 100 hours of operation. At the end of your drying season, grease and oil all parts to prevent rust.

CARE SHOULD BE TAKEN TO AVOID GETTING OIL INTO THE RATCHET PAWL SOLENOIDS OR ON BELTS.

IGNITION

OPERATION

Upon a call for heat, power is applied to the control board, creating the spark and powering the gas valve. Electronic timing allows the system to continue to spark and hold the gas valve open for a specified trial for ignition period (approx. 7 seconds). If a flame is not present at the end of the trial for ignition period, the system will lockout. If a flame is present, the system will continue to operate, provided the electrodes are immersed in the flame.

In the spark source, a capacitor is charged and discharged rapidly through the primary of high voltage transformer. The current to charge the capacitor also energizes the valve control circuit so that as long as this action continues, the valve will remain open. The capacitor is discharged by a solid state switch, triggered by a neon circuit.

The flame detector monitors the spark current and the flame conductance to ground. If the spark of the flame is not present, feedback to the spark source removes power from the valve control circuit.

LOCATION OF ELECTRODE TIP

The electrode assembly should be located so that the tips are inside the flame envelope and about 1/2 inch above the base of the flame. **IMPORTANT:** Ceramic insulator should not be within or close to the flame pattern. Study the illustration before positioning the electrodes.

NOTE: Electrode assemblies are precision components and should not be adjusted or disassembled. Electrodes should have a gap spacing of 0.125 (+ or -) 0.032". If this spacing is not correct, return the electrode assembly to the factory for replacement. Electrodes within their ceramic casing are NOT field adjustable. Adjust only the electrode mounting bracket.

WARNING: HIGH VOLTAGE.

SAFETY CHECKS




1. Manually shut off the gas supply and apply power to the control board. The system shall lockout after the trial for ignition period. Check that there is no voltage output between terminals B and V2 using a suitable voltmeter or neon tester.
2. Manually open the gas valve and apply power to the control unit. The system shall lockout after the trial for ignition period and there shall be no voltage between terminals B and V2 under the following conditions:
 - (1) The low voltage electrode is shorted to the ground.
 - (2) The high voltage electrode is shorted to the ground.The electrodes are shorted together.

NOTE

Recycle system before each test.

REPAIRS

The Ignition System is not field repairable. Faulty units should be returned to the factory for repair or replacement.



TROUBLE SHOOTING

PROBLEM	SOME POSSIBLE CAUSES AND SOLUTIONS	PROBLEM	SOME POSSIBLE CAUSES AND SOLUTIONS
1. Lights do not work.	<ul style="list-style-type: none"> (a) No electricity. Light bulbs burned out. (b) Fuse blown. (c) Broken or loose wire. 	5. Heat shuts off	<ul style="list-style-type: none"> (a) Dryer has run low on grain. (b) Modulating Valve faulty. (c) High Limit Control tripped out. (d) Solenoid faulty. (e) Out of gas. (f) Faulty or broken electrodes. (g) Machine not grounded.
2. High Limit Light does not work.	<ul style="list-style-type: none"> (a) Light bulb burned out. (b) High Limit tripped out. (Reset by pushing Red Button.) (c) Switch itself burned out (Replace) 	6. Not enough heat.	<ul style="list-style-type: none"> (a) Valves from gas supply are not fully open. (b) Increase pressure at pressure regulator. (On LP units, this is set at factory for approximately 7 - 8 pounds. However, to increase gas flow on LP units, turn adjusting screw in.) (c) Burner partially plugged. Remove and clean. (d) Hand valve not fully open. (e) Adjust Modulating Valve.
3. Air Pressure Switch not functioning.	<ul style="list-style-type: none"> (a) Dryer must be full of grain to operate. If dryer runs out of grain, the air will escape freely and loss of air pressure causes air pressure switch to open circuit. (b) Air tube from pressure switch into dryer may be filled with chaff. (Clean) (c) Adjust setting for less pressure. To close circuits, turn adjusting screw counter clockwise. CAUTION: DO NOT adjust to point that lights will stay on when fans are not running. 	7. Gas Lines frosting up.	<ul style="list-style-type: none"> (a) When first starting burner, open the Main Hand Valve only partially until the unit becomes warm. (b) Gas valve on tank not completely open. (c) Dirty strainer-clean. (d) Check gas line for leaks. (e) On LP machine, vaporizer not in flame enough.
4. If flame does not light. (Fenwal Ignition)	<ul style="list-style-type: none"> (a) Electrodes not positioned in flame properly. (b) Electric Power not on. (c) Polarity of 115 Volts coming to dryer reversed or 15 amp fuse in plug or in control cabinet blown. (d) Machine not grounded. (e) Gas not on. Modulating valve not open far enough. (f) Gas solenoid not opening. (Faulty or loose wire). (g) High Limit Control (reset) tripped out. (h) Air Pressure Switch not functioning. (i) Broken wire from ignition board to electrodes. (j) Ignition board faulty--replace only. (k) Push reset button on ignition board. 	8. Automatic Moisture Control does not work	<ul style="list-style-type: none"> (a) Switch in dial control is faulty or there is a loose or broken wire to the dial control. Check and make replacement. IN THE MEANTIME, OPERATE ON MANUAL. (b) Loose or broken wire at toggle switch, ratchet solenoid, or in rubber cord. (c) Switch or solenoid burned or shorted out. (d) Dial set too high.

375 ALL HEAT CONVERSION


It is possible to operate your Model 375 Dryer as "all-heat" for use with "combination drying" or "dryeration" system. These systems save fuel and energy and produce even finer quality grain.

To convert the machine, install Kit 1279062-L.P. 1279063-NAT. consisting of:

- 3 - 1211241 Burner Unit Weld.
- 4 - 1210316 Ignition Tube Weld.
- 4 - 1214468 Burner Locator Strips
- and either:
- 3 - 1215987 Burner Gas Lead Tubes for LP Gas
- or 3 - 1235999 Burner Gas Lead Tubes for Nat. Gas

Then follow these steps:

- 1) Remove the center front floor panel, item 16, page 10.
- 2) Remove the three 3/8" pipe plugs from the bottom three holes of the burner head, item 11, page 10.
- 3) Install the three new burner units and gas lead tubes in the same manner that the five existing burner units are mounted.
- 4) Install the burner locator strips and ignition tube weldments between each burner unit making sure that the ignition tube ends are fitted tightly into the corners of the flanges of the burner units.
- 5) Be sure that the small spot of weld on the gas lead tubes is facing the rear of the dryer.



INSTRUCTIONS FOR ORDERING PARTS

To eliminate error and speed delivery:

1. Write your **NAME** and **ADDRESS** on your order **PLAINLY**.
2. Explain **WHERE** and **HOW** to make shipment.
3. **GIVE MODEL NAME, NUMBER, and SERIAL NUMBER** that is stamped on the **NAME PLATE** of your product.
4. Order from your **PARTS LIST** as this is the **ONLY** means we have of identifying the parts you need. Order by **QUANTITY DESIRED**, the **PART NUMBER**, and the description **OF PART**.
5. Order your parts from your **LOCAL M-C DEALER** or **DISTRIBUTOR**.
6. **INSPECT ALL SHIPMENTS ON RECEIPT**. If any parts are damaged or missing, file a claim with the carrier before accepting.
7. Do not return parts to Mathews Company without a "Return Goods Authorization" from the factory. A list of all returned parts, a letter of explanation, and your name and address should be included with the shipment. **TRANSPORTATION CHARGES MUST BE PREPAID**.



OWNERS NOTICE

**TO INSURE WARRANTY CLAIMS, BE CERTAIN TO FILL
OUT AND MAIL WARRANTY CARD WITHIN 30 DAYS.**

NOTE: The Company reserves the right to incorporate any changes in design without obligation to make these changes on units previously sold.

