



Mathews Company

Mathews Company

Means } Commitment

2

Volume

PINNACLE



Controls Manual



DOC - P 0 2 - 0 9 1 2

Effective: September, 2012

CONTROLS MANUAL - PINNACLE



© 2012 Mathews Company
500 Industrial Avenue
Crystal Lake, IL 60012 USA
Toll Free: (800) 323-7045
www.mathewscompany.com

Warranty Statement






MATHEWS COMPANY LIMITED WARRANTY FOR WHOLE GOODS

Except as otherwise set forth herein, Mathews Company (Seller) warrants that the equipment supplied by Seller to Buyer shall be free from defects in materials and workmanship when properly installed and operated under normal conditions and in accordance with all applicable instruction manuals. This limited warranty shall expire two (2) years from the date of shipment from Seller's Crystal Lake, Illinois, U.S.A. facility. In addition, for a period of five (5) years from the date of shipment from Seller's Crystal Lake, Illinois, U.S.A. facility, Seller will re-balance M-C Shredder rotors for Buyer at Seller's Crystal Lake, Illinois, U.S.A. facility, provided that the rotors did not become unbalanced through abnormal use by Buyer or were not damaged by Buyer in any way.

To obtain consideration under this limited warranty, Buyer must first notify Seller in Crystal Lake, Illinois, U.S.A., stating in what respects the equipment is believed by Buyer to be defective and providing a list of the parts at issue. Additionally, Buyer must complete a warranty request form stating the machine serial number. Upon receipt by Seller of such notice from Buyer, Buyer may receive authorization from Seller to return the parts. If parts are to be scrapped locally, Buyer will be so advised. If Seller provides Buyer with authorization to return the parts, Buyer shall return such parts to Seller's facility in Crystal Lake, Illinois, U.S.A., transportation prepaid, for examination by Seller. No parts shall be returned to Seller unless Buyer first obtains a return authorization number from Seller. If, in Seller's sole judgment, the parts returned by Buyer are defective and covered under this limited warranty, Seller shall have the option of repairing, rebuilding or replacing such parts. This limited warranty shall not apply to parts which, in Seller's sole judgment, have been the subject of negligence, abuse, accident, misapplication, tampering, alteration, improper adjustment, or electrical problems caused by low voltage conditions; nor shall it apply to consumables, such as belts; nor shall it apply to parts damaged by acts of God, war or civil insurrection, acts of terrorism, improper installation, operation, maintenance or storage, or other than normal application, use or service, including, without limitation, operational failures caused by corrosion, erosion, wear and tear, rust or other foreign materials in the system in which they are utilized.

Failure to give notice within the warranty period shall be a waiver of this limited warranty and no assistance or other action thereafter taken by Seller shall be deemed to extend or revive the warranty period. This limited warranty covers only whole goods and shall not apply to replacement parts or upgrade kits. A separate warranty statement published by Seller covers the warranty on parts and upgrade kits. This limited warranty shall not apply to any products, parts, accessories or other equipment not manufactured by Seller, provided that Seller, upon request by Buyer, shall advise Buyer of any warranties known to Seller that may be offered by the manufacturer of such equipment. This limited warranty shall not cover, and Seller shall not under any circumstances be liable for, damages for injuries to persons or property; loss of crops or other products; losses caused by harvest delays; loss of profits; loss of use; cost of rental equipment; expenses of labor, travel or other items relating to the removal or replacement of defective parts; damages resulting from the removal of defective parts or the installation of repaired, rebuilt or replaced parts; expenses relating to the transportation of parts to and from Seller's facility; any consequential, incidental, contingent or special damages, whether arising in contract, in tort or under statute; or any other damages or expenses not agreed upon in writing by Seller, even if Seller has been advised of the potential for any such damages or expenses. THIS LIMITED WARRANTY IS IN LIEU OF ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ALL WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE OR USE. No person is authorized to give any other warranty or to assume any other liability on Seller's behalf.

Table of Contents

	Introduction	1.1
	Overview	1.1
	User Interface	1.1
	Operation	2.1
	Overview	2.1
	Dryer Operation	2.2
	Operation Mode	2.2
	Discharge Mode.....	2.4
	Operational Timers.....	2.7
	Trending	2.7
	PLC I/O	2.8
	Digital Inputs.....	2.8
	Digital Outputs.....	2.11
	Analog Inputs & Outputs	2.13
	Manuals & Datasheets	2.16
	Settings	3.1
	Setpoints	3.1
	Alarm Setpoints	3.1
	Operational Setpoints.....	3.2
	Sensor Calibration	3.4
	System Configuration	3.10
	System Configuration (Basic)	3.10
	System Configuration (Advanced)	3.13
	Troubleshooting	4.1
	Alarm Pop-Ups and History	4.1
	Stack Light Status (if equipped)	4.2
	Alarm Types	4.4
	Notes	5.1

Introduction

Overview

This volume of the manual is intended to provide you with a thorough overview and explanation of the touch screen software that interfaces with the Pinnacle Programmable Logic Controller (PLC). All possible features of the current Pinnacle software (HMI version 12.12.0151.xx and PLC version 12.11.0200.xx, where xx refers to a minor revision, 01, 02, etc.) will be explained.

Pinnacle and Pinnacle Lite is a member of the Pinnacle family of control systems in which the Pinnacle Lite system controls the dryer through a combination of the PLC interfaced with a Human Machine Interface (HMI) or "touch screen" and conventional relays and timers that are interfaced through buttons and switches. Conversely, Pinnacle, a completely PLC-controlled system does not include any buttons or switches as all operator control is done through a larger touch screen.



Pinnacle Lite Remote Cabinet




Pinnacle Remote Cabinet

The Pinnacle control system's components are intermixed between the High Voltage Cabinet and the Remote Control Cabinet. The PLC is located in the High Voltage Cabinet whereas the HMI is located on the Remote Control Cabinet.

User Interface

The touch screen interface of Pinnacle has been initially designed and continues to be refined, based on user feedback over past years, to provide the most intuitive and straightforward approach to interfacing with the machine. Navigation through the screens is accomplished by selecting one of the eight main chapters (Dryer Overview, Dryer Operation, Setpoints, Faults, Trending, PLC I/O, System Configuration and Manuals & Datasheets) that are shown across the bottom banner of the touch screen. Depending on what chapter you are on, the corresponding icon will illuminate in color which helps understand where you are within the program.



The side bar gives an operational overview, showing the Operation and Discharge modes and the green colored lights indicate what components are operating. Additionally, the Alarm Rest button will allow you to reset a current alarm.



The touch screen allows you to not only monitor parameters, but to also change operational and alarm set points. For the most part, values that can be changed will be displayed as black text with a white background. Values that display in white with the dark gray background are read-only values and cannot be changed.

Example of a displayed value that can be changed:



Example of a displayed value that cannot be changed:




Selecting a white field to change the numerical value will bring up a number keypad. Depending on the input that is being changed, there may be a minimum and maximum range to the value which will be displayed on the keypad. When attempting to enter a value outside of the min/max range, the value will be displayed red on the keypad and will not allow the value to be entered. Once a suitable value has been entered, press "Enter" to input the value and be returned to the screen that the value was being entered on. If you do not wish to change the value, press "Esc" to return without making a change. The "←" button will delete one digit and "Clr" will delete the entire entry.




Certain data field inputs or buttons have a help button associated with it so that it's function or purpose is readily available. This will be indicated with a "?" button and simply pressing it will display a help message pop-up which can easily be closed by pressing the "x" button in the upper right hand corner.

Example of a "?" help button:



After a lapse of time, the screen saver will appear. Simply touch anywhere on the screen to make the screen saver disappear and revert to the screen most recently displayed.



Operation

Overview

While operating the dryer, the majority of the time you will be monitoring the Dryer Overview screen to see the dryer's discharge rate, average mid-grain temperature, discharged grain's moisture and temperature, as well as the status of the fill and takeaway equipment, burner and fan(s):

The screenshot shows the Pinnacle Dryer Overview interface. At the top, it displays 'PINNACLE TruDry Technology', 'Model #: 10840', 'Serial #: 60nnnn', and 'Date & Time: 07 / 28 / 2011 08 : 59 : 07'. The main area features a central diagram of the dryer with various sensors and actuators labeled: 'Infeed', 'Rotary Bin Level Switch (LS 122)', 'Plenum Temperature (Setpoint 190 °F, Actual 180 °F, TI 144)', 'Air Pressure Switch (PS 125)', 'Fuel', 'Air Pressure Switch (XV-163, XV-162, XV-164)', 'Average Mid-Grain Temperature (Actual 76 °F, TE 142)', 'Blower #1 (M 101)', 'Discharge Rate (Setpoint 12.0 %, Actual 12.0 %, SI 125)', 'Discharge Temp / Moist (TE 134: 73 °F, MIE 134: 22.0 %)', and 'Takeaway'. On the right, there is a sidebar with 'Operational Overview' (Operation Mode: Manual, Discharge Mode: Manual), 'Equipment Overview' (Blower(s), Dryer Fill, Burner, Discharge), and an 'Alarm Reset' button. At the bottom, a navigation bar includes icons for 'Dryer Overview', 'Dryer Operation', 'Setpoints', 'Faults', 'Trending', 'PLC I/O', 'System Configuration', 'Manuals & Datasheets', and 'Exit Runtime'.

Change the plenum temperature set point by touching the white setpoint field.

Turns green when the customer fill equipment is energized.

Turns green when enabled and the auger moves when the grain fill is occurring.

Average of the readings from the four mid-grain temperature probes (RTDs).

Valves turn green as gas train is energized. Animation shows position of gas control valve.

Change the discharge rate in manual mode by touching the white set point field.

Discharge temperature and moisture percentages are displayed.

Animation shows the center dump or discharge auger action and turns green when activated.

Dryer overview screen (shown) is an animated visualization of the drying process.

Set operation and discharge modes and monitor the operational timers as the dryer runs. Also used for starting/stopping the dryer in manual or automatic mode.

Change any of the operational or alarm set points for various parts of the system.

View and address faults and fault history.

View current and past data in a chartable graph format.

See values of analog inputs/ outputs or status of digital inputs/outputs.

Configure system options and view factory settings.

View dryer manuals and electrical schematics.



Dryer Operation

From the Dryer Operation screen, you can select Manual or Automatic mode of operation for the dryer as well as set the discharge mode of control, either Manual or TruDry. Attempting to change the mode of operation while the dryer is running is not possible as the button is grayed out.

Operation Mode

The operation mode section of the Dryer Operation screen allows you to set the mode of operation in either manual or automatic; manual allows you to manually start and stop components, whereas automatic allows you to perform an automatic sequence of events to start, stop or cool down the machine.

There is also a safety feature to prevent repeated starts of the blower(s) and this will be seen with a check box next to the field labeled "OK To Restart Blower(s)"; a blower cannot be started unless the box is checked. After a blower is started and subsequently shutdown, a timer will start and a repeated start of the blower will not be permitted until the timer has elapsed. If the machine is not equipped with a soft starter, this can be overridden by checking the box and accepting the warning message about repeated starts of the fan motor(s); this will require a service level login. If the system is equipped with a soft starter, overriding the timer is not permitted.

Manual Operation

Manual operation mode allows you to start and stop any of the four main components of the dryer (blowers, burner, fill equipment or discharge/takeaway equipment).



To start a component, press the button in the left hand column with the green lettering. To stop that particular component, press the opposite red-lettered button in the right hand column. If a component is currently operating, the green button will have dimmed and the red button will be highlighted, showing the option to stop the operating component.

Automatic Operation

Automatic operation allows you to initiate an automatic start-up, shut-down or cool-down sequence of operation with a single push button.

The screenshot displays the Pinnacle TruDry Technology control interface. At the top, it shows the model number (3500), serial number (59734), and date/time (07/06/2010 17:13:21). The interface is divided into several sections:

- Operation Mode:** Includes checkboxes for Manual (unchecked) and Automatic (checked). Below this are checkboxes for "OK To Restart Blower(s)" (checked), "No Faults" (checked), "Blower(s) Off" (checked), "Gas Turned On" (checked), "Fill Equipment Enabled" (checked), "Burner Cover Removed" (checked), "Takeaway Equipment Enabled" (checked), and "Start-Up Conditions Met" (checked). A "5:00" timer is also visible.
- Discharge Mode:** Includes checkboxes for Manual (checked) and TruDry Technology (unchecked). It shows "Actual" and "Setpoint" values for percentage (0.0% and 12.5%) and temperature (77°F and 120°F).
- Operational Timers:** Lists various delays in seconds: Fill Start Delay (5), Fill Stop Delay (20), Takeaway Delay (15), Grain Flow Timer (5:00), Cool Down Timer (5:00), Blower Confirm Delay (5), Blower 1 Delay (15), Blower 2 Delay (8), and Blower 3 Delay (8).
- Buttons:** "Start-Up" (green), "Cool-Down" (blue), and "Shut-Down" (red).
- Navigation Bar:** Includes icons for Dryer Overview, Dryer Operation, Setpoints, Faults, Trending, PLC I/O, System Configuration, Manuals & Datasheets, and Exit Runtime.
- Right Panel:** Features the Mathews Company logo, "Operational Overview" (with "Automatic" selected), "Discharge Mode" (with "Manual" selected), "Equipment Overview" (with "Blower(s)", "Dryer Fill", "Burner", and "Discharge" indicators), and an "Alarm Reset" button.

To start-up the machine automatically, a checklist needs to be fulfilled to confirm that the start-up conditions are met. The "OK To Restart Blower(s)" checkbox needs to be checked per the conditions previously explained. Similarly, the "No Faults", "Fill Off", "Blower(s) Off" and the "Discharge Off" conditions need to be met and the system will show the status of these conditions with the checkboxes checked. Lastly, the "Gas Turned On", "Fill Equipment Enabled", "Burner Cover Removed" and the "Takeaway Equipment Enabled" checkboxes are manually checked once those un-monitored conditions are met. Once all of the Start-Up conditions are met, the Start-Up button will illuminate indicating that it is active and start-up operations are permitted.

When the Start-Up button has been pressed, the dryer will sequentially start the blowers and enable the fill equipment. As the blower(s) are starting, a blower confirmation delay timer will elapse to allow air pressure to build up. If the dryer is empty, the fill equipment will operate and grain will be introduced to the dryer until the fill level is sufficient to actuate the fill switch, which indicates to the system that the dryer has completed a first-time fill. Provided that sufficient air pressure has been developed, the ignition process will be initiated and pop-up windows will appear, advising you the status of the burner ignition process.



Once the burner has successfully been lit, the dryer will now be fully operational and the only options that exist are to shut-down or cool-down the machine by selecting the corresponding button on the bottom of the screen. If cool-down mode is selected, the fan(s) will continue to run for the duration of the cool-down timer. If you desire to re-start the dryer while the machine is in cool-down, simply press the re-start button and after confirmation of the re-start, you will be guided through the burner ignition process again. Selecting the shut-down button will completely shut all equipment off once you have confirmed that you intend to shutoff the dryer.

Discharge Mode

The discharge mode refers to the manner in which the speed of the discharge system changes. The options are: (1) Manual discharge mode in which the user sets the intended discharge rate and (2) TruDry mode in which the system will change the speed with the goal of maintaining the average mid-grain temperature equal to the target mid-grain temperature.

Manual

Manual mode of operation means you can directly tell the discharge metering system what speed the dryer will discharge grain at. Depending on what model dryer you are operating, the % discharge speed will correspond to an approximate bu/hr value. These values are calculated based on discharge capacity values which will be discussed further in the settings section. Additionally, a table is included on the next page so that you may correlate the discharge speed % to bu/hr.

	Heat + Cool					
	20%-15% Moisture			25%-15% Moisture		
	bu/hr	tonnes/hr	speed	bu/hr	tonnes/hr	speed
10520	560	13.0	37%	320	7.5	18%
10630	690	16.1	48%	395	9.2	24%
10730	790	18.4	56%	455	10.6	29%
10840	945	22.0	57%	545	12.7	30%
101050	1,155	26.9	71%	670	15.6	38%
101275	1,385	32.3	87%	805	18.8	47%
2000	2,000	4.6	61%	1,200	28.0	33%
2400	2,400	55.9	75%	1,440	33.5	42%
3000	3,000	69.9	48%	1,800	41.9	25%
3500	3,500	81.5	58%	2,100	48.9	31%
4000	4,000	93.2	67%	2,400	55.9	37%
4800	4,800	111.8	83%	2,800	65.2	44%

TruDry Technology

TruDry is the name of a discharge mode of operation that automatically increases or decreases the discharge speed of the dryer. TruDry is not an automatic moisture control mode of operation and does not utilize the discharge moisture value, but instead controls the discharge rate by attempting to maintain an average mid-grain temperature setpoint. The principal of operation is that as the grain entering the dryer increases in moisture, the mid-grain temperature will go down and when the grain entering the dryer decreases in moisture, the mid-grain temperature will go up. Therefore, what the controller will do is utilize a negative responding Proportional-Integral-Derivative (PID) control loop which will increase the discharge rate when the mid-grain temperature goes up and decrease the discharge rate when the mid-



grain temperature goes down. This essentially means that as the grain's moisture goes up, the dryer will slow down and as the grain's moisture goes down, the dryer will speed up.

In order to effectively use the TruDry mode of operation, it is important to allow the dryer to get to a steady state operating condition for 2-3 hours (depending on the size of the machine and the incoming grain moisture) with a desirable and consistent discharge moisture output. Once this steady state condition has been met, you will want to set the mid-grain temperature setpoint to a value equal to the current actual mid-grain temperature. Note that although you are running the dryer in manual, you will still be able to change the mid-grain temperature setpoint. At this point, the dryer has been running for 2-3 hours and steady state has been reached, so the current reading for the actual mid-grain temperature should correspond to the desired grain moisture that is currently being discharged from the dryer. It is important to understand that TruDry is not controlling the dryer on discharge moisture, but rather indirectly based on the average mid-grain temperature.

Another step to ensure a smooth and successful transition from manual mode to TruDry is to verify the minimum and maximum discharge speeds on the Operational Setpoints page of the Setpoints Chapter are set to a reasonable values. The minimum and maximum speed setpoint refers to the minimum and maximum speed that the dryer can run at. When running in TruDry mode this is especially important because the TruDry control algorithm will attempt to speed up and slow down to maintain the mid-grain temperature setpoint, and the amount of room that the controller has to work with is determined by the minimum and maximum speed setpoints. For example if the min/max speed setpoints are 0% - 100%, the range of speed output from the controller will be higher, which means the rate at which the speed changes will be higher. On the other hand, if the min/max setpoints are 30% - 75%, the controller can only operate within that band and only has a range of 45% to work with. More information on how to change the minimum and maximum speed setpoints on the Operational Setpoints screen is found in the Settings section of this manual. A table of suggested minimum and maximum values is shown below:

	Heat + Cool	
	Recommended	
	Min	Max
10520	0%	50%
10630	10%	60%
10730	10%	70%
10840	10%	70%
101050	20%	90%
101275	30%	100%
2000	20%	80%
2400	30%	90%
3000	10%	60%
3500	20%	70%
4000	20%	80%
4800	30%	100%

Once the average mid-grain temperature setpoint has been set and the minimum and maximum speed range has been established, TruDry mode of operation can be selected by touching the TruDry check box. Once TruDry mode of operation has been selected, the ability to manually change the speed will be inhibited and the only parameter that can be adjusted will be the mid-grain temperature setpoint.



While running in TruDry, you will see the speed continuously increase or decrease to maintain the target mid-grain temperature. Do not continuously tweak the mid-grain temperature, let it try to control to the setpoint value that you previously established. TruDry should be able to handle 3-5% swings in incoming moisture with reasonable discharge moisture variation if the dryer was properly brought up to steady state as previously explained. If after running for an extended period of time you have determined that the target mid-grain temperature is too high or too low, minor adjustments can be made, but should only be done periodically, not continuously. If you want to meticulously control the dryer, then you should be running in the manual mode of operation in which you can directly control the dryer's discharge rate.





Operational Timers

The Operational Timers section of the Dryer Operation screen display the values and the status of any timer as it is running. Some of the timer values can be changed in the Setpoints area of the software and those will be explained further in this manual.

Trending

The trending chapter is where you will go to view one of two historical data plots for: (1) Temperatures - plenum temperature, discharge grain temperature and average mid-grain temperature or (2) Percentage (%) - discharge speed, discharge grain moisture, plenum temperature control valve opening. Although you will be able to access the Trending screens, you will not actually see data trends unless the dryer is currently discharging grain.



The (-) button will increase the time from the current time period to the prior time up to one day to view on the trending screen. This will give you a whole day of data to view on one screen.

The (+) button will shorten the time period from the prior to the current time. This will give you a shorter view of the data from prior time to the current time period.

The Rewind button will rewind time from the current time period to a later time on the screen.

The Pause button will stop the screen in the current time position that you are in to view the data.

The Play button will start the trending screen from the last position of time that you were viewing.

The Forward button will move you in forward up to the current time position.

PLC I/O

The PLC I/O chapter displays values corresponding to the digital and analog inputs and outputs that are interfaced with the PLC. Analog inputs and outputs refer to values that change in numerical value such as a temperature or a moisture reading, whereas digital inputs or outputs refer to parameters that are discrete and are either on or off, such as a high limit switch. The purpose of the PLC I/O chapter is for several reasons, some of which include the ability to diagnose issues that may arise or to get additional information pertaining to a particular input or output value.

Digital Inputs

Upon selecting the PLC I/O chapter button, you will be taken to the Digital Inputs screen. Because both digital inputs and digital outputs refer to discrete parameters, their values can be indicated with the equivalent of a colored bulb. If the indicator is white, the input is off, whereas if the indicator is green, the input is on.



The digital inputs that are monitored by the PLC are presented below with a brief description of their purpose:

I0.0 - Master Control Relay (MCR)

A green light indicates that the control power is ON and the safety circuit is functioning properly. White indicates it is OFF.

I0.1 - Blower(s) Overload

Green indicates that the blower circuit is ok, white indicates overload.

I0.2 - In-feed Bin Switch

Green indicates the grain level has fallen low enough for the paddle in the rotary bin switch to rotate. If white, the fill level is sufficient.

I0.3 - Discharge Level Switch

Green indicates that the level switch is made. White indicates that the grain has overloaded the level switch and it is open.

I0.4 - Discharge VFD OK

If green, the VFD is functioning properly. White indicates that the VFD is sending a fault signal to the PLC.

I0.6 - Discharge Prox Switch

Flashes from white to green at intervals in conjunction with the state of the RPM proximity sensor. When the discharge is running, the RPM proximity sensor will change state based on the rate of discharge. If the proximity sensor does not change state within a predetermined amount of time, an alarm indicating a discharge fault will be generated.

I0.7 - Linear Limit Circuit (LLC)

Green indicates that the linear limit circuit is complete and functioning properly. If white, the circuit is either incomplete or there is an error.

I1.0 - Blower #1 Auxiliary

Green indicates that the auxiliary contact for the #1 motor starter is ON. If white, it is OFF.

I1.1 - Blower #1 Press Switch

Green indicates that the #1 blower pressure switch has been activated and the blower is generating sufficient pressure. White indicates low or no pressure.

I1.2 - Discharge Prox Switch

Follows the same signal as I0.6 and is used for jam detection.

I1.3 - Low Gas Press Switch (CGA Only)

When white, the switch is off. When green, the switch is on. If CGA is enabled, the low gas pressure switch is monitored when the burner is ignited. If the gas pressure falls too low, the switch will be deactivated.

I1.4 - Burner High Limit

Green indicates that the high limit circuit is complete and is functioning properly. White indicates that the burner high limit setpoint has been reached, tripping the high limit switch.



I1.5 - Burner Ignition On

A green signal verifies that a flame is present. White signifies the absence of flame.

I1.6 - Blower #2 Auxiliary

Green indicates that the auxiliary contact for the #2 motor starter is ON. If white, it is OFF.

I1.7 - Blower #2 Press Switch

Green indicates that the blower pressure switch has been activated and the blower is generating sufficient pressure. White indicates low or no pressure.

I2.0 - High Gas Press Switch (CGA Only)

When white, the switch is OFF. When green, the switch is ON. If CGA is enabled, the high gas pressure switch is monitored when the burner is ignited. If the gas rises too high, the switch will be deactivated.

I2.1 - Tri-Start Auxiliary Contact

In an 18' tower/3-blower system only, green indicates that the auxiliary contacts of start contactor A and start contactor B are closed. White indicates one or both of the auxiliary contacts are open.

I2.3 - Blower #3 Auxiliary

Green indicates that the auxiliary contact for the #3 motor starter is ON. If white, it is OFF.

I2.4 - Blower #3 Press Switch

Green indicates that the blower pressure switch has been activated and the blower is generating sufficient pressure. White indicates low pressure.

I2.5 - LLC#1 Ok

Green indicates that linear limit circuit #1 is complete and functioning properly.

I2.6 - LLC#2 Ok (12' and 18' tower only)

Green indicates that linear limit circuit #2 is complete and functioning properly.

I2.7 - LLC#3 Ok (12' and 18' tower only)

Green indicates that linear limit circuit #3 is complete and functioning properly.

NOT USED/SPARE

Inputs & outputs marked Not Used/Spare are never used.


NOT USED

Inputs & outputs marked Not Used are not used in a particular configuration but when that feature is active, the input/output is used.



Digital Outputs

Advancing to the next screen from the Digital Inputs by pressing the Next button will take you to the Digital Outputs screen. Similar to the digital inputs, digital outputs refer to discrete parameters and their values can be indicated with the equivalent of a colored bulb. If the indicator is white, the output is off, whereas if the indicator is green, the output is on.



The digital outputs that are monitored by the PLC are presented below with a brief description of their purpose:

Q0.0 - Customer Remote Fill Run

Green indicates that the customer's remote fill equipment is running and grain is filling the dryer. White indicates that the fill equipment is not running.

Q0.1 - Customer Remote Fill Clean Out

Green indicates that the customer's remote fill equipment will continue to run to permit cleanout of the customer fill equipment. White indicates that it is not running.

Q0.2 - Blower #1 Motor Starter

Green indicates that the blower motor has been commanded to run. White indicates that it has not been commanded to run.

Q0.3 - Blower #2 Motor Starter

Green indicates that the blower motor has been commanded to run. White indicates that it has not been commanded to run.

Q0.4 - Blower #3 Motor Starter

Green indicates that the blower motor has been commanded to run. White indicates that it has not been commanded to run.

Q0.6 - Discharge VFD Run

Green indicates that the discharge VFD has been commanded to run. White indicates that it has not been commanded to run.

Q0.7 - Customer Takeaway Run

Green indicates that the customer's takeaway system has been commanded to run. White indicates that it has not been commanded to run.

Q1.0 - Burner Ignition

Green indicates that the burner has been commanded to ignite and will stay ON while operating. White indicates that it is OFF.

Q1.1 - Tri-Start Contactors

Green indicates that the start contactors A and B are turned ON. White means they are OFF.

Q1.2 - Green Lamp (if equipped)

The Green Lamp digital output commands the green light on the stack lamp to turn on when illuminated green. The green lamp on the stack light is on continuously when the control power is on and will continuously blink when the discharge is running. This digital output is only available if the machine is equipped with the auxiliary alarms feature.

Q1.4 - Discharge VFD Fault Reset

Flashes green momentarily when the PLC sends a reset request to the VFD. When white, no request is being sent.

Q1.5 - Maxon Solenoid (if configured)

Green indicates that the Maxon valve is energized. White indicates that it is not.

Q1.6 - Red Lamp (if equipped)

The Red Lamp digital output commands the red light on the stack lamp to turn on when illuminated. The red lamp on the stack light will blink when the dryer has shutdown with a Type "C" alarm or will alternate red/green blinking with a Type "A" alarm while discharging. More information is available on alarms in the Troubleshooting section of this manual. This digital output is only available if the machine is equipped with the auxiliary alarms feature.

Q1.7 - Fire Alarm Signal

Green indicates that the fire alarm has been activated. White indicates that it has not.

NOT USED/SPARE

Inputs & outputs marked Not Used/Spares are never used.


NOT USED

Inputs & outputs marked Not Used are not used in a particular configuration but when that feature is active, the input/output is used.



Analog Inputs & Outputs

Advancing to the next screen from the Digital Outputs by pressing the Next button will take you to the Analog Inputs and Outputs screen. The analog inputs and outputs screen displays the raw and scaled values.



The analog inputs and outputs that are monitored by the PLC are presented below with a brief description of their purpose:

AIW4 - Discharge Grain Moisture

Indicates the moisture of the grain flowing across the discharge moisture sensor.

AIW6 - Discharge Grain Temperature

Indicates the temperature of the grain flowing across the discharge moisture sensor.

AIW8 - Plenum Temperature

Indicates the plenum temperature from the plenum RTD.

AIW12 - Mid-Grain Temperature #1

Indicates mid-grain temperature #1 from the RTD transmitter.

AIW14 - Mid-Grain Temperature #2

Indicates mid-grain temperature #2 from the RTD transmitter.

AIW16 - Mid-Grain Temperature #3

Indicates mid-grain temperature #3 from the RTD transmitter.

AIW18 - Mid-Grain Temperature #4

Indicates mid-grain temperature #4 from the RTD transmitter.



AQW4 - Plenum Temperature Control

Indicates the commanded opening for the fuel control valve to regulate plenum temperature.

AQW0 - Discharge Speed Control

Indicates the commanded discharge speed sent to the VFD.

The discharge speed analog output provides all pertinent discharge speed information. The scaled discharge speed output % that is defined either manually in Manual mode or automatically in TruDry mode is shown as well as the corresponding output voltage from the PLC. This is the analog output voltage that is sent to the VFD for discharge speed control. This value can be verified for troubleshooting purposes by measuring the voltage across the output of the PLC output or by measuring the analog input voltage on the VFD. A tabulation of data for all dryer models is shown on the next page with VFD frequency, metering speed, and discharge rate (bu/hr) for 0% - 100% in 10% increase.

The VFD frequency is shown to provide an indication of what frequency the discharge metering motor is running at; this value is not read directly from the VFD, but rather it is a calculated value based on the discharge speed %.

The discharge motor speed and the corresponding metering system speed are both shown with units of revolutions per minute (RPM). The metering speed is the speed at which either the metering rolls or sweep system is running at downstream of the discharge gearbox speed reduce.

A tabulation of data for all tower dryer models is shown on the next page with VFD frequency, metering speed, and discharge rate (bu/hr and metric tonnes/hr) for 0% - 100% in 10% increase.

VFD Freq (Hz)	Discharge Speed (%)																			
	0%			10%			20%			30%			40%			50%				
	Metering Speed (RPM)	Disch Rate (bu/hr)	Disch Rate (tonnes/hr)	VFD Freq (Hz)	Metering Speed (RPM)	Disch Rate (bu/hr)	Disch Rate (tonnes/hr)	VFD Freq (Hz)	Metering Speed (RPM)	Disch Rate (bu/hr)	Disch Rate (tonnes/hr)	VFD Freq (Hz)	Metering Speed (RPM)	Disch Rate (bu/hr)	Disch Rate (tonnes/hr)	VFD Freq (Hz)	Metering Speed (RPM)	Disch Rate (bu/hr)	Disch Rate (tonnes/hr)	
10520	93	2.2		11.7	1.3	219	5.1	18.4	2.1	344	8.0	25.1	2.9	469	10.9	31.8	3.7	594	13.8	16.8
10630																				
10730	5.0	0.6		11.7	1.3	219	5.1	18.4	2.1	344	8.0	25.1	2.9	469	10.9	31.8	3.7	594	13.8	16.8
10840																				
101050	110	2.6		11.7	1.3	257	6.0	18.4	2.1	405	9.4	25.1	2.9	552	12.9	31.8	3.7	699	16.3	19.7
101275																				
2000	5.0	0.6	259	6.0	1.2	543	12.7	16.0	1.8	828	19.3	21.5	2.5	1,113	25.9	27.0	3.1	1,397	32.5	39.2
3000																				
3500	5.0	0.2	476	11.1	0.4	999	23.3	16.0	0.7	1,522	35.5	21.5	0.9	2,046	47.6	27.0	1.1	2,569	59.8	72.0
4000																				
4800																				

VFD Freq (Hz)	Discharge Speed (%)																				
	60%			70%			80%			90%			100%								
	VFD Freq (Hz)	Metering Speed (RPM)	Disch Rate (bu/hr)	Disch Rate (tonnes/hr)	VFD Freq (Hz)	Metering Speed (RPM)	Disch Rate (bu/hr)	Disch Rate (tonnes/hr)	VFD Freq (Hz)	Metering Speed (RPM)	Disch Rate (bu/hr)	Disch Rate (tonnes/hr)	VFD Freq (Hz)	Metering Speed (RPM)	Disch Rate (bu/hr)	Disch Rate (tonnes/hr)	VFD Freq (Hz)	Metering Speed (RPM)	Disch Rate (bu/hr)	Disch Rate (tonnes/hr)	
10520	845	19.7		970	22.6	1,095	25.5	1,220	28.4	1,345	31.3	1,436	33.4	1,583	36.9	1,682	39.2	1,815	42.5	1,945	45.5
10630																					
10730	45.2	5.2		51.9	6.0	1,289	30.0	65.3	72.0	8.3	84.7	9.2	93.5	10.1	100.0	10.9	11.7	12.6	13.5	14.4	15.3
10840																					
101050	994	23.2		1,141	26.6	1,289	30.0	1,436	33.4	1,583	36.9	1,730	39.8	1,877	42.5	1,975	45.2	2,072	47.9	2,170	49.7
101275																					
2000	38.0	4.4	1,967	45.8	5.0	2,536	59.1	54.5	60.0	6.9	65.7	72.0	8.3	84.7	9.2	93.5	10.1	100.0	10.9	11.7	12.6
2400																					
3000	38.0	1.6	3,615	84.2	1.8	4,139	96.4	49.0	54.5	2.0	4,662	108.6	54.5	60.0	65.7	72.0	77.1	82.2	87.3	92.4	97.5
3500																					
4000																					
4800																					




The calculated discharge rate is displayed in bu/hr and is calculated based on the quantity of grain that is discharged with each revolution of the metering system and is referred to as the discharge capacity with units of bu/rev. The default value for this parameter is model specific and has been approximated based on past experience, as shown in the following table. It is important to understand that this value can be adjusted for a more accurate discharge rate indication. A further explanation on how to adjust this parameter will be found in the Settings section of this manual.

	Discharge Capacity	
	(bu/rev)	(m3/rev)
10520	2.708	0.09540
10630		
10730		
10840	3.187	0.11227
101050		
101275		
2000	7.500	0.26422
2400		
3000	38.333	1.35043
3500		
4000		
4800		

Manuals & Datasheets

The Windows-based interface of Pinnacle puts all the documentation for the system right at your fingertips. The software will be loaded with the appropriate manuals for the model/serial number. Additionally, there will be a set of electrical schematics specific to the dryer. Open any of these files in Adobe .pdf format by selecting the respective button as shown below:



Settings

The Pinnacle control system has features that are customizable with several settings that can be changed as necessary. These settings are thoroughly discussed throughout this section of the manual.

Setpoints

Selecting the setpoints chapter button will take you to the first of three screens, alarms setpoints, followed by operational setpoints and lastly, sensor calibration.

Alarm Setpoints

The alarm setpoints screen provides you with the ability to change limits and other values that correspond to alarm values. The alarms that these setpoints correspond to will be explained further in the Troubleshooting section of this manual.



Mid-Grain Band

The Alarm Set Point is the allowed deviation from the mid-grain temperature set point while the discharge system is running.

Mid-Grain Band Delay

The Mid-Grain Band delay is a user-defined time duration that will delay the cool down of the dryer after the Mid-Grain Band warning alarm has occurred.



Discharge Moisture Low Limit

The Discharge Moisture Low Limit alarm set point is a discharge moisture value that will trigger an alarm when the value drops below the discharge moisture low limit set point for duration of 5-minutes while the discharge is running.

Discharge Moisture High Limit

This Discharge Moisture High Limit alarm set point is a discharge moisture value that will trigger an alarm when the value exceeds the discharge moisture high limit set point for duration of 5-minutes while the discharge is running.

Grain Flow Timeout

The Grain Flow Timeout set point is the time delay allowed once the grain level has dropped below the bin level switch. Once the grain flow timeout set point has been reached, an alarm will be triggered that will place the dryer into COOL-DOWN mode.

Plenum Temperature Band

The Plenum Temperature band is the maximum allowed deviation between the actual plenum temperature and the plenum temperature set point.

Operational Setpoints

Selecting the Next button from the Alarm Setpoints screen will take you to the Operational Setpoints screen which provides you with the ability to change operational values that affect the performance of the machine.



Plenum Temperature

The Plenum Temperature set point is used to control the plenum temperature when the burner is lit. The PLC will control plenum temperature by adjusting the burner control valve to increase or decrease the amount of fuel flowing to the burner.

Control Valve Initial Opening

The Control Valve Initial Opening is the position of the fuel control valve commanded as the burner is undergoing the initial ignition sequence.

Control Valve Min Opening

The Fuel Control Valve Minimum Opening % set point is the lowest possible control valve output allowed by the dryer.

Control Valve Max Opening

The Fuel Control Valve Maximum Opening % set point is the highest possible control valve output allowed by the dryer.

Auto Temp Adjust Jump

The Auto Temp Adjust Jump set point refers to the automatic temperature decrease of the plenum temperature set point when the VFD back off speed set point has been reached.

Auto Temp Adjust Max

The Auto Temp Adjust Max set point refers to the total allowed adjustment to the plenum temperature as a result of multiple auto temp adjustments.

Auto Adjust Timer

The Auto Adjust Timer refers to the time before an automatic temperature adjustment is made to the plenum temperature set point.

VFD Back off Speed

The VFD Back-off Speed refers to the VFD speed at which the automatic plenum temperature set point adjustment feature will become enabled.

Cool-Down Timer

The Cool-Down Timer refers to the length of time that the dryer will be placed in COOL-DOWN mode following a type-B fault or when the dryer is placed in COOL-DOWN mode.

Mid-Grain Temp

The Mid-Grain Temperature set point refers to the target mid-grain temperature that the dryer will attempt to maintain during automatic discharge control.

Fill Start Delay

The Fill Start Delay set point refers to the time between when the grain level has dropped below the Bin Level switch and when the Dryer Fill System is activated.

Fill Stop Delay

The Fill Stop Delay set point refers to the time between when the grain level has risen above the Bin Level switch and when the Dryer Fill System is deactivated.



Takeaway Cleanout Delay


The Takeaway Cleanout Delay setpoint refers to the amount of time that the dryer takeaway system will be commanded to operate after the Dryer Discharge system has stopped.

Sensor Calibration


Selecting the Next button from the Operational Setpoints screen will take you to the Sensor Calibration screen:

The moisture sensors that are used on the dryer are special devices that measure the capacitance of the grain passing over the sensor's surface which correlates to a voltage that is then calibrated to a moisture value. Furthermore, the moisture sensor also measures the grain temperature because grain temperature is an important parameter to monitor while drying, but also because the temperature is used to compensate the measured grain moisture; this temperature compensation step is done within the PLC so that the moisture value that is displayed on the touch screen is a temperature compensated moisture which reflects what is measured with third party moisture testers.

Accurate calibration equations are critical for reliable and consistent operation. The Pinnacle software is equipped with three different calibration methods: (1) Single Point, (2) Advanced Linear and (3) Advanced Polynomial. Regardless of what calibration method is utilized, the end result is that there will be an equation that correlates the moisture sensor's voltage to an uncompensated moisture value. It is referred to as an uncompensated moisture because the moisture measured by the sensor needs to be compensated from a reference temperature to the actual grain temperature.



Once you are on the sensor calibration screen, you will select what calibration method will be applied to the discharge moisture sensor. If the machine is equipped with an infeed moisture sensor, there will be a next button which when selected, will take you to the equivalent set of screens to setup the infeed moisture sensor as well. The Features Enable section where the discharge moisture sensor is enabled also has a toggle to indicate what model moisture sensor is being used (FP21C or FP32C) and whether or not the moisture sensor is installed in a sampler assembly. The Pinnacle software needs to know what sensor is being used because the temperature-voltage relationship is different and the presence of a sampler will enable the advanced linear and advanced polynomial calibration methods. If no sampler is installed, the only option will be the Single Point calibration method as shown below:



Single Point Calibration

The Single Point calibration method establishes a simple relationship between sensor voltage and grain moisture. Additionally, when using the single point calibration method, it is assumed that 0.00V corresponds to 0% moisture (uncompensated). For example, if it is known that the grain's moisture is 16.2% and the sensor's voltage is reading 1.15V, the calculated calibration will be 14.09 %/V which is referred to as the "slope". This is a simple linear relationship that calculates the moisture as 14.09 %/V, so if the sensor's voltage changes to 1.05V, the calculated moisture will then change to 14.8% which is calculated as the product of the "slope" and the current voltage or $14.09\%/V \times 1.05V = 14.8\%$.

The benefit of using the Single Point Calibration is that it is easy to quickly setup the moisture sensor, however the limitation is that it will not be accurate over a wide moisture range.

In order to apply a single point calibration to your moisture sensor, make sure the Single Point method is selected and navigate to the Single Point Settings screen. On this screen you will see the current voltage being measured by the moisture sensor as well as the current moisture being calculated from the current single point calibration slope being used. The calibration slope will be shown on the screen as well as the calibration temperature that is in effect. Lastly, the sample moisture value is shown.



To establish and apply a new calibration slope, pull a sample of grain as close as possible to the moisture sensor. This will ensure that the voltage that is read off the touch screen corresponds with the grain that is passing over the sensor. Once that sample is taken, measure the sampled grain's moisture in your third party moisture tester, enter the value in the sample input box and select the Calibrate button. Once the Calibrate button is pressed, the new slope will be calculated as well as the new calibration temperature which is taken as the current grain temperature measured from the sensor.

After the calibrate button is pressed, you will then start to see the current moisture value change because the new calibration slope is now in effect.

Advanced Linear Calibration


Because of the limitations of the Single Point calibration method, the Pinnacle Lite software also includes an Advanced Linear calibration method which is based on more than one data point. Up to 8 data points can be used to establish an advanced linear calibration equation and the way in which you input the data points into the touch screen allow you to view the calibration data before applying it.

The principal behind the Advanced Linear Calibration method is that a collection of sensor voltages, tested moistures, and tested temperatures are plotted over the desired range of the sensor. For example, if the target discharge moisture is 15.5%, then you will likely want to establish a calibration that ranges from as low as 13% up to 18%. The ideal time to collect this data is when the dryer is first being put into operation at the start of a drying session. The more tested samples the better, as long as they are spread out over the desired range - be aware that two data points at 13% and 17% will produce much better results than five data points between 14.5% and 15.5%.

When you are ready to collect a sample, it is important to pull a sample of grain as close as possible to the moisture sensor which will ensure that the voltage that is read off the touch screen corresponds with the grain that is currently passing over the sensor. When you do pull a sample of grain, be sure to record the moisture sensor's voltage from the touch screen (15-sec average on the Analog Input screen). After you have recorded the voltage, measure the grain's moisture and temperature at least 3-5 times taking an average of the values. You will likely see that each time you test the grain moisture, you will get a different value from your third party moisture tester which is normal and expected. Once you have the voltage, moisture, and temperature values for the collected sample, record it on a log sheet such as what is shown below:

Date/Time	Sensor Voltage	Grain Temp	Grain Moist


You can also skip logging on a sheet of paper and enter it directly on the touchscreen by enabling the Advanced Linear Calibration method and selecting the Settings button.




Here you will see a table that allows for entry of the previously mentioned voltage, moisture, and temperature values collected for multiple samples.

Based on the tested temperature, the uncompensated moisture will be calculated as shown in the read-only column. To clear the values of a sample row, simply press the x button to the left of the values. When clearing a row of sample data, it will then be excluded from the calculated calibration equation.

Because you now have the ability to enter multiple data points, the slope of the calibration will be calculated, as previously mentioned in the Single Point Calibration method, as well as an "intercept" value. At any point you can see what slope and intercept values currently being used by looking in the lower right hand corner where they are presented in green on a dark background. After all of your samples are entered in the table, press the re-scale data points button and followed by the re-calculate proposed button and a linear regression will be performed on the samples entered. A linear regression will calculate the slope and intercept of a trend line that passes through the data points previously input. Graphically, this can be represented as follows:



The sample data points are plotted as uncompensated moisture values on the vertical axis with the corresponding raw sensor voltage on the horizontal axis. The trend line shown above is drawn as close as possible through the data points and the corresponding slope and intercept of the line is then taken to be the calibration equation once the calibration is applied. After the slope and intercept are calculated, the values will be shown in the upper right hand corner as proposed values. In order to determine if entered samples produce a reasonable calibration curve, you can select the View Data Points button which will show a scatter plot of the entered samples:




Note that when viewing the plotted data points, the values should always produce a line that slopes from the lower left corner to the upper right hand corner as shown above. Once the values are determined to be acceptable, the proposed calibration can be applied by pressing the Apply Calibration button. Once this is done, the Current Calibration will be copied from the Proposed Calibration values and the moisture will now be calculated from the new calibration.

You are also able to perform the same process in a spreadsheet program of your choice if more than 8 samples are collected. Instead of entering the samples individually and calculating the slope and intercept on the touch screen, you can enter the slope and intercept directly in the white input boxes in the lower left hand corner.

The advantage of the Advanced Linear Calibration method is that it covers a wider range of moisture and, as a result, is more accurate and reliable when compared to the Single Point calibration method. The limitation is that it requires some dedicated time to get the calibration accurate for a particular grain to be dried.

Advanced Polynomial Calibration

Because of the limitations of the Single Point and Advanced Calibration methods, the Pinnacle Lite system offers a third method that allows for the input of the sensor manufacturer's certified calibration constants. This is the easiest method to apply and is the most accurate. Enabling the Advanced Polynomial Calibration option and selecting the Settings screen will display the advanced polynomial constants which are provided by the sensor manufacturer for a particular type of grain and sensor type.



Similar to third party moisture testers, updated calibration data is occasionally made available for different grain types used with different sensor types. The default values that are loaded are for standard Corn being used with a moisture sampler that is equipped with the FP32C moisture sensor. Updated and/or new calibration constant for use with the Advanced Polynomial Calibration method will periodically be made available for other grains or hybrid varieties of Corn.

In the event that these constants need to be changed or updated, simply touch the value and enter the




updated value. This should only be done as directed by your dealer or Mathew Company personnel.

Although this calibration data is provided by the sensor manufacturer, it is possible that there may be a discrepancy between the correlation of sensor voltage and the moisture reading on the sensor. This discrepancy would be due to the type, variety or hybrid of grain that was used to perform the certified calibration by the sensor manufacturer. In the event that there is a consistent discrepancy, for example, consistently 1.3% low or high from what your 3rd party moisture sensor is reading, there is a feature that you can employ to close the gap of this discrepancy. On the calibration screen when the advanced polynomial calibration mode is selected, you will see the up and down arrows which allows you to make minor adjustments to the offset of the sensor. If your display is consistently showing the measured grain moisture to be 1.3% lower than your 3rd party moisture tester, you will want to add a positive offset adjustment, by increasing to +1.3%. After a few minutes, you will see the results of the adjustment and your moisture display should be more consistent with your 3rd part testing equipment.

System Configuration

Selecting the System Configuration chapter button will take you to the System Configuration screen which provides the ability to change various system parameters. Most of the system configuration will be performed at the factory and will not need to be changed by the operator.

System Configuration (Basic)



The system configuration parameters are presented below with a brief description of their purpose:

Customer

The Customer name input is used for system identification and personalization throughout the program interface.

Model Number



The Model Number refers to the Mathews Company dryer model. This is a factory configured setting that will enable or disable features that are unique to a given dryer model.

Dryer Serial Number

The Dryer Serial Number is logged at the factory for system identification purposes.

Number of Blowers

The Number of Blowers is based on the dryer type and does not require an input. Based on the dryer model number that is selected, the corresponding number of blowers will be selected.

Discharge Capacity

The Discharge Capacity parameter is what the system uses to determine how many bu/hr the system is discharging. This also determines the total amount of grain dried. The only time this parameter should be changed is when adjustments need to be made based on measured operational data. If it is determined that the displayed bu/hr meter shown on the Dryer Overview screen, the Analog Inputs & Outputs screen or the Screen Saver screen is inaccurate, the following procedure should be followed to calibrate the discharge capacity:

1. Run the discharge constant for a set duration of time (minimum 30 min) and record the Metering Speed (RPM) from the Discharge Speed Analog Output.
2. Multiply the recorded Metering Speed (RPM) by the number of minutes the test was conducted. This will be the number of revolutions that the metering system turned over the course of the test.
3. Determine how much grain was discharged from the dryer by either unloading the grain to a truck which can be weighed or (b) determining how much of a particular bin was filled during the time duration of the test. If bin volume is used, the total number of bushels or cubic meters will then be obtained. If grain weight is used, convert to volume based on the test weight of the grain.
4. Once the total volume of grain has been determined, divide that value by the number of revolutions calculated in step number 2 above. This value will now have units of bu/rev or m³/rev depending on what units are being used.
5. Update the Discharge Capacity parameter on the Factory Settings screen and select the Save Settings button.

Discharge Configuration

The Discharge Configuration refers to the type of dryer discharge arrangement the dryer is equipped with. Available options are "center dump" or "auger." This parameter properly displays the dryer discharge configuration on the dryer overview screen.

Total Grain Dried

The total grain dried value is a bushel counter that refers to the total number of bushels that the dryer has processed.



Grain Dried

The grain dried value is a bushel counter that refers to the number of bushels that the dryer has processed since the Reset Grain Dried button has been pushed.

Reset Grain Dried

The Reset Grain Dried will reset the Grain Dried bushel counter back to zero.

Lifetime Hours

The Lifetime Hours is an hour counter that refers to the total number of hours that the dryer has been in operation.

Resettable Hours

The Resettable Hours is an hour counter that refers to the number of hours that the dryer has been in operation over a defined length of time.

Reset Hours

The Reset Hours button will reset the resettable hours counter back to zero.

Screen Saver

The screen saver setting determines how long the touchscreen will wait before going into screen saver mode.

Date

The displayed Date is a system parameter that can be changed by the user.

Time

The displayed Time is a system parameter that can be changed by the user.

HMI Version

The HMI Version refers to the software version of the HMI (Human Machine Interface) currently installed on the system.

PLC Version

The PLC Version refers to the software version of the PLC (Programmable Logic Controller) currently installed on the system.

Brightness

Use the Brightness adjustment to increase or decrease the HMI screen brightness.

Fill Switch Bypass

The Fill Switch Bypass toggle is used to bypass the In-feed Bin switch. Bypassing the bin switch will remove safeties associated with lighting the burner and should only be used for testing or diagnostic purposes. Use this toggle with caution.



Bypass Air Pressure

The Bypass Air Pressure toggle enables or disables the Air Pressure switch. Bypassing the Air Pressure switch will remove safeties associated with lighting the burner and should only be used for testing or diagnostic purposes. Use this toggle with caution.

Soft Start

If the dryer is equipped with a Soft Start, this toggle will be enabled by the factory.

CGA Gas Train

If the dryer is equipped with a CGA-Approved Gas Train, this toggle will be enabled by the factory. A CGA approved gas train will include high and low gas pressure switches.

Enable Gas Valve Limits

The Fuel Control Valve Opening % set point is limited by the minimum and maximum valve opening % allowed by the dryer.


System Configuration (Advanced)

In the upper left hand corner there is a login button to provide dealer and factory level access to advanced system configuration parameters. Upon logging in, the background color will change to an orange color indicating that you have logged into the system:



Additionally, a Next arrow will now appear in the lower right hand corner and upon selecting the Next button, you will be taken to the advanced system configuration screen:






The advanced system configuration parameters are presented below with a brief description of their purpose. The first section of the advanced system configuration screen is the features enable section which is used to select what options the dryer is equipped with. These settings will be done during system software configuration and testing at the Mathews Company facility, however your dealer or Mathews Company service personnel may make adjustments based on addition of upgrades or retrofits.

Moisture Sensor

The presence of a moisture sensor on the discharge and the infeed of the dryer can be selected. The option to select an infeed moisture sensor requires the presence of a discharge moisture sensor. Once a discharge moisture sensor is selected, you will have the option to specify what type of sensor is installed and whether or not the sensor is mounted in a sampler assembly. Correctly selecting the model of the moisture sensor will ensure that the proper temperature scaling is used and the presence of the moisture sampler assembly will enable the Advanced Linear and Advanced Polynomial calibration methods. The same applies to the infeed sensor as well. In order to determine the correct moisture sensor installed on your machine, see the images below to correctly identify the physical sensor with the model:



FP21C Moisture Sensor



FP32C Moisture Sensor

Bypass Prox Switch

The Bypass Prox Switch enable will allow the discharge to run unmonitored without checking for the presence of a rotating discharge metering shaft. This feature is only used as directed by M-C service personnel or for demonstration purposes on tabletop Pinnacle Lite demonstration units.

Enable Alarm Beacon

The alarm beacon is used to annunciate alarms with either a flashing red or green lamp on the outside of the high voltage cabinet. This feature is only selected if the machine is equipped with this hardware. Once this procedure has been followed, the discharge capacity has now been calibrated.

Minimum VFD Speed

The Minimum VFD Speed setting will correlate with what has been programmed on the discharge metering VFD. This value allows for the calculation of the VFD Frequency displayed on the Discharge Speed Analog Output screen.

Maximum VFD Speed

The Maximum VFD Speed setting will correlate with what has been programmed on the discharge metering VFD. This value allows for the calculation of the VFD Frequency displayed on the Discharge Speed Analog Output screen.

Maximum Discharge Motor Speed

The Maximum Discharge Motor Speed setting will correlate with what has been programmed on the discharge metering VFD. This value allows for the calculation of the Motor Speed displayed on the Discharge Speed Analog Output screen.

Mid-Grain Temp PID Setpoints

The purpose of the Mid-Grain Temp PID Values is to set the Proportional, Integral, and Derivative parameters of the TruDry PID control loop. Please note that changes to these parameters will drastically impact the operation of the dryer when running in TruDry mode and any settings change should only be done when instructed by Mathews Company service personnel.

On the left side, values for the Proportional, Integral, and Derivative parameters can be adjusted. On the right side you will see the mid-grain temperature setpoint and the actual mid-grain temperature. The default values for the Proportional, Integral, and Derivative parameters are recommended to be used. If fine-tune adjustments need to be made, the following explains the impact of each parameter:

Proportional - The Proportional parameter determines the gain of the control loop based on the difference between the setpoint and the actual value. Adjustment of this parameter will increase or decrease the gain when a difference between the setpoint and actual value is established.

Integral - The Integral parameter determines the responsiveness of the control loop from a time standpoint. Adjustment of this parameter will cause the control loop to become more or less responsive.
Derivative - The Derivative parameter determines the amount of dampening that the control loop will exhibit. Adjustment of this parameter will increase or decrease the amount of overshoot that is observed by the control loop.



Plenum Temp PID Setpoints

The purpose of the Plenum Temp PID Values is to set the Proportional, Integral, and Derivative parameters of the Plenum Temperature PID control loop. Please note that changes to these parameters will drastically impact the operation of the dryer when controlling the plenum temperature and any settings change should only be done when instructed by Mathews Company service personnel.

On the left side, values for the Proportional, Integral, and Derivative parameters can be adjusted. On the right side you will see the mid-grain temperature setpoint and the actual mid-grain temperature. The default values for the Proportional, Integral, and Derivative parameters are recommended to be used. If fine-tune adjustments need to be made, the following explains the impact of each parameter:

Proportional - The Proportional parameter determines the gain of the control loop based on the difference between the setpoint and the actual value. Adjustment of this parameter will increase or decrease the gain when a difference between the setpoint and actual value is established.

Integral - The Integral parameter determines the responsiveness of the control loop from a time standpoint. Adjustment of this parameter will cause the control loop to become more or less responsive.




Derivative - The Integral parameter determines the amount of dampening that the control loop will exhibit. Adjustment of this parameter will increase or decrease the amount of overshoot that is observed by the control loop.

Troubleshooting

Alarms are presented to the user in three ways: (1) As pop ups when the alarm condition occurs, (2) A recorded event in the Alarms chapter, or (3) By means of the red and green stack light mounted to the High Voltage cabinet (if equipped).

Alarm Pop-Ups and History

When an alarm condition occurs, a popup will appear on the screen detailing the reason for the alarm and what type of alarm it is. Press the "Accept" button to acknowledge the alarm and return to the previous screen.



To navigate to the alarm history, press the Faults icon on the bottom navigation bar. The alarm history shows a brief description of the alarm as well as the date it was recorded:



Stack Light Status (if equipped)



Alarm Color Indication	Description
Solid Green Light	Control Power On Not Discharging
Pulsing Green Light	Dryer Is Discharging
Pulsing Green & Red Light	Dryer Is Discharging With Active Warning Alarms
Flashing Red Light	Dryer Has Shutdown

The screenshot shows the Pinnacle control interface. At the top, it displays 'PINNACLE TruDry Technology', 'Model #: 101375', 'Serial #: 590008', and 'Date & Time: 08/27/2012 15:45:39'. Below this is a table of alarm history:

Name	Time	Date	Accept
Master Control Relay (MCR) De-Energized	15:45:01	08/27/2012	-----
Master Control Relay (MCR) De-Energized	15:44:55	08/27/2012	-----
Linear Limit Fire Alarm	15:44:36	08/27/2012	-----
Master Control Relay (MCR) De-Energized	15:44:36	08/27/2012	-----

Below the table is a navigation bar with icons for: Dryer Overview, Dryer Operation, Setpoints, Faults, Trending, PLC I/O, System Configuration, Manuals & Datasheets, and Exit Runtime. On the right side, there are sections for 'Operational Overview' (Operation Mode: Automatic, Discharge Mode: Manual) and 'Equipment Overview' (Blower(s), Dryer Fill, Burner, Discharge). An 'Alarm Reset' button is also present.

The alarms are in reverse chronological order so that the most recent alarms will always appear at the top. Alarms that have been acknowledged are shown in yellow. Alarms that have been resolved appear in green. Scroll to the right using the scroll bar or arrows to show the date/time of the alarm and the date/time that it was accepted from the initial pop up. Selecting a row from the alarm history list will pull up screen that explains the type of alarm, the ID code of the alarm and the cause of the alarm:

The screenshot shows an 'Alarm Help' dialog box with a close button (X) in the top right corner. The text inside the dialog is as follows:

!!! Warning Alarm !!!

Name: Discharge Moisture High Limit

Type: Type A, Warning Only

ID Code: 30

Cause: The discharge moisture has exceeded the discharge moisture high limit setpoint for a duration of 5 minutes while the discharge metering is running



Alarm Types

Alarm messages pop up in full-screen warnings that are color coded based on the severity of the fault condition.

Type A faults are displayed in yellow and are warnings only.

Type B faults are displayed in orange and send the dryer into cool-down mode.

Type C faults are displayed in red and are the most serious, sending the dryer into shut-down mode.

In addition to the type of fault, the popup will display the name, ID code and a description of the cause.

Even though the alarm has been accepted/acknowledged, the fault is still active. Once the condition causing the fault has been rectified, the alarm reset button can be pressed on the vertical side bar to clear the alarm from the active alarm list.

A list of all alarms names, alarm type, ID codes, and cause is presented in the following table.

Alarm Popup Name	Alarm ID Code	Type	Cause
Master Control Relay (MCR) De-Energized	1	Type C	The MCR has become de-energized due to lost power or a tripped safety circuit.
Linear Limit Fire Alarm	2	Type C	Linear Limits Circuit is Open - One of the LLC switches has opened due to high temperature
High Gas Pressure	3	Type B	High gas pressure detected in the gas train.
Blower(s) Overload	6	Type C	Overload detected for blowers – Check motor circuit protector or soft starter if equipped.
Blower #1 Motor Starter	7	Type C	Blower #1 motor starter has experienced a fault condition.
Blower #1 Air Pressure	8	Type A	Blower #1 is not providing adequate pressure for burner operation.
Blower #1 Air Pressure Switch	9	Type B	Blower #1 air pressure switch is indicating air pressure when the blower is not operating.
Blower(s) Tri-Start	11	Type C	One of the two contactors A or B has experienced a fault condition.
Blower #2 Motor Starter	12	Type C	Blower #2 motor starter has experienced a fault condition.



Blower #3 Motor Starter	13	Type C	Blower #3 motor starter has experienced a fault condition.
Blower #2 Air Pressure	14	Type A	Blower #2 is not providing adequate pressure for burner operation.
Grain Fill Timeout	16	Type B	Infeed grain fill is insufficient to maintain grain level.
Burner Ignition Failure	18	Type B	Burner failed to ignite after 3 trials.
Burner High Limit	19	Type C	Plenum temperature has reached high limit setpoint.
High Plenum Temperature	20	Type C	The plenum temperature has risen outside of the plenum temperature band.
False Flame	21	Type B	The flame sensing system has detected the presence of a flame with the burner off.
Low Plenum Temperature	22	Type B	Plenum temperature has dropped below the low limit setpoint.
Plenum Temperature RTD Failure	23	Type B	The plenum RTD input module on the PLC has detected a fault.
Low Gas Pressure	24	Type B	Low gas pressure detected in the gas train.
Discharge VFD	25	Type C	The Discharge VFD has detected a fault due to a possible overload of the metering system.
Discharge Level	26	Type C	The discharge level switch is open due to a possible overload of grain or a blocked discharge takeaway system.
Discharge Jam or Proximity Switch Failure	28	Type B	The Discharge metering system has stopped running. The proximity sensor is not detecting rotation of the metering system.
Discharge Moisture Low Limit	29	Type A	The discharge moisture has dropped below the discharge moisture high limit set point for a duration of 5-minutes while the discharge metering is running.
Discharge Moisture High Limit	30	Type A	The discharge moisture has exceeded the discharge moisture high limit setpoint for a 5-minute duration while the discharge metering is running.
Blower #3 Air Pressure	31	Type A	Blower #3 is not providing adequate pressure for burner operation.
Blower #2 Air Pressure Switch	33	Type B	Blower #2 air pressure switch is indicating air pressure when the blower is not operating.



Blower #3 Air Pressure Switch	34	Type B	Blower #3 air pressure switch is indicating air pressure when the blower is not operating.
Mid-Grain Band	35	Type A	The mid-grain temperature has exceeded or dropped below the mid-grain band alarm setpoint for a 30-second duration.
Mid-Grain Band Delay	36	Type B	The mid-grain temperature has exceeded or dropped below the mid-grain band alarm setpoint for the duration of the mid-grain band delay.
Mid-Grain Temperature Probe #1	37	Type A	The #1 mid-grain temperature probe has failed or become disconnected from the transmitter.
Mid-Grain Temperature Probe #2	38	Type A	The #2 mid-grain temperature probe has failed or become disconnected from the transmitter.
Mid-Grain Temperature Probe #3	39	Type A	The #3 mid-grain temperature probe has failed or become disconnected from the transmitter.
Mid-Grain Temperature Probe #4	40	Type A	The #4 mid-grain temperature probe has failed or become disconnected from the transmitter.
Mid-Grain Temperature Probe Transmitter #1	41	Type A	The #1 mid-grain temperature probe transmitter in the junction box has failed or become disconnected.
Mid-Grain Temperature Probe Transmitter #2	42	Type A	The #2 mid-grain temperature probe transmitter in the junction box has failed or become disconnected.
Mid-Grain Temperature Probe Transmitter #3	43	Type A	The #3 mid-grain temperature probe transmitter in the junction box has failed or become disconnected.
Mid-Grain Temperature Probe Transmitter #4	44	Type A	The #4 mid-grain temperature probe transmitter in the junction box has failed or become disconnected.
Linear Limit #1 Fire Alarm	45	Type C	Linear limits circuit #1 is open – One of the LLC #1 circuit switches has opened due to high temperature.
Linear Limit #2 Fire Alarm	46	Type C	Linear Limits Circuit #2 is open - One of the LLC #2 circuit switches has opened due to high temperature
Linear Limit #3 Fire Alarm	47	Type C	Linear Limits Circuit #3 is open - One of the LLC #3 circuit switches has opened due to high temperature