

PINNACLE 20 20

CONTROLS MANUAL

Model Year 2019



GRAIN DRYER SPECIALISTS

CONTROLS MANUAL - PINNACLE 20 | 20



© 2019 Mathews Company 500 Industrial Avenue Crystal Lake, IL 60012 USA www.mathewscompany.com

Warranty Statement

MATHEWS COMPANY LIMITED WARRANTY FOR WHOLE GOODS

Except as otherwise set forth herein, Mathews Company (Seller) warrants that the equipment supplied by Seller to Buyer shall be free from defects in materials and workmanship when properly installed and operated under normal conditions and in accordance with all applicable instruction manuals. This limited warranty shall expire two (2) years from the date of shipment from Seller's Crystal Lake, Illinois, U.S.A. facility. In addition, for a period of five (5) years from the date of shipment from Seller's Crystal Lake, Illinois, U.S.A. facility, Seller will re-balance M-C Shredder rotors for Buyer at Seller's Crystal Lake, Illinois, U.S.A. facility, provided that the rotors did not become unbalanced through abnormal use by Buyer or were not damaged by Buyer in any way.

To obtain consideration under this limited warranty, Buyer must first notify Seller in Crystal Lake, Illinois, U.S.A., stating in what respects the equipment is believed by Buyer to be defective and providing a list of the parts at issue. Additionally, Buyer must complete a warranty request form stating the machine serial number. Upon receipt by Seller of such notice from Buyer, Buyer may receive authorization from Seller to return the parts. If parts are to be scrapped locally, Buyer will be so advised. If Seller provides Buyer with authorization to return the parts, Buyer shall return such parts to Seller's facility in Crystal Lake, Illinois, U.S.A., transportation prepaid, for examination by Seller. No parts shall be returned to Seller unless Buyer first obtains a return authorization number from Seller. If, in Seller's sole judgment, the parts returned by Buyer are defective and covered under this limited warranty, Seller shall have the option of repairing, rebuilding or replacing such parts. This limited warranty shall not apply to parts which, in Seller's sole judgment, have been the subject of negligence, abuse, accident, misapplication, tampering, alteration, improper adjustment, or electrical problems caused by low voltage conditions; nor shall it apply to consumables, such as belts; nor shall it apply to parts damaged by acts of God, war or civil insurrection, acts of terrorism, improper installation, operation, maintenance or storage, or other than normal application, use or service, including, without limitation, operational failures caused by corrosion, erosion, wear and tear, rust or other foreign materials in the system in which they are utilized.

Failure to give notice within the warranty period shall be a waiver of this limited warranty and no assistance or other action thereafter taken by Seller shall be deemed to extend or revive the warranty period. This limited warranty covers only whole goods and shall not apply to replacement parts or upgrade kits. A separate warranty statement published by Seller covers the warranty on parts and upgrade kits. This limited warranty shall not apply to any products, parts, accessories or other equipment not manufactured by Seller, provided that Seller, upon request by Buyer, shall advise Buyer of any warranties known to Seller that may be offered by the manufacturer of such equipment. This limited warranty shall not cover, and Seller shall not under any circumstances be liable for, damages for injuries to persons or property; loss of crops or other products; losses caused by harvest delays; loss of profits; loss of use; cost of rental equipment; expenses of labor, travel or other items relating to the removal or replacement of defective parts; damages resulting from the removal of defective parts or the installation of repaired, rebuilt or replaced parts; expenses relating to the transportation of parts to and from Seller's facility; any consequential, incidental, contingent or special damages, whether arising in contract, in tort or under statute; or any other damages or expenses not agreed upon in writing by Seller, even if Seller has been advised of the potential for any such damages or expenses.

THIS LIMITED WARRANTY IS IN LIEU OF ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ALL WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE OR USE.

No person is authorized to give any other warranty or to assume any other liability on Seller's behalf.

Table of Contents

	i	Introd	uction	1.1
	ر		Overview	1.1
			Touch Screens	1.1
			Home Screen	1.2
	0	Opera	tion	2.1
(Control	2.1
			Control Power	2.1
			Fans and Burners	2.2
			Grain Fill and Discharge	2.3
			Quick Launches	2.3
			Overview	2.4
			Graphics	
			Read and Write Values	2.5
			Monitor	
			Discharge Information	2.6
			Trending Graphs	2.6
			Running Data	2.6
		System	n Settings	3.1
(ر	-	Fan Settings	3.1
			Fan Control Buttons	3.2
			Cool Down and Takeaway Timers	3.2
			Takeaway Equipment Settings	3.2
			Discharge Speed	3.3
			Discharge System	3.3
			Discharge Graphic	3.4
			Discharge Sequencing Chart	3.4
			Grain Fill Settings	3.4
			Fill System	3.5
			Fill Graphic	3.6
			Fill Sequencing Chart	3.6
			Moisture Sensor Settings	
			Moisture Alarms	
			Temperature Alarms	
			Sensor Calibration	
			Burner Settings	
			Discharge Speed Control	
			Manual Settings	
			TruDry Settings	
			AccuDry Settings	
	(2)	Histori	cal Data	
			Alarm Pop-Ups and History	4.1
			Alarm List	4.3
			Cool Down Alarms	4.14
			Trending	4.17
			Data Logging History	
			55 5 1	

Troubleshooting	5.1
Service	
Configuration and Features	5.2
TruDry Settings	5.3
AccuDry Settings	5.4
Burner Settings	
HMI Settings	5.6
Dryer Components	5.7
System Configuration	5.10
PLC I/O Modules	5.11
Safety Circuit	5.20
Notes	6.1

Introduction

Overview

This volume of the manual is intended to provide you with a thorough overview and explanation of the touch screen software that interfaces with the Programmable Logic Controller (PLC). All possible features of the current Pinnacle 20|20 software (HMI version 19.32.0610.XX and PLC version 19.31.1200.XX, where XX refers to a minor revision, 01, 02, etc.) will be explained.

Pinnacle 20|20 is the latest member of the Pinnacle family of control systems. The Pinnacle 20|20 is a completely PLC-controlled system that does not include any buttons or switches as all operator control is done through two large touch screens.



Pinnacle 20/20 Remote Cabinet

The Pinnacle 20|20 control system's components are located in the High Voltage Cabinet, Low Voltage Cabinet and the Remote Control Cabinet. The high voltage components such as the motor controls are located in the High Voltage Cabinet. The low voltage components, such as the PLC, are located in the Low Voltage Cabinet, and the HMIs are located in the Remote Control Cabinet.

Touch Screens

Pinnacle 20|20 comes equipped with two separate HMI touch screens. Each screen works independently from the other. There are no restrictions to viewing pages on either touch screen. The user can choose to display the same page or different pages on both touch screens. Commands made through either touch screen will be reflected on both screens.

DOC-PT02-0219 Introduction 3

Home Screen

The Pinnacle 20|20 control features a Home screen where all the features of the control can be accessed. The top half of the Home screen contains the dryer information, date and time. The middle of the Home screen features 3 tiles that cover the operation of the dryer. *Note that the graphics for these 3 tiles will vary depending on the model dryer that is loaded on the control.* At the bottom of the Home screen are 3 tabs that contain the System Settings, Historical data, and Troubleshooting tiles. Clicking on these 3 tabs at the bottom will open a different menu of blue tiles to chose from. Shown below is the menu associated with the Troubleshooting tab.



The touch screen allows you to not only monitor parameters, but to also change operational and alarm set points. For the most part, values that can be changed will be displayed as black text with a white background. Values that display in green with the dark gray background are read-only values and cannot be changed.

Example of a displayed value that cannot be changed:



Example of a displayed value that can be changed:



Selecting a white field to change the numerical value will bring up a keypad. Depending on the input that is being changed, there may be a minimum and maximum range to the value which will be displayed on the keypad. When attempting to enter a value outside of the min/max range, the value will not be accepted. Once a suitable value has been entered, press "Enter" to input the value and be returned to the screen that the value was being entered on. If you do not wish to change the value, press "Esc" to return without making a change.



Many features throughout the control have a help button associated with it so that it's function or purpose can be readily explained. This will be indicated with a "?" button and simply pressing it will display a help message pop-up which can easily be closed by pressing the "x" button in the upper right hand corner.



DOC-PT02-0219 Introduction 1.3

Pinnacle 20 | 20 Controls Manual

Throughout the control, there are tiles that contain a blue triangle in the upper right corner. These blue triangles signify quick lauch tiles. Pressing a tile containing this blue triangle will navigate away from the current page and to a page containing features specific to that particular tile.



Other than the Home and pop up pages, all other pages contain a page header. In addition to the date and time, the header contains a "Back" button on the left and a "Home" button on the right. To navigate back to the previous screen, simply press the "Back" button. To navigate to the Home page, simply press the "Home" button. Every header contains an "Alarm Reset" button as well. This button will turn red, yellow or orange in the event of an alarm. The color of the button will depend on the type of alarm present. Red alarms are critical, yellow are warnings and orange are Cool Down. If no other intervention or physical reset is needed, the alarm can be cleared from any page by simply pressing the Alarm Reset button. For orange, or Cool Down alarms, pressing the Alarm Reset will cause a pop up to appear allowing the user to cancel the Cool Down if so desired.





Operation

Control

When first starting the dryer, the Control page will need to be accessed. The Control page layout differs slightly from dryer model to dryer model. It is here where the Control Power, Grain Fill, Discharge, Fan, Blowers, and Burners can all be started from the same page. Each function such as Grain Fill, Discharge, Fans & Burners are grouped in boxes or tiles. It is within these tiles where the associated command buttons are located. The green buttons are "START" or "ON" buttons while the red buttons are "STOP" or "OFF" buttons. These command buttons are designed to communicate to the operator the feature's status and available function by way of color and text within the button. For a pair of buttons, one will have text within it that reads the status (ON, OFF, or RUNNING) while the other button will have text that reads the available command (TURN OFF, TURN ON, or STOP). The text and color within and around the buttons change as the status and available function changes.

Control Power

Shown below is the Control page for a tower or an all-heat ECO dryer. Before any function on the Control page can be performed, the Control Power must first be on. To turn Control Power on, simply press the green "TURN ON" button within the Control Power tile. There should be a slight delay while the safety circuit verifies satisfactory conditions. During this slight delay, the text within that same button should read "TURNING ON". If Control Power is achieved, the text within that same green button should then read "ON", a green glow should surround the button, and the text within the red button will change from "OFF" to "TURN OFF".



DOC-PT02-0219 Operation 2.1

Note: Failure to get Control Power will require troubleshooting. An initial place to troubleshoot for this would be the safety circuit. Reference the troubleshooting portion of this manual for more information.

Similarly, to turn Control Power off, press the associated red button that reads "TURN OFF" and the text within that button should change to "OFF" and the text within the associated green button should change from "ON" to "TURN ON", and the surrounding green glow should dissappear.

Fans and Burners

Once Control Power is on and there are no other issues preventing the starting of the other features, the dimly lit buttons will illuminate signaling that they are ready to start. Dimly lit buttons signify those features that are equipped on the dryer. Fully illuminated buttons are for features that are ready to be started or turned on. Those buttons that appear gray, are simply place holders for features that are not currently installed on the dryer. Below is an example of a Legacy Control page where the number of fans and burners vary depending on the model. For this reason, the Control page layout varies from model to model. Shown below is the Control page for a 2 burner Legacy dryer. Since the dryer is equipped with only 2 fans and 2 burners, controls for pelnums 1 and 2 are illuminated while plenums 3 and 4 are greyed out.

With Control Power on and the Fan Start buttons fully illuminated, the fans are ready to start. Starting the fans is the same as turning Control Power on. The green buttons activate while the red buttons deactivate. Both buttons communicate the status as well as control the function.



Notice the burner buttons are dimly lit. Dimly lit buttons signify features that are equipped on the dryer, but are not ready to be started or turned on. The burner buttons will not fully illumniate or be ready to start until the fans are running and air pressure is present. Once the fan status is "RUNNING" with a green glow surrounding the Start button and the air pressure is satisfied as illustrated with a green illuminated indicator, the burners can be started. Again, the buttons will communicate the available command and current status. For the burners, the start process is more complicated and it involves purging and trial for ignition. While the burners attempt to ignite, the associated buttons will communicate the current status of the ignition process via text within the buttons.



Next to each set of burner control buttons are read and write boxes. The read box in green text is the real time temperature inside that particular plenum. The white, write box, is where the operator can enter the desired temperature for that particular plenum.

Grain Fill, Discharge and Metering

The Grain Fill, Discharge and Metering tiles all contain control buttons to stop and start the fill, discharge, and metering motors. These buttons act in the same way as the rest of the buttons on the Control page by communicating the available function and current status.

Cool Down

The Cool Down funtion allows for a gracefull shutdown of the dryer. More on this function is explained in Section 4 of this manual.

Quick Launches

As mentioned in the Introduction of this manual, there are quick launch buttons throughout the software. The quick launch buttons allow the operator quick access to more in depth information and settings. They are typically located in ideal places where the subject matter of the quick launch is associated with a nearby

DOC-PT02-0219 Operation 2




Pinnacle 20 | 20 Controls Manual

function. On the Control page, the Safety Circuit quick launch is located next to the Control Power tile since issues with getting Control Power may be associated with a break in the Safety Circuit. Similarly, quick launches for the Grain Fill and Takeaway Equipment Settings are located next to the Grain Fill and Discharge tiles. Further details on these quick launch pages and their contents are explained in the System Settings, Historical Data and Troubleshooting chapters.

Overview

The Overview page is the second page of the three Operation pages. The Overview page provides the operator with a full rendering of the dryer that, with the use of different graphics, illustrates what components of the dryer are operating. The Overview page is unique to match the particular dryer that is loaded on the Pinnacle 20|20. The images below show the different Overview pages for a Legacy, Tower, ECO, and Delta dryer. In the Overiew pages, shown below, none of the dryer components (motors, burners, etc.) are running.



Graphic Explanation

The Overview page will change when different operations/features are running or turned off. The different graphics and their meaning are as follows:

Blue arrows: Indicate a fan is running.

Red arrows: Indicate a fan and burner are both running.

Blue and white burner flame: Only shown on tower dryers to further indicate the burner is on.

Blue plenum with blue arrows: Indicate a cooling plenum with the fan running.

Red plenum with red arrows: Indicate a heating plenum with the fan running and the burner on.

Sweep flashes green: Only shown on tower dryers to indicate the sweep is turning.


Area housing metering rolls flash green: Only shown on profile dryers to indicate the metering rolls are turning.

Hopper glows green: The fill is on. **Hopper flashes:** Level auger is running.

Green air pressure indicator: Air pressure switch is satisfied. **Gray air pressure indicator:** Air pressure switch is not satisfied.

In addition to these graphics, there are lines shown leading to the hopper and from the discharge. The line leading to the hopper contains two tags: Fill 1 and Fill 2. When the line is white, the fill cycle is off.

When the line is green, the fill cycle is on. When any of the tags blink, that particular part of the fill cycle is running. So while the Fill 1 or Fill 2 tags are green, but not blinking, it means it's enabled but currently not running. Only when it blinks does it mean that that particular portion, the Fill 1 or Fill 2, of the fill cycle is actually running. It is the same for the line exiting the discharge. When this line is white, it means the discharge is off. When the line is green, it means the discharge is on. A blinking Takeaway 1 or Takeaway 2 tag indicates that the Takeaway 1 or Takeaway 2, which ever is blinking, is currently running. A solid green Takeaway 1 or Takeaway 2 tag simply means it is enabled but not currently running.



Read and Write Values

The Overview page also contains information on the real-time plenum temperature, discharge speed, and if equipped, the values from the inlet and outlet sensors. The values in green text are the actual values being read. The values shown in a white box with black text are desired or "Set" values that can be changed by the operator. The ability to adjust the "Set" values associated with Mid-Grain Temp, Discharge Speed, and Outlet Sensor Moisture is dependant on the selected discharge mode. If Manual mode is selected, the Discharge Speed "Set" value will be able to be adjusted. If TruDry is selected, the Mid-Grain Temp "Set" value will be able to be adjusted. Finally, if AccuDry is selected, the Outlet Sensor "Set Moist" value, which is the desired outlet grain moisture, will be able to be adjusted. One value that can always be adjusted, regardless of selected discharge mode, is the plenum temperature(s).

DOC-PT02-0219 Operation 2.5



Monitor

Discharge Information

The Monitor Page is the third of the three Operation pages. The Monitor page is divided into thirds. The top third contains quantitative values that can either be read or adjusted. The operator can also change between discharge modes from here. However, it is important to note that when changing between TruDry and AccuDry, the operator must change to Manual mode first before changing to TruDry or AccuDry.

Another area where the operator can change discharge modes and make adjustments to the discharge settings is in the Discharge Speed Control quick launch. More on the contents within the Discharge Speed Control page can be viewed in the Settings chapter of this manual.



Trending Graphs

In the middle of the Monitor page a quick view of different trending graphs is displayed. The graph shows up to 2 hours of recorded data. The operator can choose which trending graph to display on the Monitor page by selecting either the Moisture Trending button or Mid-Grain Trending button. Selecting these buttons will cause the display to toggle between these two graphs. The button highlighted in green indicates the graph that is currently being displayed on the Monitor page.

If more information about the trending graphs is desired, the operator can quickly access it by simply pressing the "More Trending Options" button. This quick launch contains larger graphs, with more information which is further explained in the Historical Data chapter of this manual.


Running Data

The bottom third of the Monitor page is where a table containing historical running data is displayed. The data displayed is grouped into rows that correspond to a date and time at which those values were recorded. A row of data is recorded every 10 minutes, spanning a total of two hours. The data that makes up this two hour graph is collected whether the dryer is discharging or not. More data can be accessed by pressing the More Data History quick launch button.



System Settings

At the bottom of the Pinnacle 20|20 Home page, there are 3 tabs: System Settings, Historical Data, and Troubleshooting. Pressing any of these 3 tabs will cause the tab to turn blue and a different set of options, shown as blue tiles, to appear. These options will change if a different tab is selected. The Pinnacle 20|20 control system has features that are customizable with several settings that can be changed as necessary. The System Settings tab are where these customizable features can be found. Section 3 of this manual will explain these features in detail and how to properly set these features.



Fan Settings

The first of the six options under System Settings is Fan Settings. By selecting the Fan Settings option, the operator will be taken to a page dedicated to all settings pertaining to the fans.



Regardless of dryer model, this page will have a section containing the Fan Control buttons and another section containing Cool Down and Takeaway timers. The Tower, ECO and Delta Fan Settings page also contain quick launch buttons at the bottom for specific components that relate in some way to the fans. This is common on many pages of the Pinnacle 20|20 control. If space allows, there will be quick launches for components that are related to the features on that particular page. Since space is lacking on the Legacy Fan Settings page, those quick launches are not present at the bottom.

DOC-PT02-0219 System Settings 3.1



Fan Control Buttons

On the Fan Settings page are the buttons used to stop and start the fans. The functionality of these buttons are the exact same as the Fan Control buttons on the Control page which was discussed in Chapter 2. In addition to the control buttons, there are Air Pressure indicator lights. The Air Pressure indicator light will appear gray when the air pressure switch is not satisfied. However, when the air pressure switch senses enough air pressure to satisfy the switch, the indicator light will illuminate green to indicate this scenario.

Cool Down and Takeaway Timers

On the Fan Settings page, there is a section dedicated a timer associated with the Fan(s) and it is called the Cool Down Timer.

Cool Down Timer

The Cool Down Timer is an adjustable timer that determines the length of time that the dryer will be placed in Cool Down mode following a type-B fault. When activated, the numbers in green font, under Actual, will countdown until the timer expires. At that time, the dryer will shutdown.

Takeaway Timer

The Takeaway Timer is an adjustable timer that determines the length of time the takeaway equipment will continue to run for after the metering stops.

Takeaway Equipment Settings

The second of the six options under System Settings is Takeaway Equipment Settings. By selecting the Takeaway Equipment Settings option, the operator will be taken to a page dedicated to all settings pertaining to the takeaway.



Just as can be done on the Control page, the discharge system can be started and stopped from the Takeaway Equipment Settings page as well and the buttons behave in the same manner.

Discharge Speed

The upper section of the Takeaway Equipment Settings page features a rendering of the takeaway portion of the dryer as well as some values in boxes labeled Discharge Speed. It is in the box labeled "Act" where the actual metering, or sweep speed, is shown and in the box labeled "Set" where that speed can be changed provided the dryer is discharging in manual mode.

Discharge system

It is important to have a good understanding of the discharge system and it's design. This design provides versatility for different dryer sites. Some sites will utilize the features and components that make this system versatile while others will not need to. The features that provide this versatility are the signals and timers. This system provides two signals. They are named Takeaway 1 and Takeaway 2.

Takeaway 1 Signal

The Takeaway 1 signal runs the discharge auger on profile dryers as well as any other equipment that is connected to it. Any other equipment that shares the Takeaway 1 signal will start and stop with the discharge auger of a profile dryer. Since the tower dryers do not have a discharge auger, nothing is connected to the Takeaway 1 signal from the factory. However, the signal is there to be used to run other equipment if so desired.

Takeaway 2 Signal

The Takeaway 2 signal is meant for equipment further downstream from equipment tied to the Takeaway 1 signal. Again, this signal is provided for convenience and is only to be used to run other equipment if so desired.

In addition to these signals are two, PLC timers. These timers, the Takeaway 1 Start Delay timer and the Takeaway 2 Stop Delay timer, are both adjustable.

Takeaway 1 Start Delay

This is an adjustable timer inside the PLC that delays the start of the dyer's metering system. The timer starts its countdown once the Takeaway Start button is pressed and equipment tied to the Takeaway 2 signal starts operating. When the timer expires all equipment using the Takeaway 1 signal will start.

Takeaway 2 Stop Delay

This is an adjustable timer inside the PLC that determines how long to run the Takeaway 2 equipment after the Takeaway Stop button has been pressed. The timer starts once the Takeaway Stop button has been pressed and continues to run the Takeaway 2 equipment until the timer expires.

Takeaway 1 and 2 Jog

These two jog buttons enable the user to momentarily turn equipment on that are tied to these signals. This is useful when there is a back up or blockage of grain. Pressing and holding the Takeaway 1 Jog button will turn on all equipment tied to the Takeaway 1 signal for as long as the button is pressed. Releasing the button will stop the equipment. The Takeaway 2 Jog button works the same way for equipment tied to the Takeaway 2 signal.

Metering

The metering buttons only control the metering. They do not control the takeaway.

Discharge Graphic

Pinnacle 20 | 20 Controls Manual

This graphic is used to give a real-time illustration of the operating components of the discharge system. When the sischarge system is off, nothing on the graphic will be illuminated and the line exiting the dryer with the Takeaway tags will be white. Once the Discharge system is turned on, the Metering, along with the line exiting the dryer with the Takeaway tags will illuminate green. A flashing green graphic of any portion of the Discharge system indicates that the equipment for that particular portion of the system is currently running.

Discharge Sequencing Chart

The bottom half of the Takeaway Equipment Settings page contains a chart that illustrates the sequencing of the discharge system and associated timers. The green, horizontal lines within this chart indicate when different operations are starting, running, and shutting down. Under this chart are the two, previously discussed, adjustable timers used to control the timing of the equipment associated with the discharge system.

Discharge Start-Up Sequence


Following the logic of the chart, pressing the Discharge start button will cause the start up of the Takeaway 2 equipment. At the same time, the Takeaway 1 Start Delay timer will begin its countdown. Once the countdown expires, the Metering and Takeaway 1 equipment will begin operating.

Discharge Shut-Down Sequence

Following the logic of the chart, pressing the Discharge stop button will immediately stop the metering and equipment associated with Takeaway 1. At the same time, the Takeaway 2 Stop Delay timer will begin its countdown. Once the countdown expires, Takeaway 2 equipment will shut down.

Grain Fill Settings

The third of the six options under System Settings is Grain Fill Settings. By selecting the Grain Fill Settings option, the operator will be taken to a page dedicated to all settings pertaining to the filling the dryer with grain.



Just as can be done on the Control page, the fill system can be started and stopped from the Grain Fill Settings page as well and the buttons behave in the same manner. The Grain Fill Settings page layout is very similar to that of the Takeaway Equipment Settings page.

Fill System

Before moving on to the different features of the Grain Fill Settings page, it is important to have a good understanding of the Grain Fill System and it's design. The design provides versatility to accomdate different dryer sites. Some sites will utilize these features while others will not need to. The features that provide this versatility are the signals and timers. This system provides two signals and four timers.

Fill 2 Signal

The Fill 2 runs the level auger on profile dryers as well as any other equipment that is connected to the Fill 2 signal. Any other equipment that shares the Fill 2 signal will start and stop with the level auger of a profile dryer. Since the tower dryers do not have a level auger, nothing is connected to the Fill 2 signal from the factory. However, the signal is there to be used to run other equipment if so desired.

Fill 1 Signal

The Fill 1 signal is provided for equipment further upstream from Fill 2 equipment. Again, this signal is provided for convenience and is only to be used to run other equipment if so desired.

Grain Flow Timer

This is an adjustable timer that is started once the Grain Fill is started. If the set time for this timer elapses before the Rotary Bin Switch paddle in the hopper stops rotating, it will be assumed there is no more grain to fill the dryer with and the dryer will enter a Cool Down mode.

Fill 1 Start Delay

This is an adjustable timer that is started once the paddle of the Rotary Bin Switch in the hopper begins to rotate. Paddle rotation is used to sense the lack of grain. When the Rotary Bin Switch begins to rotate, the call for grain is started and if equipped, the Fill 2 equipment and level auger will start running. The time entered for the Fill 1 Start Delay is the time that needs to elapse before Fill 1 equipment is turned on.

Fill 1 Stop Delay

The Fill 1 Stop Delay is a timer that decides when to turn the Fill 1 equipment off. The timer starts when the Rotary Bin Switch paddle stops rotating, ending the call for grain. Once the entered time value for this timer expires, the Fill 1 equipment will turn off.

Fill 2 Stop Delay

The Fill 2 Stop Delay is a timer that decides when to stop the Fill 2 equipment and level auger if equipped. After the Fill 1 Stop Delay timer expires, shutting down the Fill 1 equipment, the Fill 2 equipment and level auger will continue to run for the allotted time entered for the Fill 2 Stop Delay timer.

Fill From Empty

This feature is typically used when filling an empty or near empty dryer. Checking the Fill From Empty box ignores the Grain Flow timer, allowing ample time for the dryer to be filled with grain from an empty state. After the dryer is filled, this box is automatically unchecked, allowing the PLC to control the automatic fill cycle of the dryer during operation.

DOC-PT02-0219 System Settin



Fill Graphic

This graphic is used to give a real-time illustration of the operating components of the Grain Fill System. When the Grain Fill System is off, nothing on the graphic will be illuminated and the line entering the dryer with the Fill 1 and Fill 2 tags will be white. Once the Grain Fill System is turned on, the Hopper, Fill 1 and Fill 2 will illuminate green. A flashing green graphic of any portion of the Grain Fill System indicates that the equipment for that particular portion of the system is currently running.

Fill Sequencing Chart

The bottom half of the Grain Fill Settings page contains a chart that illustrates the sequencing behind the Grain Fill System and associated timers. The green, horizontal lines within this chart indicate when different operations are starting, running, and shutting down. Under this chart are the previously discussed, adjustable timers used to control the timing of the equipment associated with the Grain Fill System.

Grain Fill Start-Up Sequence

Following the logic of the chart, the grain fill sequence starts with a call for grain. The call for grain comes when the rotary bin switch in the hopper starts rotating, due to the lack of grain. This call for grain starts all equipment associated with Fill 2. It also causes the Fill 1 Start Delay timer to begin its countdown. Once the Fill 1 Start Delay timer expires, all equipment associated with Fill 1 will start.

Grain Fill Shut-Down Sequence

Following the logic of the chart, the shutdown sequence starts when the call for grain ends. When the call for grain ends, the equipment associated with Fill 1 and 2 will continue to run for the duration of the Fill 1 Stop Delay timer. Once the Fill 1 Stop Delay timer expires, all the equipment associated with Fill 1 will turn off but all the equipment associated with Fill 2 will continue to run for the duration of the Fill 2 Stop Delay timer. Once the Fill 2 Stop Delay timer expires, all equipment associated with Fill 2 will stop.

Moisture Sensor Settings

The fourth of the six options under System Settings is Moisture Sensor Settings. This page contains all settings pertaining to the Moisture Sensors. It is here where the Moisture Sensors can be calibrated as well. The page layout is slightly different between AccuDry and non-AccuDry equipped dryers. Shown below on the left is an AccuDry equipped dryer, while the one on the right is a non-AccuDry dryer.





The Moisture Sensor Settings page is seperated into two halves. The top half is dedicated to the inlet moisture sensor while the bottom half is dedicated to the outlet moisture sensor. If the dryer is not equipped with one or more of these sensors, the displayed values will simply be grayed out and read N/A.

Moisture Alarms

The Pinnacle 20|20 control can be set up to alert the operator, or even further, shut the dryer down when grain moistures, detected by the moisture sensors, reach pre-set alarm limits. There are two types of limits: high limits and low limits. There are also two types of alarms: warning alarms and critical alarms. If a warning alarm limit is exceeded, the control will trigger a warning message to be displayed on the HMI screens. If that particular reading continues further off course and exceeds the critical alarm limit, the dryer will shutdown and a critical alarm message will appear on the HMI screens.

Each sensor has it's own table of moisture alarm settings. The Inlet Moisture Alarms table is located at the top, left side of the Moisture Sensor Settings page while the Outlet Moisture Alarms table is located at the bottom, left side of the same page. The adjustable limits are shown in black text, in white boxes. The high limits are at the top of the table while the low limits are at the bottom of the table. Reference the labels to the right of the adjustable limits to dicipher between a critical limit and a warning limit. In between the adjustable warning values is the actual grain moisture being read by the moisture sensor.

High Moisture Critical

If the Current Moisture exceeds the value entered for the High Moisture Critical value, the dryer will shut down. The input value for this High Moisture Critical alarm must be equal to or greater than the value entered for the High Moisture Warning value. To expand the allowable input range for the High Moisture Critical value, the High Moisture Warning value may first need to be adjusted.

High Moisture Warning

If the Current Moisture exceeds the value entered for the High Moisture Warning value, the control will display a High Moisture warning message. The input value for this High Moisture Warning alarm must be equal to or less than the value entered for the High Moisture Critical value. The lowest value allowed for this warning is equal to the Low Moisture Warning value. To expand the allowable input range for the High Moisture Warning value, the High Moisture Critical and Low Moisture Warning values may first need to be adjusted.

Current Moisture

This value is the real time grain moisture value being read by the moisture sensor.

Low Moisture Warning

If the Current Moisture falls below the value entered for the Low Moisture Warning, the control will display a Low Moisture warning message. The input value for this Low Moisture Warning alarm must be equal to or less than the value entered for the High Moisture Warning value. The lowest value allowed for this warning is equal to the Low Moisture Critical value. To expand the allowable input range for the Low Moisture Warning value, the High Moisture Warning and Low Moisture Critical values may first need to be adjusted.

Low Moisture Critical

DOC-PT02-0219

If the Current Moisture falls below the value entered for the Low Moisture Critical, the dryer will shut down.



System Settings 3.7

Pinnacle 20 | 20 Controls Manual

The input value for this Low Moisture Critical alarm must be equal to or lower than the value entered for the Low Moisture Warning value. To expand the allowable input range for the Low Moisture Critical value, the Low Moisture Warning value may first need to be adjusted.

<u>Temperature Alarms</u>

The Pinnacle 20|20 control can also be set up to alert the operator or even shut the dryer down when grain temperatures, detected by the moisture sensors, reach pre-set alarm limits. As previously mentioned there are high and low limits and there are critical and warning alarms.

Each sensor has it's own table of temperature alarm settings. The Inlet Temperature Alarms table is located at the top, right side of the Moisture Sensor Settings page while the Outlet Temperature Alarms table is located at the bottom, right side of the same page. The adjustable limits are shown in black text, in white boxes. The high limits are at the top of the table while the low limits are at the bottom of the table. Reference the labels to the right of the adjustable limit to dicipher between a critical limit and a warning limit. In between the adjustable warning values is the actual grain temperature being read by the moisture sensor.

High Temp Critical

If the Current Temp exceeds the value entered for the High Temp Critical value, the dryer will shut down. The input value for this High Temp Critical alarm must be equal to or greater than the value entered for the High Temp Warning value. To expand the allowable input range for the High Temp Critical value, the High Temp Warning value may first need to be adjusted.

High Temp Warning

If the Current Temp exceeds the value entered for the High Temp Warning value, the control will display a High Temp warning message. The input value for this High Temp Warning alarm must be equal to or less than the value entered for the High Temp Critical value. The lowest value allowed for this warning is equal to the Low Temp Warning value. To expand the allowable input range for the High Temp Warning value, the High Temp Critical and Low Temp Warning values may first need to be adjusted.

Current Temp

This value is the real time grain Temp value being read by the Moisture sensor.

Low Temp Warning

If the Current Temp falls below the value entered for the Low Temp Warning, the control will display a Low Temp warning message. The input value for this Low Temp Warning alarm must be equal to or less than the value entered for the High Temp Warning value. The lowest value allowed for this warning is equal to the Low Temp Critical value. To expand the allowable input range for the Low Temp Warning value, the High Temp Warning and Low Temp Critical values may first need to be adjusted.

Low Temp Critical

If the Current Temp falls below the value entered for the Low Temp Critical, the dryer will shut down. The input value for this Low Temp Critical alarm must be equal to or lower than the value entered for the Low Temp Warning value. To expand the allowable input range for the Low Temp Critical value, the Low Temp Warning value may first need to be adjusted.

Sensor Calibration

The sensor calibration procedure varies slightly between AccuDry equipped and non-AccuDry dryers. Below are the procedures for both variations.

Inlet Sensor, AccuDry

To calibrate the Inlet moisture sensor, press the "Start Calibration" button to the left of the Inlet Sensor Calibration tile. This will prompt the system to measure the grain moisture for 30 seconds, which will be indicated by the "Wait" indicator blinking green. Meanwhile, obtain a lab measurement of current Inlet grain. When the "Ready" button illuminates green, enter the lab measured values in the white box labeled "Lab Measured Moisture". Once entered, press "Confirm Calibration" to complete the calibration process. When the "Start Calibration" button is pressed, the text for this button will change to "Cancel Calibration", allowing the operator to cancel the calibration if desired. Note that the calibration process allows for a maximum of 0.5% calibration per calibration. If the sensor is off by 2%, the sensor will need to be calibrated 4 times.

Outlet Sensor, AccuDry

To calibrate the outlet moisture sensor, press the "Start Calibration" button, to the left of the Outlet Sensor Calibration box. This will prompt the system to measure the grain moisture for 30 seconds, which will be indicated by the "Wait" indicator blinking green. Meanwhile, obtain a lab measurement of current Outlet grain. When the "Ready" button illuminates green, enter the lab measured values in the white box labeled "Lab Measured Moisture". Once entered, press "Confirm Calibration" to complete the calibration process. When the "Start Calibration" button is pressed, the text for this button will change to "Cancel Calibration", allowing the operator to cancel the calibration if desired. Note that the calibration process allows for a maximum of 0.5% calibration per calibration. If the sensor is off by 2%, the sensor will need to be calibrated 4 times.

Inlet Sensor, non-AccuDry

To calibrate the Inlet moisture sensor for a non-AccuDry dryer, obtain a lab measurement of current Inlet grain. Press the white box labeled "Lab Measured Moisture" and enter the recently obtained lab measured value. Press the Calibrate button to calibrate or the Cancel button to cancel the calibration. Note that the calibration process allows for a maximum of 0.5% calibration per calibration. If the sensor is off by 2%, the sensor will need to be calibrated 4 times.

Outlet Sensor, non-AccuDry

To calibrate the Outlet moisture sensor for a non-AccuDry dryer, obtain a lab measurement of current Outlet grain. Press the white box labeled "Lab Measured Moisture" and enter the recently obtained lab measured value. Press the Calibrate button to calibrate or the Cancel button to cancel the calibration. Note that the calibration process allows for a maximum of 0.5% calibration per calibration. If the sensor is off by 2%, the sensor will need to be calibrated 4 times.

DOC-PT02-0219 System Settings



Burner Settings

The fifth of the six options under System Settings is Burner Settings. This page contains all settings pertaining to the Burners and plenum temperature.



The Burner Settings page layout will vary depending on the model of dryer. For Legacy dryers, there are toggle buttons at the bottom of the page. These toggle buttons are used to take the operator to the burner settings for burners 1 through 4 and for burners 5 through 8. Note that the burners are labeled in an accessending manner, starting with 1 to indicate the bottom-most burner on the dryer. The ECO, Tower and Delta dryer Burner Settings page layout will have component, quick launch buttons at the bottom of the page instead. The components listed there are for convenience, and are related to the burner or ignition process.

The burners can be started from the Burner Settings page for Tower dryers. They are started in the same manner as what was described in Chapter 2, Control, Fans & Burners. The ability to start and stop the burners from the Burner Settings page is not possible for ECO, Legacy, and Delta dryers. This must be done from the Controls page.

Plenum Temp

The Burner Settings page displays information pertaining to the burner in 3 seperate columns. The first column is the Plenum Temp. There are two values displayed: an actual plenum temperature value being read by the plenum RTD and a set value, that the operator can adjust to meet their desired plenum temperature.

Valve % Opening

The second column is the Valve % Opening. The Valve % Opening refers to the modulating valve that controls the flow of gas to the burner. It is here where the operator can set the initial valve percent opening. The initial valve percent opening is the amount the modulating valve will open upon starting the burner. Two other adjustable values the operator can enter are the max and min. The max and min values are the maximum and minimum percent the valve will open during operation. The value in between the min and max values is the actual valve percent opening the modulating value is currently open to.

Mode

The last column is a heat/cool indicator. This indicates whether the plenum is considered a heat zone or a cool zone by the AccuDry software. When the indicator globe is blue, it indicates a cool zone. When the indicator globe is red, it indicates a heat zone. The value entered as the "Dryer Off Temp" detemines whether the burner is considered off or on. Access to the "Dryer Off Temp" value is through the Service Screens, in the AccuDry Settings page. If the actual plenum temperature is lower than this value, the mode will appear with the circular indicator globe colored blue. If the actual plenum temperature is above this value, the circular indicator globe will appear red.

Note: These indicators lock upon entering AccuDry, so the operator should leave and re-enter AccuDry if a plenum is to be turned on or off while in AccuDry.

Discharge Speed Control

The last of the six options under System Settings is Discharge Speed Control. This page contains all settings pertaining to the discharge speed as well as the settings associated with the different modes of discharge: Manual, TruDry, AccuDry Lite and AccuDry.



On the bottom of the Discharge Speed Control page are the four discharge modes to toggle between. Each discharge mode has a seperate set of settings. For 2017, 3 of the 4 discharge modes are available. The one that is not available in 2017 is the AccuDry Lite.

Regardless of which discharge mode settings page is displayed, the operator can change the discharge mode from any one of them. However, it is important to understand that in order to change discharge modes, the operator must be in Manual mode first before changing to any of the other available modes. For instance, if the dryer is currently discharging in AccuDry mode and the operator wants to change to TruDry mode, the operator must first select Manual mode, and then select TruDry mode.

In addition to being able to select the mode of discharge from any of these pages, the Manual, TruDry and AccuDry Settings pages also all contain the same information for the following tiles: Disch Speed, Disch Speed Alarms, and Mid-Grain Temperature Alarms.

DOC-PT02-0219 System Settings 3.11

Manual Settings

When discharging in Manual mode, the operator controls the speed at which the grain discharges at. This adjustable value is under the Manual Settings tile, next to the Set Discharge Speed, input box.



Each dryer model has a discharge capacity for every revolution of the metering rolls for profile dryers and sweep for tower dryers. These discharge capacities are used to calculate how much grain is being discharged from the dryer given a specific discharge speed. The chart below shows what these discharge

capacities are.

	Discharge	Capacity
	(bu/rev)	(m3/rev)
L1000		
L1000VC		
L1500		
L1500VC		
L2000	3.667	0.12918
L2000VC	0.007	0.12010
L3000		
L4000		
L5000		
L60000		
D600/D600h	2.433	0.0857
D900/D900h		
D1200/D1200h		
D1500/D1500h	3.667	0.1292
D1800/D1800h	0.007	0.1202
D2100/D2100h		
D2400/D2400h		
D3200/D3200h	4.889	0.1723
E300/E300h/E300hc	1.825	0.06429
E400/E400h/E400hc	2.433	0.08571
E500/E500h/E500hc	3.042	0.10717
E600/E600h/E600hc	3.667	0.12918
10530	5.000	0.17857
10740	7.000	0.25000
10950	9.000	0.32143
101160	11.000	0.39286
101375	13.000	0.46429
2000	10.000	0.35714
2400	12.000	0.42857
2700	14.000	0.49340
12-20-100	10.000	0.35714
12-24-125	12.000	0.42857
12-28-150	14.000	0.49340
3000	40.000	1.42857
3500	45.000	1.60714
4000	50.000	1.78571
4800	55.000	1.96429

Depending on the model dryer, the % discharge speed will correspond to an approximate bu/hr or metric tonnes/hr value given a known discharge capacity. The table below correlates discharge speed % to bu/hr based on moisture removal and mode of operations (All Heat or Heat + Cool)

			All I	Heat					Hea	t + Cool		
	20%	%-15% mois			%-15% mosi	ture	209	%-15% mois			5%-15% mos	siture
	bu/hr	tonnes/hr	speed	bu/hr	tonnes/hr	speed	bu/hr	tonnes/hr	speed	bu/hr	tonnes/hr	speed
L1000	700	22.9	33%	600	14.0	28%	1,270	29.6	59%	390	9.1	18%
L1000VC	-	-	-	-	-	-	1,270	29.6	59%	390	9.1	18%
L1500	1,050	24.4	49%	880	20.5	41%	1,830	42.6	85%	600	14.0	28%
L1500VC	-	-	-	-	-	-	1,830	42.6	85%	600	14.0	28%
L2000	1,320	30.7	62%	1,040	24.2	49%	2,200	50.0	100%	750	21.7	43%
L2000VC	-	-	-	-	-	-	2,200	50.0	100%	750	21.7	43%
L3000	1,700	39.6	40%	1,460	34.0	34%	3,060	71.3	71%	940	21.9	22%
L4000	2,280	53.1	53%	1,860	43.4	43%	3,910	91.1	91%	1,300	30.3	30%
L5000*	2,870	66.9	67%	2,280	53.1	53%	4,770	99.9	100%	1,660	38.7	39%
L6000*	3,470	80.9	81%	2,680	62.5	63%	5,600	99.9	100%	2,000	46.6	47%
D600	-	-	-	-	-	-	920	21.4	65%	540	12.6	38%
D900	-	-	-	-	-	-	1,380	32.1	64%	800	18.6	37%
D1200		-	-	-	-	-	1,780	41.5	66%	1,030	24.0	38%
D1500	•	-	-	-	-	-	2,170	50.5	67%	1,250	29.1	39%
D1800	•	-	-	-	-	-	2,590	60.3	67%	1,470	34.2	38%
D2100	1	-	-	-	-	-	2,970	69.2	69%	1,700	39.6	40%
D2400	1	-	-	-	-	-	3,370	78.5	66%	1,930	45.0	38%
D3200	1	-	-	-	-	-	4,500	104.8	66%	2,560	59.6	37%
D600h*	1,494	34.8	100%	711	16.6	50%	920	21.4	65%	540	12.6	38%
D900h*	2,241	52.2	100%	1,071	24.9	50%	1,380	32.1	64%	800	18.6	37%
D1200h*	2,889	67.3	100%	1,386	32.3	52%	1,780	41.5	66%	1,030	24.0	38%
D1500h*	3,519	82.0	100%	1,692	39.4	53%	2,170	50.5	67%	1,250	29.1	39%
D1800h*	4,185	97.5	100%	2,016	47.0	52%	2,590	60.3	67%	1,470	34.2	38%
D2100h*	4,806	111.9	100%	2,313	53.9	52%	2,970	69.2	69%	1,700	39.6	40%
D2400h*	5,454	127.0	100%	2,628	61.2	51%	3,370	78.5	66%	1,930	45.0	38%
D3200h*	7,281	169.6	100%	3,510	81.8	51%	4,500	104.8	66%	2,560	59.6	37%
E300	550	12.8	72%	270	6.3	35%	310	7.2	41%	175	4.1	23%
E400	730	17.0	72%	360	8.4	35%	410	9.5	40%	230	5.4	23%
E500	910	21.2	72%	445	10.4	35%	510	11.9	40%	290	6.8	23%
E600	1,100	25.6	72%	535	12.5	35%	610	14.2	40%	345	8.0	23%
E700	1,283	29.9	72%	626	14.6	35%	710	16.5	40%	406	9.5	23%
E300h	550	12.8	72%	270	6.3	35%	-	-	-	-	-	-
E400h	730	17.0	72%	360	8.4	35%	-	-	-	-	-	-
E500h	910	21.2	72%	445	10.4	35%	-	-	-	-	-	-
E600h	1,100	25.6	72%	535	12.5	35%	-	-	-	-	-	-
E700h	1,283	29.9	72%	626	14.6	35%						
E300hc	-	-	-	-	-	-	310	7.2	41%	175	4.1	23%
E400hc	-	-	-	-	-	-	410	9.5	40%	230	5.4	23%
E500hc	-	-	-	-	-	-	510	11.9	40%	290	6.8	23%
E600hc	-	-	-	-	-	-	610	14	40%	345	8.0	23%
E700hc							710	16.5	40%	406	9.5	23%
10530	-	-	-	-	-	-	700	16.3	34%	400	9.3	19%
10740	-	-	-	-	-	-	930	21.7	32%	540	12.6	19%
10950	-	-	-	-	-	-	1,240	28.9	33%	720	16.8	19%
101160	-	-	-	-	-	-	1,500	34.9	33%	870	20.3	19%
101375	-	-	-	-	-	-	1,700	39.6	32%	1,000	23.3	19%
12-20-100	-	-		-	-	-	2,000	46.6	48%	1,160	27.0	28%
12-24-125	-	-	-	-	-	-	2,400	55.9	48%	1,390	32.4	28%
12-28-150	-	-	-	-	-	-	2,800	65.2	48%	1,620	37.8	28%
3000	-	-	-	-	-	-	3,000	69.9	50%	1,800	41.9	30%
3500	-	-	-	-	-	-	3,500	81.5	52%	2,100	48.9	31%
4000	-	-	-	-	-	-	4,000	93.1	54%	2,400	55.8	32%
4800 *Note: May need	-	<u> </u>	-		-	-	4,800	111.8	59%	2,800	65.2	34%

^{*}Note: May need to run at lower plenum temperatures for low moisture removal when drying in all heat.

The values shown in the Disch Speed Tile of the Manual Settings page are all values associated with the discharge speed. This includes the actual discharge speed, VFD frequency, discharge rate, motor and metering speed. The charts on the following two pages show the discharge speed in 10% increments and the resulting bu/hour, tonnes/hour, VFD Frequency and Metering Speed for each dryer model.

DOC-PT02-0219 System Settings 3.13



											ľ	Discharge Speed (%)	Speed	(%)										
1		%0	%			1(10%			20	20%	,			30%			4(40%			1	20%	
	VFD IN	_	Disch			_	Disch	Н	_	_	Disch	Disch	_	_	Disch	Disch		Metering Disch	Disch	Disch	VFD	_	Disch	Disch
	Freq (Hz)	Speed (RPM)	Rate (bu/hr) (tc	Rate Rate (bu/hr) (tonnes/hr)	Freq (Hz)	Speed (RPM)	Rate (bu/hr)(t	Rate Rate (bu/hr) (tonnes/hr)	Freq (Hz)	Speed (RPM) (Rate (bu/hr)(t	Rate Rate (bu/hr) (tonnes/hr)	Freq (Hz)	Speed (RPM)	Rate (bu/hr)(t	Rate Rate (bu/hr) (tonnes/hr)	Freq (Hz)	Speed (RPM)	Rate (bu/hr)	Rate Rate (bu/hr) (tonnes/hr)	Freq (Hz)	Speed (RPM)		Rate Rate (bu/hr) (tonnes/hr)
L1000																								
L2000		0.0	0	0.0		0.	215	2.0		2.0	429	10.0		2.9	644	15.0		3.9	828	20.0		4 6	1073	25.0
L2000VC									12.0								24.0				30.0			
L3000)				 }				<u>.</u>				2				2				2			
L4000		0.0	0	0.0		2.0	429	10.0		3.9	858	20.0		5.9	1287	30.0		7.8	1716	40.0		8.6	2145	50.0
L5000																								
E300/E300h/E300hc		İ	0	0.0	T		9/	1.8			153	3.6	T		229	5.3			305	7.1			381	8.9
E400/E400h/E400hc		<u> </u>	0	0.0		•	102	2.4		1	203	4.7		•	305	7.1		•	407	9.5			508	11.8
E500/E500h/E500hc	0.0	0.0	0	0.0	0.9	0.7	127	3.0	12.0	4.1	254	5.9	18.0	2.1	381	8.9	24.0	2.8	508	11.8	30.0	3.5	989	14.8
E600/E600h/E600hc			0	0.0			153	3.6			306	7.1			460	10.7			613	14.3			992	17.8
E700/E700h/E700hc			0	0.0			179	4.2			358	8.3			536	12.5			715	16.7			894	20.8
D600/D600h		0	0	0.0		10	142	3.3		0 0	285	9.9		7.0	427	6.6		3.0	569	13.3		0 7	711	16.6
D900/D900h		2.	0	0.0		2.	215	5.0		2.7	429	10.0		5.3	643	15.0		2	858	20.0		ř	1072	25.0
D1200/D1200h		0.0	0	0.0		1.2	268	6.2		2.4	536	12.5		3.7	804	18.7		4.9	1073	25.0		6.1	1340	31.2
D1500/D1500h		0.0	0	0.0	٥	1.5	322	7.5	120	2.9	644	15.0	α τ	4.4	964	22.5	24.0	5.9	1287	30.0	30.0	7.3	1608	37.5
D1800/D1800h	2	0.0	0	0.0	 }	1.8	386	9.0		3.5	772	18.0		5.3	1157	27.0)	7.0	1545	36.0	2	8.8	1930	44.9
D2100/D2100h		0.0	0	0.0		2.0	429	10.0		3.9	858	20.0		5.8	1286	30.0		7.8	1716	40.0		9.7	2144	49.9
D2400/D2400h			0	0.0		7 3	515	12.0		4.7	1030	24.0	<u> </u>	7 0 2	1543	35.9		0 4	2059	48.0		117	2573	59.9
D3200/D3200h		2	0	0.0		5.7	989	16.0		ì	1373	32.0		2.	2057	47.9		t S	2746	64.0		-	3430	79.9
10530			0	0.0		'	207	4.8			414	9.6			621	14.5			828	19.3			1035	24.1
			0	0.0			290	6.8			580	13.5			869	20.3			1159	27.0			1449	33.8
	0.0	0.0	0	0.0	0.9	0.7	373	8.7	12.0	4.	745	17.4	18.0	2.1	1118	26.0	24.0	2.8	1490	34.7	30.0	3.5	1863	43.4
101160			0	0.0			455	10.6			911	21.2			1366	31.8			1822	42.4			2277	53.0
101375			0	0.0			538	12.5			1076	25.1			1615	37.6			2153	50.1			2691	62.7
12-20-100			0	0.0			414	9.6			828	19.3			1242	28.9			1656	38.6			2070	48.2
12 24 125	0.0	0.0	0	0	0.9	0.7	497	11.6	12.0	4.	994	23.1	18.0	2.1	1490	34.7	24.0	2.8	1987	46.3	30.0	3.5	2484	67.9
12-28-150			0	0			580	13.5			1159	27.0			1739	40,5			2318	54			2898	67.5
3000			0	0.0			969	13.9			1191	27.8			1787	41.6			2383	55.5			2978	69.4
	0 0	00	0	0.0	0 9	0.0	670	15.6	12.0	0.5	1340	31.2	18.0	0 7	2010	46.8	24 0	0	2681	62.4	30.0	12	3351	78.0
	?		0	0.0		, 1	745	17.3	<u>1</u>	<u> </u>	1489	34.7	2	<u> </u>	2234	52.0	, ,	?	2978	69.4	}	<u>.</u>	3723	86.7
4800			0	0.0	\dashv		819	19.1	1		1638	38.2		\rceil	2457	57.2			3276	76.3			4095	95.4

									٦	Discharge Speed (%)	Speed	(%)								
		٩	%09			7	%02		1	S S	80%	(8)			%U6			10	100%	
	VED	Motoring	Disch	doil	7,67	Motoring	Disch	dosiC	757	Motoring	Disch	dosiC	72/	Motoring	do sign	do i C	757	Motoring	- doi:	Diech
	Fred	Speed	Rate	Rate	Fred	Speed	Rate	Rate	Fred	Speed	Rate	Rate	Fred	Speed	Rate	Rate	Fea	Speed	Rate	Rate
	(Hz)	(RPM)	(bu/hr)	(tonnes/hr)	(Hz)	(RPM)	(bu/hr)	(tonnes/hr)	(Hz)	(RPM)	(bu/hr)	(tonnes/hr)	(Hz)	(RPM)	(bu/hr)	(tonnes/hr)	. (Hz)	(RPM)	(bu/hr)	(tonnes/hr)
L1000																				
L1000VC		5.9	1287	30.0		6.8	1502	35.0		7.8	1716	40.0		8.8	1931	45.0		8.6	2145	50.0
L2000VC					9				9								9			
1 3000	36.0		İ		42.0				48.0		İ		0.40				10.09			
L4000		7	717	ć		7	- 000	0			2,0	0		7	2000	C			000	G G
T2000		`: :	4/07	0.00		13./	3003	0.07		0.01	3432	8. 8.		o. /	280	n. 0		C.	4290	5. 5. 5.
E300/E300h/E300hc			458	10.7			534	12.4			610	14.2			989	16.0			292	17.8
E400/E400h/E400hc			610	14.2			712	16.6		•	813	18.9			915	21.3			1017	23.7
E500/E500h/E500hc	36.0	4.2	763	17.8	42.0	4.9	068	20.7	48.0	5.6	1017	23.7	54.0	6.3	1144	26.6	0.09	7.0	1271	29.6
E600/E600h/E600hc			919	21.4			1073	25.0			1226	28.6			1379	32.1			1532	35.7
E700/E700h/E700hc			1073	25.0			1251	29.1			1430	33.3			1609	37.5			1788	41.6
D600/D600h		5.0	854	19.9		8	266	23.2		7 8	1139	26.5		α	1281	29.8		80	1423	33.2
D900/D900h	'	?	1287	30.0		2	1502	35.0		2	1716	40.0		2	1931	45.0		2	2145	50.0
D1200/D1200h	ļ	7.3	1609	37.5		8.5	1878	43.7		9.8	2145	50.0		11.0	2414	56.2		12.2	2681	62.5
D1500/D1500h	36.0	8.8	1931	45.0	42.0	10.2	2253	52.5	48.0	11.7	2574	0.09	54.0	13.2	2897	67.5	900	14.6	3218	75.0
D1800/D1800h	2	10.5	2317	54.0	7	12.3	2704	63.0) 	14.0	3089	72.0	2	15.8	3476	81.0	2	17.6	3861	89.9
D2100/D2100h	_	11.7	2574	0.09		13.7	3004	70.0		15.6	3432	79.9		17.6	3863	0.06		19.5	4290	66.66
D2400/D2400h		14.0	3089	72.0		16.4	3605	84.0		18.7	4119	95.9		21.1	4635	108.0		23.4	5148	119.9
D3200/D3200h		2	4118	95.9			4807	112.0	1	:	5491	127.9			6180	143.9			6864	159.9
10530			1242	28.9			1449	33.8			1656	38.6			1863	43.4			2070	48.2
10740	36.0	2.4	1739	40.5	42.0	6	2029	47.3	48.0	5.6	2318	54.0	54.0	6.3	3353	60.8	0.09	7.0	3726	67.5
101160		!	2732	63.6			3188	74.3			3643	84.9			4099	95.5			4554	106.1
101375			3229	75.2			3767	87.8			4306	100.3			4844	112.8			5382	125.4
12-20-100			2484	67.3			2898	67.5			3312	77.1			3726	86.8			4140	96.4
12-24-125	36.0	4.2	2981	69.4	42.0	4.9	3478	81.0	48.0	5.6	3974	92.6	54.0	6.3	4471	104.1	0.09	7.0	4968	115.7
12-28-150			3478	81.0			4057	94.5			4637	108		_	5216	121.5			2796	135.0
3000			3574	83.3			4170	97.1			4765	111.0			5361	124.9			2957	138.8
3500	36.0	1.5	4021	93.7	42.0	1.7	4691	109.3	48.0	2.0	5361	124.9	54.0	2.2	6031	140.5	0.09	2.5	6701	156.1
4000		2	4468	104.1	<u>:</u>	:	5212	121.4	<u> </u>	 }	5957	138.8)	!	6701	156.1	<u> </u>	ì	7446	173.4
4800			4914	114.5			5733	133.5			6553	152.6			7372	171.7			8191	190.8

3.15

System Settings 3.15

Setting Discharge Speed Operational Limits

From any of these discharge settings pages (Manual, TruDry, or AccuDry Settings pages), in the Disch Speed tile, the operator can set operational limits that pertain to the discharge speed. The two operational limits the operator can set are the max and min speeds the discharge can run at. With the operational limits in place, the user will not be able to enter a speed in the Set Discharge Speed box of the Manual Settings page that exceeds these limits. *Note: The lowest allowable min limit that can be entered is 10%.*



Setting Dicharge Speed Alarm Limits

Again, from any of these discharge settings pages, under Disch Speed Alarms, the operator can set alarm limits that pertain to the discharge speed. There are two types limits: high limits and low limits. There also two types of alarms: warning alarms and critical alarms. If a warning alarm limit is exceeded, the control will trigger a warning message to be displayed on the HMI screens. If that particular reading continues further off course and exceeds the critical alarm limit, the dryer will shutdown and a critical alarm message will appear on the HMI screens.

High Speed Critical

If the Current Speed exceeds the value entered for the High Speed Critical value, the dryer will shut down. The input value for this High Speed Critical alarm must be equal to or greater than the value entered for the High Speed Warning value. To expand the allowable input range for the High Speed Critical value, the High Speed Warning value may first need to be adjusted.

High Speed Warning If the Current Speed exceeds the value entered for the High Speed Warning value, the control will display a High Speed warning message. The input value for this High Speed Warning alarm must be equal to or less than the value entered for the High Speed Critical value. The lowest value allowed for this warning is equal to the Low Speed Warning value. To expand the allowable input range for the High Speed Warning value, the High Speed Critical and Low Speed Warning values may first need to be adjusted.

Current Speed

This value is the real time metering speed of the discharge system.

Low Speed Warning

If the Current Speed falls below the value entered for the Low Speed Warning, the control will display a Low Speed warning message. The input value for this Low Speed Warning alarm must be equal to or less than the value entered for the High Speed Warning value. The lowest value allowed for this warning is equal to the Low Speed Critical value. To expand the allowable input range for the Low Speed Warning value, the High Speed Warning and Low Speed Critical values may first need to be adjusted.

Low Speed Critical

If the Current Speed falls below the value entered for the Low Speed Critical, the dryer will shut down. The input value for this Low Speed Critical alarm must be equal to or lower than the value entered for the Low Speed Warning value. To expand the allowable input range for the Low Speed Critical value, the Low Speed Warning value may first need to be adjusted.

Setting Mid-Grain Temperature Alarm Limits

Since the speed of the discharge impacts the mid-grain temperature, it is on any of these discharge settings pages where the operator can set the mid-grain temperature alarm limits. If the dryer is discharging and the mid-grain temperature exceeds the mid-grain temperature alarm band for a set period of time, the dryer will enter a Cool Down mode.

The two alarm limits that can be entered that pertain to the mid-grain temperature are the Alarm Band and Alarm Band Delay.

Alarm Band

The Mid-Grain Temperature Alarm Band is the allowed deviation from the mid-grain temperature set point while the discharge system is running.

Alarm Band Delay

The Mid-Grain Alarm Band Delay is a user-defined time duration in minutes that will delay the Cool Down of the dryer after the Mid-Grain Band warning alarm has occurred. If the Mid-Grain temperature returns to the acceptable range within this time period, no shut down will occur.

DOC-PT02-0219 System Setting

TruDry Settings

The TruDry Settings page is very similar to the Manual Settings page. The only difference, other than the component quick launches, is the "Set Discharge Speed" box displayed on the Manual Settings page has been replaced by mid-grain temperature boxes.



To understand the settings on the TruDry Settings page, it is best to first have a good understanding of how TruDry works.

TruDry Technology

TruDry is the name of a temperature based discharge mode of operation that automatically increases or decreases the discharge speed of the dryer. TruDry is not an automatic moisture control mode of operation and does not utilize the discharge moisture value, but instead controls the discharge rate by attempting to maintain an average mid-grain temperature setpoint. The mid-grain temperature is the temperature of the grain, measured approximately halfway down the heat zone of the dryer, and halfway into the grain column by an RTD (resistive temperature device). There are two RTD's, on opposite sides of the dryer, measuring the grain temperature. These two temperatures are used to calculate the average mid-grain temperature. The principal of operation is that as the grain entering the dryer increases in moisture, the mid-grain temperature will go down and when the grain entering the dryer decreases in moisture, the mid-grain temperature will go up. Therefore, what the controller will do is utilize a negative responding Proportional-Integral-Derivative (PID) control loop which will increase the discharge rate when the midgrain temperature goes up and decrease the discharge rate when the midgrain temperature goes up and decrease the discharge rate when the midgrain temperature goes down. This essentially means that as the grain's moisture goes up, the dryer will slow down and as the grain's moisture goes down, the dryer will speed up.

In order to effectively use the TruDry mode of operation, it is important to allow the dryer to get to a steady state operating condition for 2-3 hours (depending on the size of the machine and the incoming grain moisture) with a desirable and consistent discharge moisture output. Once this steady state condition has been met, the operator will want to set the mid-grain temperature setpoint to a value equal to the current actual mid-grain temperature. Note that although the dryer is running in manual, the operator will still be able to change the mid-grain temperature setpoint via the TruDry Settings page.

At this point, the dryer has been running for 2-3 hours and steady state has been reached, so the current reading for the actual mid-grain temperature should correspond to the desired grain moisture that is currently being discharged from the dryer. It is important to understand that TruDry is not controlling the dryer based on discharge moisture, but rather indirectly based on the average mid-grain temperature.

Another step to ensure a smooth and successful transition from manual mode to TruDry is to verify the minimum and maximum discharge speed Operational Limits are set to reasonable values. When running in TruDry mode this is especially important because the TruDry control algorithm will attempt to speed up and slow down to maintain the mid-grain temperature setpoint, and the amount of room that the controller has to work with is determined by the minimum and maximum speed setpoints. For example if the min/max speed setpoints are 10% - 100%, the range of speed output from the controller will be higher, which means the rate at which the speed changes will be higher. On the other hand, if the min/max setpoints are 30% - 75%, the controller can only operate within that band and only has a range of 45% to work with. A table of suggested minimum and maximum values is shown below.

	All	Heat	Heat -	+ Cool
	Recom	mended	Recom	mended
	Min	Max	Min	Max
E300 - E700	25%	75%	10%	55%
E300h - E700h	25%	75%	-	-
E300hc - E700hc	-	-	10%	55%
L1000 - L6000	20%	80%	15%	100%
D600 - D3200	-	-	30%	70%
D600h - D3200h	40%	100%	30%	70%
10530 - 101375	-	-	10%	45%
12-20-100 - 12-28-150	-	-	15%	65%
3000 - 4800	-	-	15%	65%

DOC-PT02-0219 System Settings 3.19

Pinnacle 20 | 20 Controls Manual

Once the average mid-grain temperature setpoint has been set and the minimum and maximum speed range has been established, TruDry mode of operation can be selected by touching the TruDry button in the upper right corner of any of the discharge settings pages. Once TruDry mode of operation has been selected, the ability to manually change the speed will be inhibited and the only parameter that can be adjusted will be the mid-grain temperature setpoint.

While running in TruDry, the speed will continuously increase or decrease to maintain the target mid-grain temperature. Do not continuously tweak the mid-grain temperature, let it try to control to the setpoint value that you previously established. TruDry should be able to handle 3-5% swings in incoming moisture with reasonable discharge moisture variation if the dryer was properly brought up to steady state as previously explained. If after running for an extended period of time and it has been determined that the target mid-grain temperature is too high or too low, minor adjustments can be made, but should only be done periodically, not continuously. If the operator wants to meticulously control the dryer, then the dryer should be run in the manual mode of operation where the operator can directly control the dryer's discharge rate.

AccuDry Settings

The AccuDry Settings page is very similar to the Manual Settings page as well. The only difference, other than the component quick launches, is the "Set Discharge Speed" box displayed on the Manual Settings page has been replaced by values and information pertaining to AccuDry.



To understand the settings on the AccuDry Settings page, it is best to first have a good understanding of the AccuDry Technology and how AccuDry works.

AccuDry Technology

The AccuDry mode of operation utilizes input signals from both the discharge moisture sensor and the infeed moisture sensor to control the dryer's discharge rate. When the AccuDry mode of operation is available, it will display it's corresponding toggle button under the TruDry button. Also, when on the AccuDry Settings page, an input will be made available which allows the operator to enter the target discharge moisture setpoint.

When running in AccuDry, similar to the guidelines that were provided for TruDry, the minimum and maximum discharge speed Operational Limits are important to the controller's operation. The AccuDry control algorithm will attempt to speed up and slow down the discharge to maintain the discharge moisture setpoint, and the amount of room that the controller has to work with is determined by the minimum and maximum speed setpoints. For example if the min/max speed setpoints are 1% - 100%, the range of speed output from the controller will be higher, which means the rate at which the speed changes will be higher. On the other hand, if the min/max setpoints are 30% - 75%, the controller can only operate within that band and only has a range of 45% to work with.

Similar to how the mid-grain temperature setpoint (used in TruDry) can be changed while in manual mode, so too can the discharge moisture setpoint (used in AccuDry) be changed while in manual mode. The only limitation is that the operator cannot change the discharge speed setpoint when running in TruDry or AccuDry.

In order to effectively use the AccuDry mode of operation, it is important to allow the dryer to get to a steady state operating condition for 2-3 hours upon initial installation (depending on the size of the machine and the incoming grain moisture) with a desirable and consistent discharge moisture output. Once this steady state condition has been met, the operator will confirm the discharge moisture setpoint that is desired and make any required changes. Also, be sure the minimum and maximum discharge speed Operational Limits are set to an accurate band.

The AccuDry system will remember grain moistures upon startup from the previous shutdown. For example, if the dryer was discharging 15.5% moisture the night prior, and start up with 15.4% the following morning, the system will allow quick entry into AccuDry mode.

If the discharge moisture is significantly different from the previous operations moisture, the system will not enable AccuDry until it has gathered sufficient information to run correctly and efficiently.


Note: It is advised not to change the status of the burners while operating in AccuDry mode. Instead, change to manual discharge mode first, change the burners to off/on, then get back into AccuDry.

DOC-PT02-0219 System Settings 3.21

How AccuDry Works

AccuDry technology utilizes the Dryer Moisture Systems Dryer Master DM510 system. The DM510 system uses specially designed in-line moisture and temperature sensors located at both the infeed and discharge of the dryer. These sensors provide continuous moisture and temperature readings to the PLC, which is shared with the DM510 logic board.

The DM510 board uses this information to build an operating model of your dryer. As infeed moistures and drying conditions change throughout the day; AccuDry continuously calculates and automatically adjusts to the optimum discharge rate for current conditions.



AccuDry has two important advantages. First, in automatic mode, it can continually watch the dryer. It does not have to help unload trucks, load trains, or do any other jobs around the elevator that a normal dryer operator does throughout the day. The dryer receives the user's full attention.

Second, it has the benefit of continuous moisture information from both the infeed and discharge of the dryer, giving it a complete picture of all the grain in the dryer, and the grain exiting the dryer.

With this information, AccuDry does not have to wait to react to changes in the outlet moisture. It is able to adjust the discharge rate as the incoming moisture changes. For example, as wetter grain comes into the dryer, AccuDry begins to slow down the discharge rate just as the wetter grain reaches the hot zone.

AccuDry Status

While running in manual mode, AccuDry mode will not be available until the system is "Ready." The ready state is shown by the color of the AccuDry button, which is explained below.

AccuDry Not Ready (Grayed Out AccuDry Button)

By default, the dryer will not have enough information to jump right into AccuDry mode and the AccuDry button will appear grayed out. In order for AccuDry to be "Ready," the system must achieve the following before it will allow the dryer to enter AccuDry mode:

- 1. There must not be any alarms present;
- 2. The dryer must be in the "Running" state of operation, further explanation may be found below;
- 3. The Actual Discharge Rate must be within 5% of the Suggested Rate;
- 4. The Discharge Moisture must be within 2% of the Setpoint Moisture and;
- 5. The AccuDry system must have enough knowledge and runtime, to have a Predicted Discharge Moisture within 2% of the Actual Discharge Moisture.

Attempting to enter AccuDry Mode, whether ready or not, by pressing the AccuDry button from any of the discharge settings pages, will cause an AccuDry Status screen to appear as shown below.



This screen will appear slightly different depending on the state of the AccuDry model. The items displayed on this screen are the dryer running state, the not ready reason, the AccuDry predicted discharge moisture, the actual measured discharge moisture, the AccuDry suggested rate, the actual discharge rate, and whether or not the DM510 board is recording data (AccuDry Learning). This screen will provide information to better achieve AccuDry readiness, and will get the dryer into AccuDry much faster than guess work in Manual mode.

AccuDry Learning

On the AccuDry Status screen, the Learn mode will be illuminated when the dryer is operating (discharge is ON), and the moisture sensors have product being detected. This indicator states that the AccuDry system is "learning" from it's current operating inputs, and will stop "learning" and saving data when the discharge is turned OFF. Lastly is AccuDry mode, for when you are running in AccuDry mode.

DOC-PT02-0219 System Settings 3.23



AccuDry Dryer State

The dryer state field indicates the seven (7) stages of operating your dryer. The seven states are as follows;

Stand-By

The dryer fans, discharge, and burner(s) are off. The dryer may not be full (no moisture displayed by the infeed moisture sensor).

Primed

The dryer fans, discharge, and burner(s) are off. The dryer is full (moisture displayed by the infeed moisture sensor).

Idle Running

The dryer fans, discharge, and burner(s) are off. The dryer is full (moisture displayed by the infeed moisture sensor). This feature is only available on systems that make use of the fan switch input.

Shutdown

The dryer is OFF. The fans, the discharge, and burner(s) are off. The dryer is full (moisture displayed by the infeed moisture sensor). This feature is only available on systems that make use of the fan switch input.

Preheat

The dryer fans are on, the burner(s) are on, the discharge is off. The dryer is full (moisture displayed by the infeed moisture sensor).

Running

The dryer fans are on, the burner(s) are on, the discharge is on. The dryer is full (moisture displayed by the infeed moisture sensor). Moisture is displayed at the discharge sensor.

Holding

The dryer fans are on, the burner(s) are on, the discharge is off. The dryer is full (moisture displayed by the infeed moisture sensor). This is a temporary state and it will revert to Manual mode after 25 minutes as a safety precaution.

AccuDry Not Ready Reason

The not ready field indicates the reason the dryer will not allow entry into AccuDry mode.

Discharge Off

The discharge is off and must be turned on.

Drying Temp Critical

Plenum temperature is in alarm and must be corrected.

Inlet Moisture Critical

Inlet grain moisture is in alarm and must be corrected.

Outlet Moisture Critical

Discharge grain moisture is in alarm and must be corrected.

Inlet Temperature Critical

Inlet grain temperature is in alarm and must be corrected.

Outlet Temperature Critical

Discharge grain temperature is in alarm and must be corrected.

Burner Off

Burner is OFF and must be lit.

Rate Off

Discharge rate is in alarm and must be corrected.

Fan Off

Fan is OFF and must be turned on.

Model Prediction

AccuDry is gathering data, and the predicted moisture (based on current data) is not acceptably close to the actual discharge moisture. Continue running in manual until enough data is taken to accurately predict correct discharge moistures.

Beta 2 Filling

A technical subset of model prediction. The system is gathering feedback on how the dryer is efficiently drying a particular grain. Continue running in manual until enough data is taken to accurately predict correct discharge moistures.

Beta 2 Stabilizing

A technical subset of model prediction as well. The system is fine-tuning feedback based on how the dryer is operating. Continue running in manual until enough data is taken to accurately predict correct discharge moistures.

Target Difference

Moisture setpoint is not acceptably close to the actual discharge moisture. Continue running in manual until discharge moisture is within 2% of setpoint moisture. This is done to alleviate moisture overshoot when switching to AccuDry.

Suggested Rate

The suggested rate field indicates what the AccuDry system would run at that given moment if it were to take over controls of the VFD. It is important to note that this field updates regularly, and will become more and more accurate as the dryer learns for each individual grain type.

Actual Rate

The actual rate field indicates the real-time commanded speed from the PLC to the VFD.

DOC-PT02-0219 System Settings



AccuDry Ready

While running in manual when the AccuDry button text will change from gray to white, AccuDry reaches the "Ready" state. Pressing the AccuDry button will again cause the AccuDry status screen to appear. When AccuDry is selected from this screen, the button will flash "Enabling..." for a few seconds, and will illuminate the AccuDry text in green lettering; the dryer is now in AccuDry mode.







Once AccuDry mode of operation has been selected, the ability to manually change the speed will be inhibited and the only parameter that can be adjusted will be the discharge moisture setpoint. While running in AccuDry, the speed will continuously increase or decrease to maintain the target discharge moisture setpoint. Do not continuously tweak the discharge moisture setpoint, let it try to control to the setpoint value that was previously established.

A Typical Daily Routine

The following steps should be included in the daily routine when using the AccuDry system:

- 1. Before dryer start-up, check the outlet moisture sensor to ensure it is clean and free of debris. The sensor chute has no obstructions ahead of the sensor, and the flow-metering device is operating.
- 2. Start the dryer as has been done in the past from the dryer control panel. The Pinnacle 20|20 software will indicate the dryer is in "Manual" mode.
- 3. On the Dryer Overview screen, verify the discharge rate and discharge moisture setpoints. Modify them accordingly.
- 4. After the normal fan and burner startup procedure, as outlined in the Operations Manual, begin discharging.
- AccuDry can be selected when the AccuDry button is illuminated white. Begin running in AccuDry and double-check the discharge moisture setpoint (now the only setpoint able to be changed) is correct.

- 6. AccuDry will now automatically adjust the dryer discharge rate to achieve the displayed product target moisture.
- 7. Periodically check the moisture sensors to ensure they are clean and there is good product flow. Metering may be turned off for roughly 60 seconds to clear out any fines or bees wings that may have accumulated in the sampling chute.
- 8. While operating the dryer, calibrate the moisture sensors as required.
- 9. When dryer discharge is turned off, AccuDry will automatically revert to "Manual" mode after 25 minutes.

DOC-PT02-0219 System Settings 3.21





Historical Data

As discussed in the previous chapter, there are 3 tabs at the bottom of the Pinnacle 20|20 Home page: System Settings, Historical Data, and Troubleshooting. Pressing any of these 3 tabs will cause the tab to turn blue and a different set of options, shown as blue tiles, to appear. These options will change if a different tab is selected. This section will discuss the second tab, Historical Data.



Alarm Pop-Ups and History

The first of the four options under Historical Data is Alarm History. By selecting the Alarm History tile, the operator will be taken to a page listing all the active and past alarms. The top portion of the Alarm History page lists the Active alarms, and the bottom portion of the page lists the past, acknowledged alarms. Alarms that are still active are shown in yellow, orange or red depending on alarm type. Alarms that have been resolved appear in green. Each alarm has an ID, name, time and date of occurance. The alarms listed in the Alarms History page are done so in reverse chronological order so that the most recent alarms will always appear at the top. Due to size restrictions, the Alarm History page is limited to approximately 22 past, acknowleged alarms.



DOC-PT02-0219 Historical Data 4.1

Pinnacle 20 | 20 Controls Manual

When an alarm condition occurs, a popup will appear on the screen detailing the reason for the alarm and what type of alarm it is. These popups will appear on any active screen, on both HMI's. Press the "X" button to acknowledge the alarm and make the popup go away. The alarms are color coded to signify what type of alarm it is. Yellow popup alarms are warning alarms, orange pop up alarms are Cool Down alarms and red pop up alarms are critical alarms.



As mentioned, each alarm comes with it's own unique ID or Alarm numbers. The following pages list all the possible alarms, their ID's, name, and cause.

Alarm List

The following table summaries all of the possible alarms that can be generated by the Pinnacle 20 | 20 Control System:

Alarm ID Code	Alarm Name	Alarm Type	Alarm Cause
2	Linear Limit Fire Alarm	Type C	Linear Limits Circuit is Open - One of the LLC switches has opened due to high temperature.
3	High Gas Pressure Fault	Type C	High gas pressure detected in the gas train
4	Emergency Stop Depressed	Type C	Emergency Stop depressed
10	Motor Overload(s)	Type C	Overload has been detected for one of the motors, check the motor circuit protector or soft starter if equipped.
11	Blowers Tri-Start Auxillary	Type A	One of the two contactors A or B has experienced a fault condition
16	Grain Fill Timeout	Туре В	Infeed grain fill is insufficient to maintain grain level.
24	Low Gas Pressure	Туре В	Low gas/fuel pressure detected in the gas/ fuel train
26	Discharge Level	Туре В	The discharge level switch is open due to a possible overload of grain or a blocked discharge takeaway system.
27	Customer Takeaway Fault	Туре В	The customer takeaway equipment has failed or is not on, check customer takeaway equipment status contacts.
28	Discharge Jam - Proximity Switch	Type B	The Discharge metering system has possibly stopped running because the proximity sensor is not detecting rotation.

DOC-PT02-0219 Historical Data

Alarm ID Code	Alarm Name	Alarm Type	Alarm Cause
35	Mid Grain Band	Туре А	The mid-grain temperature has exceeded or dropped below the mid-grain band alarm setpoint for a duration of 30 seconds
36	Mid-Grain Band Delay	Type B	The mid-grain temperature has exceeded or dropped below the mid-grain band alarm setpoint for the duration of the mid-grain band delay
37	Mid-Grain Temperature Probe 1	Type A	Mid-grain temperature probe #1 has failed or become disconnected.
38	Mid-Grain Temperature Probe 2	Type A	Mid-grain temperature probe #2 has failed or become disconnected.
49	Plenum Door(s)	Type C	An open plenum door has been detected with the control power on.
50	Customer E-Stop	Type C	Customer E-Stop Activated
51	Plenum 1 Low Temperature	Type B	The temperature in plenum #1 has dropped below the low temperature setpoint.
52	Plenum 2 Low Temperature	Type B	The temperature in plenum #2 has dropped below the low temperature setpoint.
53	Plenum 3 Low Temperature	Type B	The temperature in plenum #3 has dropped below the low temperature setpoint.
54	Plenum 4 Low Temperature	Туре В	The temperature in plenum #4 has dropped below the low temperature setpoint.
55	Plenum 5 Low Temperature	Туре В	The temperature in plenum #5 has dropped below the low temperature setpoint.

Alarm ID Code	Alarm Name	Alarm Type	Alarm Cause
56	Plenum 6 Low Temperature	Туре В	The temperature in plenum #6 has dropped below the low temperature setpoint.
57	Plenum 7 Low Temperature	Type B	The temperature in plenum #7 has dropped below the low temperature setpoint.
58	Plenum 8 Low Temperature	Type B	The temperature in plenum #8 has dropped below the low temperature setpoint.
61	Plenum 1 High Temperature	Type C	The temperature in plenum #1 has exceeded the high temperature setpoint.
62	Plenum 2 High Temperature	Type C	The temperature in plenum #2 has exceeded the high temperature setpoint.
63	Plenum 3 High Temperature	Type C	The temperature in plenum #3 has exceeded the high temperature setpoint.
64	Plenum 4 High Temperature	Type C	The temperature in plenum #4 has exceeded the high temperature setpoint.
65	Plenum 5 High Temperature	Type C	The temperature in plenum #5 has exceeded the high temperature setpoint.
66	Plenum 6 High Temperature	Type C	The temperature in plenum #6 has exceeded the high temperature setpoint.
67	Plenum 7 High Temperature	Type C	The temperature in plenum #7 has exceeded the high temperature setpoint.
68	Plenum 8 High Temperature	Type C	The temperature in plenum #8 has exceeded the high temperature setpoint.

Historical Data 4.5 DOC-PT02-0219



Alarm ID Code	Alarm Name	Alarm Type	Alarm Cause
75	Infeed Moisture Sensor Signal Missing	Туре А	The infeed sensor signal has dropped to below 0.5VDC and is probably disconnected
76	Infeed Moisture Snesor Signal Too High	Туре А	The infeed sensor signal has exceeded 9.5VDC and is probably too wet or faulty
77	Discharge Moisture Sensor Signal Missing	Туре А	The discharge sensor signal has dropped to below 0.5VDC and is probably disconnected
78	Discharge Moisture Sensor Signal Too High	Туре А	The discharge sensor signal has exceeded 9.5VDC and is probably too wet or faulty
79	Fill 1 Equipment Fault	Туре В	Fill 1 Equipment Status signal failed to close after signal to operate fill equipment.
80	Fill 2 (Cleanout) Equipment Fault	Туре В	Fill 2 Equipment Status signal (Level Auger) Failed to close after signal to operate fill cleanout equipment.
100	Dryer Master Communications	Туре А	The Dryer Master system board is not responding; check: (A) - Dryer Master board not powered up; (B) - Communications between PLC and Dryer Master board; (C) - Dryer Master software stopped.
111	High Discharge Moisture	Туре А	The system has experienced high discharge moisture.
113	High Discharge Temperature	Туре А	The system has experienced high discharge temperature.
114	Critical High Discharge Temperature	Туре В	The system has experienced critical high discharge temperature.

Alarm ID Code	Alarm Name	Alarm Type	Alarm Cause
115	Low Discharge Moisture	Туре А	The system has experienced low discharge moisture.
116	Critical Low Discharge Moisture	Туре В	The system has experienced critical low discharge moisture.
117	Low Discharge Temperature	Type A	The system has experienced low discharge temperature.
118	Critical Low Discharge Temperature	Type B	The system has experienced critical low discharge temperature.
121	High Infeed Moisture	Type A	The system has experienced high infeed moisture.
122	Critical High Infeed Moisture	Type B	The system has experienced critical high infeed moisture.
123	High Infeed Temperature	Type A	The system has experienced high infeed temperature.
124	Critical High Infeed Temperature	Туре В	The system has experienced critical high infeed temperature.
125	Low Infeed Moisture	Туре А	The system has experienced low infeed moisture.
126	Critical Low Infeed Moisture	Туре В	The system has experienced critical low infeed moisture.
127	Low Infeed Temperature	Type A	The system has experienced low infeed temperature.

Historical Data 4.7 DOC-PT02-0219



Alarm ID Code	Alarm Name	Alarm Type	Alarm Cause
128	Critical Low Infeed Temperature	Type B	The system has experienced critical low infeed temperature.
131	High Plenum Temperature	Type A	The system has experienced high plenum temperature.
132	Critical High Plenum Temperature	Type B	The system has experienced critical high plenum temperature.
133	Low Plenum Temperature	Туре А	The system has experienced low plenum temperature.
134	Critical Low Plenum Temperature	Туре А	The system has experienced critical low plenum temperature.
135	AccuDry Suspended	Type B	The system is suspended due to: a. Rate out of range, b. Moisture sensor signal missing, or c. Drying temperature out of range.
141	High Discharge Speed	Type A	The system has experienced high discharge speed.
142	Critical High Discharge Speed	Туре В	The system has experienced critical high discharge speed.
143	Low Discharge Speed	Туре А	The system has experienced low discharge speed.
144	Critical Low Discharge Speed	Туре В	The system has experienced critical low discharge speed.
145	Plenum 1 High Limit Switch	Type C	Burner #1 high temperature switch has been activated

Alarm ID Code	Alarm Name	Alarm Type	Alarm Cause
146	Plenum 2 High Limit Switch	Туре С	Burner #2 high temperature switch has been activated
147	Plenum 3 High Limit Switch	Туре С	Burner #3 high temperature switch has been activated
148	Plenum 4 High Limit Switch	Type C	Burner #4 high temperature switch has been activated
149	Plenum 5 High Limit Switch	Type C	Burner #5 high temperature switch has been activated
150	Plenum 6 High Limit Switch	Type C	Burner #6 high temperature switch has been activated
151	Plenum 7 High Limit Switch	Type C	Burner #7 high temperature switch has been activated
152	Plenum 8 High Limit Switch	Type C	Burner #8 high temperature switch has been activated
153	Blower 1 Motor Starter	Туре А	Blower #1 motor starter has experienced a fault condition
154	Blower 2 Motor Starter	Туре А	Blower #2 motor starter has experienced a fault condition
155	Blower 3 Motor Starter	Туре А	Blower #3 motor starter has experienced a fault condition
156	Blower 4 Motor Starter	Туре А	Blower #4 motor starter has experienced a fault condition

Historical Data 4.9 DOC-PT02-0219



Alarm ID Code	Alarm Name	Alarm Type	Alarm Cause
157	Blower 5 Motor Starter	Type A	Blower #5 motor starter has experienced a fault condition
158	Blower 6 Motor Starter	Туре А	Blower #6 motor starter has experienced a fault condition
159	Blower 7 Motor Starter	Type A	Blower #7 motor starter has experienced a fault condition
160	Blower 8 Motor Starter	Type A	Blower #8 motor starter has experienced a fault condition
161	Blower 1 Air Pressure	Type B	Blower #1 is not providing adequate pressure for burner operation
162	Blower 2 Air Pressure	Туре В	Blower #2 is not providing adequate pressure for burner operation
163	Blower 3 Air Pressure	Туре В	Blower #3 is not providing adequate pressure for burner operation
164	Blower 4 Air Pressure	Туре В	Blower #4 is not providing adequate pressure for burner operation
165	Blower 5 Air Pressure	Туре В	Blower #5 is not providing adequate pressure for burner operation
166	Blower 6 Air Pressure	Туре В	Blower #6 is not providing adequate pressure for burner operation
167	Blower 7 Air Pressure	Туре В	Blower #7 is not providing adequate pressure for burner operation

Alarm ID Code	Alarm Name	Alarm Type	Alarm Cause
168	Blower 8 Air Pressure	Туре В	Blower #8 is not providing adequate pressure for burner operation
169	Blower 1 Air Pressure Switch	Туре А	Blower #1 air pressure switch is indicating air pressure when the blower is not operating
170	Blower 2 Air Pressure Switch	Туре А	Blower #2 air pressure switch is indicating air pressure when the blower is not operating
171	Blower 3 Air Pressure Switch	Туре А	Blower #3 air pressure switch is indicating air pressure when the blower is not operating
172	Blower 4 Air Pressure Switch	Type A	Blower #4 air pressure switch is indicating air pressure when the blower is not operating
173	Blower 5 Air Pressure Switch	Type A	Blower #5 air pressure switch is indicating air pressure when the blower is not operating
174	Blower 6 Air Pressure Switch	Type A	Blower #6 air pressure switch is indicating air pressure when the blower is not operating
175	Blower 7 Air Pressure Switch	Type A	Blower #7 air pressure switch is indicating air pressure when the blower is not operating
176	Blower 8 Air Pressure Switch	Туре А	Blower #8 air pressure switch is indicating air pressure when the blower is not operating
177	Burner 1 Ignition Failure	Туре А	Burner #1 has not been able to maintan an adequate flame signal for dryer operation
178	Burner 2 Ignition Failure	Type A	Burner #2 has not been able to maintan an adequate flame signal for dryer operation

Historical Data 4.11 DOC-PT02-0219



Alarm ID Code	Alarm Name	Alarm Type	Alarm Cause
179	Burner 3 Ignition Failure	Туре А	Burner #3 has not been able to maintan an adequate flame signal for dryer operation
180	Burner 4 Ignition Failure	Type A	Burner #4 has not been able to maintan an adequate flame signal for dryer operation
181	Burner 5 Ignition Failure	Type A	Burner #5 has not been able to maintan an adequate flame signal for dryer operation
182	Burner 6 Ignition Failure	Type A	Burner #6 has not been able to maintan an adequate flame signal for dryer operation
183	Burner 7 Ignition Failure	Type A	Burner #7 has not been able to maintan an adequate flame signal for dryer operation
184	Burner 8 Ignition Failure	Type A	Burner #8 has not been able to maintan an adequate flame signal for dryer operation
185	Burner 1 False Flame	Type C	The flame sensing system has detected the presence of a flame with burner #1 off
186	Burner 2 False Flame	Type C	The flame sensing system has detected the presence of a flame with burner #2 off
187	Burner 3 False Flame	Type C	The flame sensing system has detected the presence of a flame with burner #3 off
188	Burner 4 False Flame	Type C	The flame sensing system has detected the presence of a flame with burner #4 off
189	Burner 5 False Flame	Type C	The flame sensing system has detected the presence of a flame with burner #5 off

Alarm ID Code	Alarm Name	Alarm Type	Alarm Cause
201	Burner 1 Lost Flame	Type B	Burner #1 successfully ignited, but was unable to maintain a sufficient flame
202	Burner 2 Lost Flame	Type B	Burner #2 successfully ignited, but was unable to maintain a sufficient flame
203	Burner 3 Lost Flame	Type B	Burner #3 successfully ignited, but was unable to maintain a sufficient flame
204	Burner 4 Lost Flame	Type B	Burner #4 successfully ignited, but was unable to maintain a sufficient flame
205	Burner 5 Lost Flame	Type B	Burner #5 successfully ignited, but was unable to maintain a sufficient flame
206	Burner 6 Lost Flame	Type B	Burner #6 successfully ignited, but was unable to maintain a sufficient flame
207	Burner 7 Lost Flame	Type B	Burner #7 successfully ignited, but was unable to maintain a sufficient flame
208	Burner 8 Lost Flame	Type B	Burner #8 successfully ignited, but was unable to maintain a sufficient flame
217	Safety Relay Failure	Type C	The Safety Relay failed to latch. Check the safety relay circuit is complete.
218	CoolDown Stopped	Type B	Cooldown Mode stop via HMI pushbutton.

DOC-PT02-0219 Historical Data 4.13



Cool Down Alarms

One of the types of alarms that can occur are Cool Down alarms. When a Cool Down alarm occurs the dryer will enter Cool Down mode and the alarm popup will be orange as shown below:



After pushing the "X" in the upper right hand corner, the popup will disappear. When the dryer enters Cool Down mode, the fill, takeaway, metering /sweep and burners all stop. The fan(s) are the only components left running and they will continue run until the Cool Down timer expires.

The Cool Down timer can be seen from any HMI page, in the upper right hand corner, next to the Home button, while the dryer is in Cool Down mode.



Pressing the Cool Down timer button while the dryer is in Cool Down mode will cause the pop up delow to appear, allowing the user the ability to cancel Cool Down mode or continue with it.



Selecting "No" meands the dryer will continue the Cool Down mode until the timer expires. When the Cool Down timer expires, the fan(s) will automatically stop.

DOC-PT02-0219 Historical Data

Pinnacle 20 | 20 Controls Manual

If "Yes" is selected, Cool Down mode will be cancelled causing the dryer fan(s) to contine to run. *Caution: Cancelling Cool Down mode means the dryer fan(s) will continue to run until commanded by the user, via the HMI, to do otherwise.* To acknowledge when the user selects "Yes", cancelling Cool Down mode, the following pop up will appear.




In addition to the pop up, a line item will appear in the Alarm History page, acknowledging when Cool Down mode has been cancelled.

Cool Down Button

Cool Down mode can be forced by simply pressing the Cool Down button on the Controls page. Doing so will shut down the burner(s), fill cycle and metering. Equipment associated with Takeaway 1 and 2 will begin their shutdown sequence after the takeaway timer, on the fan settings page, expires. The fan(s) will shut down as soon as the Cool down timer, also on the fan settings page, expires.

Trending

The third of the four options under Historical Data is Trending. By selecting Trending, the operator will be taken to a page containing Moisture and Mid-Grain trending graphs.



As previously mentioned in Section 2, the trends displayed on the Monitor page are limited to 2 hour intervals. However, if the "More Trending Options" button located on the Monitor page is pressed, the operator is taken to this Trending page where the trends are displayed on a larger scale. Also, the Trending page allows for the two trending graphs to be displayed at 4 different time intervals. These time inteval options are at the bottom of the Trending page and pressing them toggles the two graphs between 2, 4, 12 and 24 hour increments.

For convenience, the Mid-Grain Trending graph is directly below the Moisture Trending graph. These two graphs are in-line with each other, allowing the x-axis of both trends to be in sync. This makes it easy to read both the moistures and Mid-Grain temperatures at a given time since the time is plotted on the x-axis.

DOC-PT02-0219 Historical Data



Data Logging History

The last of the four options under Historical Data is Data Logging History. By selecting Data Logging History, the operator will be taken to a page listing all the data logged over the past six hours. The data is listed in reverse order with the most recent data at the top of the page. Each row of data contains the date, time, discharge speed, infeed moisture, discharge moisture, discharge moisture setpoint, mid-grain temperature and mid-grain temperature setpoint. The data listed is done so in ten minute increments.

As previously mentioned in Section 2, the running data displayed on the Monitor page is limited to displaying the last 2 hours of data in 10 minutes intervals. However, if the "More Data History" button located on the Monitor page is pressed, the operator is taken to this Data Logging History page where the data is still displayed in 10 minutes increments but spans a period of six hours.

Unlike the data shown on the Monitor page, this page only updates while the dryer is discharging. This allows the operator to see past running data even if the dryer has not been discharging for an extended period of time.



Troubleshooting

As discussed in the previous chapter, there are 3 tabs at the bottom of the Pinnacle 20|20 Home page: System Settings, Historical Data, and Troubleshooting. Pressing any of these 3 tabs will cause the tab to turn blue and a different set of options, shown as blue tiles, to appear. These options will change if a different tab is selected. This section will discuss the last tab, Troubleshooting.




Service

The first of the five options under Troubleshooting is Service. Only qualified service personnel have access to these Service screens. Upon pressing the Service tile, a popup screen will appear requiring a password be entered before access to the service screens is granted.



Pinnacle 20 | 20 Controls Manual

After the correct password is entered, the text and image on the Service button will turn orange and the button itself will be half it's normal size while the servcie technician is logged in. The button shrinks in order to make room for the Service Logout timer. This timer is a countdown that when expired, will automatically log the service technician out of the service screens.



Touching the Service button again, while logged in will navigate to the first Service page, Configuration & Features.



Configuration & Features

The Configuration & Features page is where the configuration of the dryer is defined and ships preloaded with the correct Dryer Configuration, Discharge Configuration and Dryer Features selected.

Dryer Configuration

The Dryer Configuration tile contains a "Load Configuration" button. After installing updated software, the user will need to reselect the correct Dryer Series and Model from the dropdown menu's. The series Dryer Series and Model information needs to be loaded on each HMI indivitually. The serial number will also need to be entered in the Serial Number field.

Discharge Configuration

After the dryer series and model are selected, the values in the Discharge Configuration tile will automatically populate with the proper values associated with that particular dryer series and model.

5.2 Troubleshooting

Dryer Features

After loading software, the proper Dryer Features will need to be enabled. On the bottom half of the page is where these different features that are equipped on the dryer can be selected. Touching on the square box next to the feature will cause a green check to appear in the box, enabling that particular feature and indicating that the dryer is indeed equipped with that option. It is important to only select the features that are equipped on the dryer. Selecting these options allows the information associated with these features to appear on all the other pages of the control.

TruDry Settings

The second button under the Service Page is the TruDry Settings button. This page allows for adjustments to be made to the varaibles that control how the TruDry mode operates.



Here the current Mid-Grain Temperature and Discharge Speed are displayed along with the Mid-Grain Temperature set point which can be adjusted. However, the main purpose of this page is to set the Proportional, Integral, and Derivative parameters of the TruDry PID control loop. Please note that changes to these parameters will drastically impact the operation of the dryer when running in TruDry mode and any settings change should only be done when instructed by Mathews Company service personnel.

The default values for the Proportional, Integral, and Derivative parameters are recommended to be used. If fine-tune adjustments need to be made, the following explains the impact of each parameter:

Proportional - The Proportional parameter determines the gain of the control loop based on the difference between the setpoint and the actual value. Adjustment of this parameter will increase or decrease the gain when a difference between the setpoint and actual value is established.

Integral - The Integral parameter determines the responsiveness of the control loop from a time standpoint. Adjustment of this parameter will cause the control loop to become more or less responsive.


Derivative - The Integral parameter determines the amount of dampening that the control loop will exhibit. Adjustment of this parameter will increase or decrease the amount of overshoot that is observed by the control loop.

DOC-PT02-0219 Troubleshootin



AccuDry Settings

The third button under the Service page is the AccuDry Settings page. This page displays the critical values for the AccuDry system to operate effectively.



Bushel Volumes

In this tile, the Garner, Hot Zone Volume, and Cold Zone indicate how many bushels are contained in those parts of the dryer. The Throughput is the speed the dryer needs to run at in order to move the grain currently at the infeed moisture sensor, to the discharge moisture sensor, in exactly 1 hour. These values are dryer specific, and the AccuDry system uses these values to best determine the rate at which the dryer should be operating. These values also play a crucial role in how the AccuDry predicted moisture value is calculated. Although these values can be input manually they are automatically generated when the Dryer Series and Model are selected on the Configuration & Features page.

The Sensor Offsets and Sensor Slopes

These tiles are where trained service technicians can manually adjust the DM sensor values. The two values that calculate the moistures are the slope and offset values. The voltage measured by the sensor is mutiplied by the slope and then added to the the offest value of the sensor, resulting in a % moisture value. Here, the technician can save time by manually adjusting the slope (not recommended) and/or offset value (preferred) in order to alleviate the need to calibrate multiple times upon initial setup, due to the 0.5% restriction placed on normal calibration routines. The technician may simply enter the desired offset with a single touch of the button, eliminating the need to calibrate several times.

DM 510 Info

This tile contains the DM version and serial number of the DM board installed on the dryer. In addition to this are two adjustable values; Dryer Off Rate and Dryer Off Temp.

Dryer Off Rate - the minimum rate at which the dryer will operate, and it is recommended to remain at 1.0%. This parameter is used to signal the DM510 that the dryer is not discharging and should not be taking any more data. If this is different than the Minimum Operational Discharge Rate, then there is a risk that the system will be calculating dryer operations while shutdown; hurting the overall re-startup time for the next drying run. If this parameter is modified, it is strongly urged that a Mathews Company Engineer or Mathews Company Service Technician is consulted before doing so.

5.4 Troubleshooting

Dryer Off Temp - is used by the DM 510 board in determining whether a plenum is considered a heat zone or cool zone. If the actual plenum temperature is lower than this value, the plenum is considered a cool zone. If the actual plenum temperature is higher than this value, the plenum is considered a heat zone. If the average of the plenum temperatures is under the value entered, the system will not be learning, therefore AccuDry will not be able to be enabled. Note: For best results, never turn burners on or off while operating in AccuDry mode. Instead, get out of AccuDry mode first, then make these changes before getting back into AccuDry mode.

DM 510 Diagnostics

This tile offers even more information on the DM 510 board including the following:

Beta2 Value & Exp - is a feedback from the sensors comparing the predicted moistures versus the actual measured values. This feedback determines how the dryer will control the discharge speed, and should not be modified.

Target difference - the maximum allowed deviation between the actual and predicted values can vary before AccuDry can be enabled. For instance, if the Moist Target Difference is 2.00%, the actual discharge moisture must be within 2.00% of the predicted discharge moisture before AccuDry can be enabled.

Rate Targe Difference - the maximum allowed deviation between the actual and suggested rate before AccuDry can be enabled. If the Rate Target Difference is 5.00%, the acutal discharge rate must be within 5.00% of the suggested discharge rate in order for AccuDry to be enabled.

DM Heart Beat - This indicator light will blink green when the DM Board is communicating with the PLC.

DM Good Heartbeat - This will illuminate green when the communication between the DM Board and PLC is sensed an adequate amount of times within a minute.

Burners Settings

The fourth and fifth buttons under the Service page are the Burners 1 - 4 Settings and Burner's 5 - 8 Settings pages. These pages will only show the values associated with burners equipped on the dryer while the additional burners on these pages will appear grayed out with N/A as values.



Pinnacle 20 | 20 Controls Manual

The actual and setpoint plenum temperature values are shown for each plenum on this page. Changes to the plenum temperature setpoint can be made here. In addition to these values, there are also PID values displayed here as well. The purpose of the Plenum Temp PID Values is to set the Proportional, Integral, and Derivative parameters of the Plenum Temperature PID control loop. Please note that changes to these parameters will drastically impact the operation of the dryer when controlling the plenum temperature and any settings change should only be done when instructed by Mathews Company service personnel.

For each plenum, the values for the Proportional, Integral, and Derivative parameters can be adjusted. The default values for the Proportional, Integral, and Derivative parameters are recommended to be used. If fine-tune adjustments need to be made, the following explains the impact of each parameter:

Proportional - The Proportional parameter determines the gain of the control loop based on the difference between the setpoint and the actual value. Adjustment of this parameter will increase or decrease the gain when a difference between the setpoint and actual value is established.

Integral - The Integral parameter determines the responsiveness of the control loop from a time standpoint. Adjustment of this parameter will cause the control loop to become more or less responsive.

Derivative - The Integral parameter determines the amount of dampening that the control loop will exhibit. Adjustment of this parameter will increase or decrease the amount of overshoot that is observed by the control loop.

HMI Settings

The last button under the Service page is the HMI Settings page.



The upper half of this page displays the information associated with the drive used to update the HMI software along with an activation button used when performing the update.

The bottom half of the page displays the Network Settings along with a PLC comms button that illuminates green when the PLC is communicating properly.

Dryer Components

The second of the five options under Troubleshooting is Dryer Components. This page allows the user to quickly understand a dryer components function and perhaps, how to set it if necessary.

Only the components that are equipped on the dryer will appear on this screen. If a particular component is not equipped on the dryer, it will appear grayed out on this page.



Clicking on any of the component tiles will bring up a screen, detailing the purpose and function of that component.



A brief description of the components listed on the dryer components page is as follows:



High Limit Switch

The High Limit Switch utilizes a capillary bulb to sense an over-temperature condition in the plenum which will cause the dryer to shutdown. The high limit setpoint is adjustable on the switch and should be set approximately 40 deg F higher than the plenum temperature setpoint.



Rotary (Bin) Fill Switch

The Rotary Fill Switch is located in the wet hopper and is powered by 24VDC. The switch is motorized and will rotate a paddle until wet grain comes in contact with the paddle. Once this happens, grain stops the rotation and proves the level of grain in the hopper.



Linear Limit Circuit (LLC) Switch (if equipped)

The Linear Limit Circuit (LLC) Switch is wrapped around the screen section of the dryer and provides a safety shutdown when over-temperature is detected.



Plenum RTD

The Plenum RTD is a temperature sensing device located in the plenum used to send a signal to the PLC to establish and maintain plenum temperature.



Air Pressure Switch

The purpose of the Air Pressure Switch is to prove airflow from the fan for safe operation of the burner. The air pressure switch is adjustable and should be set once the dryer is full of grain. Adjustment of the switch for a profile dryer is done in the burner control cabinet and indication of reaching the air pressure switch's setpoint is indicated on the green light on the outside of the burner control cabinet. For a tower dryer, adjustment of the switch is done in the High Voltage Cabinet and is indicated on the green light on the outside of the High Voltage Cabinet.



E-Stop

The E-Stop buttons are located throughout the dryer and are used to trip the safety circuit and shutdown the dryer when pressed. To reset a pressed E-stop button, simply rotate the spring loaded red button clockwise.



Control Valve Actuator

The Control Valve Actuator is an electrical actuator that is connected to the control valve through a mechanical linkage that precisely positions it based on the output of the PLC. As the plenum temperature drops below the setpoint, the PLC tells the control valve actuator to open more, whereas if the plenum temperature rises above the setpoint, the PLC tells the control valve actuator to close more.



Proximity Switch

The Proximity Switch is used to detect the rotation of the discharge metering system by sensing the proximity of a detector on the discharge metering shaft of profiles and sweep motor for towers. If the rotation goes undetected for a set duration of time, the machine will be shutdown.



Motor Overloads

The Motor Overloads are located in the high voltage cabinet and are used to protect the motors from excessive current. When excessive current draw is detected, the Motor Overload will trip, cutting power to the motor and protecting it.



Discharge Limit Switch

The type of Discharge Limit Switch used depends on the type of dryer; Tower or Profile. The towers use the same paddle style as the Rotary Fill Switch while the Profile dryers use a whisker style switch as shown on the left. The purpose of this switch is to detect a discharge grain overload condition that may be a result of a failed discharge auger or takeaway equipment. Once an overload conditions exists, the safety circuit is opened and the dryer is shutdown.



Mid-Grain RTD Assembly

The two Mid-Grain RTD (Resistance Temperature Device) Assemblies are located around the perimeter of the dryer and are used to detect the temperature of the grain in the column. Each of these two RTD assemblies is equipped with a 4-20mA transmitter which provides an analog input signal sent to the PLC.



DM510 Moisture Sensor

This sensor has a stainless steel fin that measures the grain moisture indirectly by measuring the capacitance of the field of grain and correlating it to a voltage. It also contains a small temperature probe that is mounted directly under the stainless steel fin on the face of the sensor. This probe also produces an analog voltage measurement of the grain's temperature to compensate the moisture reading and to provide a real-time indication of the grain's temperature.



Variable Frequency Drive (VFD)

The VFD's are used to control the speed of the metering and takeaway system and are directly controlled by the PLC.



Ignition System

The Ignition System is comprised of different components, each playing a role in the mangement of the burners. The Ignition System controls the overall operation of the burners by supplying high voltage from the coils to the spark plugs to ignite the burners, sending signals to open/claose the gas valves, and continuously monitoring the presence of a flame for safe and reliable operation.



Gas Pressure Switch

These switches are used to detect either low gas or high gas pressure in the gas train and shutdown the dryer if required.



Plenum Door Switch

The Plenum Door Switch is used to trip the safety circuit, shutting the dryer down in the event a plenum door is opened.

DOC-PT02-0219 Troubleshooting 5.9



System Configuration

The third of the five options under Troubleshooting is System Configuration. This page is broken into two sections, Dryer Configuration at the top and System Configuration at the bottom.



The Dryer Configuration lists the serial number and the model of the dryer that is loaded in the control.

The System Configuration lists the PLC and HMI versions. This is important information given both the PLC and HMI will develop newer, more enhanced versions of the software as time passes.

It also provides a place where the type of grain being dried can be selected. It is important that the proper grain is selected in order to receive accurate information from the moisture sensors.

Other parameters that can be changed on this page is the date, time, temperature units, dicharge units, grain density and the language.

A check box is provided to allow the dryer to be operated remotely by way of M-C Trax. When operating from a remote location, this box must be checked. When a change is made remotely, a pin will be required to be entered. This pin must match the Remote Access 4-Digit pin shown on this page of the HMI.

?

PLC I/O Modules

The fourth of the five options under Troubleshooting is PLC I/O Modules. The PLC and I/O modules are located in the Low Voltage Cabinet. The number of I/O modules depends on the model dryer. On the bottom of the page, only the I/O modules equipped on the dryer will be lit up, and therefore able to be accessed. The grayed out options cannot be accessed as those modules are not equiped on the dryer. Also, the order in which the PLC and I/O modules appear, should match the actual arrangement in which they are physically installed in the Low Voltage Cabinet.

The first option at the bottom of the page is the CPU and is on all Pinnacle 20|20 dryers. The CPU allows up to 14 digital inputs, 10 digital outputs, 2 analog inputs and 2 analog outputs.



Ia.0 - Safety Control Relay

When shown in green, the Safety Control Relay is satisfied.

Ia.1 - Fan Motor Overload(s) Fault

When shown in green, there are no Fan Motor Overload Faults present.

Ia.2 - Takeaway Equipment Status

When shown in green, Takeaway Equipment Status is ready to be started.

la.3 - Fill Equipment Status

When shown in green, Fill Equipment Status is ready to be started.

la.4 - Fill Level Signal

When shown in green, there is currently a call for grain.

Ia.5 - Proximity Switch

When this blinks green, the proximity switch is sensing the metering target.

Ia.6 - E-Stop(s)

When this shows green, all dryer E-Stops are reset. If shown in white, 1 or more dryer E-Stops are depressed and need to be reset.

DOC-PT02-0219 Troubleshooting 5.11



Ia.7 - Customer E-Stop (C5 & C6)

When this shows green, all E-Stops associated with auxillary equipment are reset. If shown in white, 1 or more E-Stops associated with auxillary equipment are depressed and need to be reset.

Ib.0 - Takeaway Overflow

When shown in green, the takeaway switch does not sense grain backup. If shown in white, grain is causing a backup that the switch detected and the situation should be addressed.

Ib.1 - Linear Limits Fault

When shown in green, there are no excessively high temperatures being detected by the Linear Limits. When shown in white, the Linear Limits sense an excessive temperature condition that needs to be addressed.

Ib.2 - Plenum Door(s)

When shown in green, the plenum door switches detect the plenum doors are closed. When shown in white, 1 or more plenum doors are open.

Ib.3 - High Gas Pressure Fault

When shown in green, there is no high gas pressure situation being detected. If shown in white, a high gas pressure situation is being detected.

Ib.4 - Low Gas Pressure Fault

When shown in green, there is no low gas pressure situation being detected. If shown in white, a low gas pressure situation is being detected.

Ib.5 - Auxilary Contactors

Green indicates that the start contactors A and B are turned ON. White means they are OFF.

Qa.0 - Fill 1 Equipment On

When shown in green, equipment tied to F3-F4 will run.

Qa.1 - Fill 2 Equipment On

When shown in green, equipment tied to F5-F6 will run.

Qa.2 - Run Takeaway 1

When shown in green, equipment tied to T3-T4 will run.

Qa.3 - Run Takeaway 2

When shown in green, equipment tied to T5-T6 will run.

Qa.4 - Prime Gas Supply

When shown in green it is commanding the supply gas solenoid to momentarily open to pressurize the gas train to satisfy the low gas pressure requirement.

Qa.5 - Control Power On

When shown in green, the Control Power is on.

5.12 Troubleshooting

Qa.6 - Reset Safety Relay

Momentary pulse to reset and latch the safety relay.

Qa.7 - Tri-Start

Turns green for 15 seconds when a command is sent to start auxilliary tri-start equipment.

Qb.0 - Run Sampler

Command to run discharge sampling motor.

Qb.1 - Run Metering

Command to run metering or sweep.

AIO - Mid-Grain #1 Temp

This is an analog signal that displays the mid-grain temperature being measured at mid-grain probe #1.

Al10 - Mid-Grain #2 Temp

This is an analog signal that displays the mid-grain temperature being measured at mid-grain probe #2


AQ0 - Burner #1 Output

This is an analog output used to control the opening of the gas control valve for burner #1.

AQ1 - Burner #2 Output

This is an analog output used to control the opening of the gas control valve for burner #2.

The next selection at the bottom of the page is an I/O module, allowing up to 16 digital inputs and 16 digital outputs.



Ia.0 - High Limit #1 Fault

Green indicates that the high limit circuit is complete and is functioning properly for burner 1. White indicates that the high limit setpoint has been reached for burner 1, tripping the high limit switch.

Troubleshooting 5.13

la.1 - Fan #1 Motor Starter

Green indicates that the auxiliary contact for fan 1 motor starter is ON. If white, it is OFF.

la.2 - Air Pressure #1

Green indicates that air pressure switch for plenum 1 has been activated and the blower for that plenum is generating sufficient pressure. White indicates low or no pressure.

la.3 - Burner #1 On

A green signal verifies that a flame is present at burner 1. White signifies the absence of flame.

Ia.4 - High Limit #2 Fault

Green indicates that the high limit circuit is complete and is functioning properly for burner 2. White indicates that the high limit setpoint has been reached for burner 2, tripping the high limit switch.

la.5 - Fan #2 Motor Starter

Green indicates that the auxiliary contact for fan 2 motor starter is ON. If white, it is OFF.

la.6 - Air Pressure #2

Green indicates that air pressure switch for plenum 2 has been activated and the blower for that plenum is generating sufficient pressure. White indicates low or no pressure.

la.7 - Burner #2 On

A green signal verifies that a flame is present at burner 2. White signifies the absence of flame.

Ib.0 - High Limit #3 Fault

Green indicates that the high limit circuit is complete and is functioning properly for burner 3. White indicates that the high limit setpoint has been reached for burner 3, tripping the high limit switch.

Ib.1 - Fan #3 Motor Starter

Green indicates that the auxiliary contact for fan 3 motor starter is ON. If white, it is OFF.

Ib.2 - Air Pressure #3

Green indicates that air pressure switch for plenum 3 has been activated and the blower for that plenum is generating sufficient pressure. White indicates low or no pressure.

lb.3 - Burner #3 On

A green signal verifies that a flame is present at burner 3. White signifies the absence of flame.

Ib.4 - High Limit #4 Fault

Green indicates that the high limit circuit is complete and is functioning properly for burner 4. White indicates that the high limit setpoint has been reached for burner 4, tripping the high limit switch.

lb.5 - Fan #4 Motor Starter

Green indicates that the auxiliary contact for fan 4 motor starter is ON. If white, it is OFF.

DOC-PT02-0219



Ib.6 - Air Pressure #4

Green indicates that air pressure switch for plenum 4 has been activated and the blower for that plenum is generating sufficient pressure. White indicates low or no pressure.

lb.7 - Burner #4 On

A green signal verifies that a flame is present at burner 4. White signifies the absence of flame.

Qa.0 - Start / Stop Fan #1

Green indicates that fan 1 motor has been commanded to run. White indicates that it has not been commanded to run.

Qa.1 - On / Off Ignition #1

Green indicates that burner 1 has been commanded to ignite and will stay ON while operating. White indicates that it is OFF.

Qa.2 - Start / Stop Fan #2

Green indicates that fan 2 motor has been commanded to run. White indicates that it has not been commanded to run.

Qa.3 - On / Off Ignition #2

Green indicates that burner 2 has been commanded to ignite and will stay ON while operating. White indicates that it is OFF.

Qa.4 - Start / Stop Fan #3

Green indicates that fan 3 motor has been commanded to run. White indicates that it has not been commanded to run.

Qa.5 - On / Off Ignition #3

Green indicates that burner 3 has been commanded to ignite and will stay ON while operating. White indicates that it is OFF.

Qa.6 - Start / Stop Fan #4

Green indicates that fan 4 motor has been commanded to run. White indicates that it has not been commanded to run.

Qa.7 - On / Off Ignition #4

Green indicates that burner 4 has been commanded to ignite and will stay ON while operating. White indicates that it is OFF.

Qb.0 - Start / Stop Fan #5

Green indicates that fan 5 motor has been commanded to run. White indicates that it has not been commanded to run.

Qb.1 - On / Off Ignition #5

Green indicates that burner 5 has been commanded to ignite and will stay ON while operating. White indicates that it is OFF.

DOC-PT02-0219 Troubleshoo



Qb.2 - Start / Stop Fan #6

Green indicates that fan 6 motor has been commanded to run. White indicates that it has not been commanded to run.

Qb.3 - On / Off Ignition #6

Green indicates that burner 6 has been commanded to ignite and will stay ON while operating. White indicates that it is OFF.

Qb.4 - Start / Stop Fan #7

Green indicates that fan 7 motor has been commanded to run. White indicates that it has not been commanded to run.

Qb.5 - On / Off Ignition #7

Green indicates that burner 7 has been commanded to ignite and will stay ON while operating. White indicates that it is OFF.

Qb.6 - Start / Stop Fan #8

Green indicates that fan 8 motor has been commanded to run. White indicates that it has not been commanded to run.

Qb.7 - On / Off Ignition #8

Green indicates that burner 8 has been commanded to ignite and will stay ON while operating. White indicates that it is OFF.

The next selection at the bottom of the page is an I/O module, allowing up to 8 analog inputs.



AIO - Inlet Moist

Indicates the moisture of the grain flowing across the infeed moisture sensor.

Al1 - Inlet Temp

Indicates the temperature of the grain flowing across the infeed moisture sensor.

?

5.16 Troubleshooting DOC-PT02-0219

AI2 - Outlet Moist

Indicates the moisture of the grain flowing across the discharge moisture sensor.

AI3 - Outlet Temp

Indicates the temperature of the grain flowing across the discharge moisture sensor.

Al4 - Burner #1 Temp

Indicates the plenum temperature from plenum 1 RTD.

AI5 - Burner #2 Temp

Indicates the plenum temperature from plenum 2 RTD.


Al6 - Burner #3 Temp

Indicates the plenum temperature from plenum 3 RTD.

AI7 - Burner #4 Temp

Indicates the plenum temperature from plenum 4 RTD.

The fourth selection at the bottom of the page is another I/O module, allowing for 4 analog outputs.



AQ0 - Burner Control Signal 3

This is an analog output used to control the opening of the gas control valve for burner #3.

AQ1 - Burner Control Signal 4

This is an analog output used to control the opening of the gas control valve for burner #4.

AQ2 - Burner Control Signal 5


This is an analog output used to control the opening of the gas control valve for burner #5.

AQ3- Burner Control Signal 6

This is an analog output used to control the opening of the gas control valve for burner #6.

Troubleshooting 5.17

The fifth selection at the bottom of the page is another I/O module, allowing for 16 digital inputs.



Ia.0 - High Limit #5 Fault

Green indicates that the high limit circuit is complete and is functioning properly for burner 5. White indicates that the high limit setpoint has been reached for burner 5, tripping the high limit switch.

la.1 - Fan #5 Motor Starter

Green indicates that the auxiliary contact for fan 5 motor starter is ON. If white, it is OFF.

la.2 - Air Pressure #5

Green indicates that air pressure switch for plenum 5 has been activated and the blower for that plenum is generating sufficient pressure. White indicates low or no pressure.

la.3 - Burner #5 On

A green signal verifies that a flame is present at burner 5. White signifies the absence of flame.

Ia.4 - High Limit #6 Fault

Green indicates that the high limit circuit is complete and is functioning properly for burner 6. White indicates that the high limit setpoint has been reached for burner 6, tripping the high limit switch.

la.5 - Fan #6 Motor Starter

Green indicates that the auxiliary contact for fan 6 motor starter is ON. If white, it is OFF.

la.6 - Air Pressure #6

Green indicates that air pressure switch for plenum 6 has been activated and the blower for that plenum is generating sufficient pressure. White indicates low or no pressure.

la.7 - Burner #6 On

A green signal verifies that a flame is present at burner 6. White signifies the absence of flame.

5.18 Troubleshooting

Ib.0 - High Limit #7 Fault

Green indicates that the high limit circuit is complete and is functioning properly for burner 7. White indicates that the high limit setpoint has been reached for burner 7, tripping the high limit switch.

lb.1 - Fan #7 Motor Starter

Green indicates that the auxiliary contact for fan 7 motor starter is ON. If white, it is OFF.

Ib.2 - Air Pressure #7

Green indicates that air pressure switch for plenum 7 has been activated and the blower for that plenum is generating sufficient pressure. White indicates low or no pressure.

lb.3 - Burner #7 On

A green signal verifies that a flame is present at burner 7. White signifies the absence of flame.

Ib.4 - High Limit #8 Fault

Green indicates that the high limit circuit is complete and is functioning properly for burner 8. White indicates that the high limit setpoint has been reached for burner 8, tripping the high limit switch.

Ib.5 - Fan #8 Motor Starter

Green indicates that the auxiliary contact for fan 8 motor starter is ON. If white, it is OFF.

Ib.6 - Air Pressure #8

Green indicates that air pressure switch for plenum 8 has been activated and the blower for that plenum is generating sufficient pressure. White indicates low or no pressure.

lb.7 - Burner #8 On

A green signal verifies that a flame is present at burner 8. White signifies the absence of flame.

The sixth, and last selection at the bottom of the page is another I/O module, allowing for 4 analog inputs and 2 analog outputs.



bleshooting 5.19

AIO - Burner #5 Temp

Indicates the plenum temperature from plenum 5 RTD.

Al1 - Burner #6 Temp

Indicates the plenum temperature from plenum 6 RTD.

Al2 - Burner #7 Temp

Indicates the plenum temperature from plenum 7 RTD.

AI3 - Burner #8 Temp

Indicates the plenum temperature from plenum 8 RTD.

AQ0 - Burner #7 Output


This is an analog output used to control the opening of the gas control valve for burner #7.

AQ1 - Burner #8 Output

This is an analog output used to control the opening of the gas control valve for burner #8.

Safety Circuit

The last of the five options under Troubleshooting is Safety Circuit. The Safety Circuit page gives an illustration of the components within the safety circuit and their status.



Again, this screen will look slightly different from dryer model to dryer model given the components that are equipped or not equipped on the dryer. From this page, Control Power can be turned on or off, just as it can be from the Control Page. However, if the safety circuit is not satisfied, Control Power will not be able to be turned on.

? 5.1

5.20 Troubleshooting

Components with green globes next to them indicate components that are good and satisfying that part of the safety circuit. However, if a globe next to the component appears grayed out as opposed to green, that indicates that there is a break in the safety circuit at that particular component. Furthermore, if there is an issue with a component, all components downstream will appear grayed out as well. It is best to check the component that is first in line where the globe is gray. For instance, if the motor overloads are grayed out, the high limits and linear limits (if equipped) will appear grayed out as well. First start troubleshooting the motor overloads, which are upstream from the High Limits and Linear Limits. It is very likely once the issue with the motor overloads are solved, the all other components downstream will glow green as well, satisfying the safety circuit. If not, move on to the next grayed out component downstream and troubleshoot.

Troubleshooting 5.21



Notes			
			_

Pinnacle 20 20 Controls Manual	

DOC-PT02-0219 Notes 6.3

Pinnacle 20 20 Controls Manual	

 <u></u>

DOC-PT02-0219 Notes 6.5

Pinnacle 20 20 Controls Manual	